



WebdynEasy LoRaWAN

User Manual

www.webdyn.com

Index

| Glossary | | |
|---------------------------------|------|--|
| Document historical | | |
| 1. About this Document | 7 | |
| 1.1 Scope | 7 | |
| 1.2 Target Audience | 7 | |
| 1.3 Product Versions | 7 | |
| 1.3.1 Safety Instructions | 8 | |
| 1.4 Regulations | 8 | |
| 2. General Presentation | 9 | |
| 2.1 The LoRaWAN Protocol | 9 | |
| 2.2 The Hub | 10 | |
| 2.2.1 General description | 10 | |
| 2.2.2 Technical Specifications | 13 | |
| 3. Installation and Maintenance | 17 | |
| 3.1 Unpacking | 17 | |
| 3.1.1 Product Contents | 17 | |
| 3.1.2 Hub Identification | 18 | |
| 3.2 Assembly | . 19 | |
| 3.2.1 Opening/Closing the Box | . 19 | |
| 3.2.2 Wall Mounting | . 19 | |
| 3.2.3 Cellular Network | 20 | |
| 3.2.4 LoRa | 22 | |
| 3.2.5 Connection | 22 | |
| 4. Configuration | 27 | |
| 4.1 Embedded web interface | 27 | |
| 4.1.1 Hub Connectivity | . 29 | |
| 4.1.2 LoRaWAN | .34 | |
| 4.1.3 System | . 37 | |
| 4.1.4 VPN | . 38 | |
| 4.1.5 Alarms | . 41 | |

| 4.1.6 Schedules | 12 |
|---|----|
| 4.1.7 Modbus | 17 |
| 4.1.8 Run Actions | 52 |
| 5 | |
| Operation | 55 |
| 5.1 The remote server | 55 |
| 5.1.1 The FTP Server | 55 |
| 5.1.2 Web Service | 57 |
| 5.1.3 MQTT | 59 |
| 5.2 The Configuration | 30 |
| 5.3 The Data | 51 |
| 5.4 Alarms | 52 |
| 5.5 Commands | 52 |
| 5.5.1 "Reboot" Command 6 | 54 |
| 5.5.2 "Factory" Command 6 | 35 |
| 5.5.3 "Update" Command 6 | 35 |
| 5.5.4 6"Connect" Command 6 | 35 |
| 5.5.5 "Status" Command 6 | 35 |
| 5.5.6 "Log" Command 6 | 36 |
| 5.5.7 "Settime" Command 6 | 57 |
| 5.5.8 "Modbus" Command 6 | 57 |
| 5.5.9 "Lorawan" Command 6 | 39 |
| 6. Update | 74 |
| 6.1 Local | 74 |
| 6.2 Remote | 74 |
| 7. Appendix: XML configuration file variables | 76 |
| Offices & Support Contact | 35 |

Glossary

| NAME | DESCRIPTION |
|-------------------|---|
| ABP | Activation By Personalization: ABP activation forces to have the DevAddr and the security key for the peripheral hard-coded in the product. This strategy may seem simpler because the join procedure does not need to be known, but it has security disadvantages. |
| ADR | Adaptive Data Rate: a data rate and radio transmission power optimisation mechanism. It is used to optimise battery consumption. |
| APN | Access Point Name: the name of the access point the gateway uses to connect to the Internet via a mobile connection. |
| AppEUI | The EUI Application is a unique application identifier issued by the IEEE organisation (EUI-64). It is only used in OTAA mode and is used to get the server keys during the JOIN. |
| АррКЕҮ | The Application Key is product specific. It is only used in OTAA mode and is used to get the server keys during the JOIN. |
| AppSKey | The Application Session Key is product specific and is used for end to end application data encryption. It is required in ABP mode and is calculated automatically by the server during the JOIN in OTAA mode. |
| Data Rate | The Data Rate is defined by a digit from 0 to 5 and sets the modulation type, the Spreading Factor and the bandwidth used. |
| DevEUI | Device EUI: the unique identifier issued by the IEEE organisation (EUI-64). |
| Device Address | 32 bit device identifier that is used to uniquely identify the product on the LoRaWAN server. It is required in ABP mode and is supplied automatically by the server during the JOIN in OTAA mode. |
| Ftp | File Transfer Protocol: communication protocol used to exchange files over a TCP/ IP network. |
| HTTP | HyperText Transfer Protocol: client-server communication protocol developed for the Web. |
| IP | Internet Protocol: message protocol in charge of addressing and sending TCP packets over the network. |
| JSON | JavaScript Object Notation: JSON is an easily interpretable data interchange format. |

| LoRa | LoRa is radio modulation including the physical connection and the physical layer in the OSI model. |
|--------------------------|---|
| LoRaWAN | LoRaWAN is a transmission protocol that uses LoRa modulation. |
| MD5 | Message Digest 5: cryptographic hash function used to obtain a file's digital imprint. |
| Modbus | Modbus is a communication protocol routinely used by industry to dialogue with industrial equipment over a network. |
| NTP | Network Time Protocol: protocol used to synchronise the local hub clock with a time reference via a computer network. |
| NwkSKey | The Network Session Key is product specific and is used for end to end LoRaWAN network data encryption. It is required in ABP mode and is calculated automatically by the server during the JOIN in OTAA mode. |
| ΟΤΑΑ | Over The Air Activation: OTAA activation is the preferred and most secure method for connecting to the LoRaWAN network. The product runs a join procedure with the network during which a dynamic DevAddr is assigned and security keys are brokered with the product. |
| PEM | File format standard for storing certificates and private keys in Base64-encoded text format. |
| DIN rail | Standard 35 mm metal rail used in Europe in industrial control equipment in racks. |
| RTU | RTU mode is an RS422/485 hard-wired bus for Modbus. |
| Spreading Factor (SF) | The spreading factor is the length of the sent frames. The more the signal is spread, the lower the speed. However it increases the product range. |
| TCP | Transmission Control Protocol: an Internet-based connection-oriented protocol that provides data packet segmenting services that the IP protocol sends over the network. This protocol provides a reliable data transfer service. See also IP. |
| TCP/IP | Transmission Control Protocol/Internet Protocol: a set of network protocols that provide interconnection services between computers of different hardware architectures and operating systems. TCP/IP includes standards for communication between computers and conventions for network interconnection and routing. |

| UDP | User Datagram Protocol: non connection-oriented protocol of the TCP/IP model transport layer. This protocol is very simple because is does not provide error checks (it is not connection-oriented). |
|-----|--|
| VPN | Virtual Private Network: ecure and encrypted connection between the concentrator and a private network, thus allowing isolation from public telecommunications networks. |
| XML | Extensible Markup Language: generic tagging computer metalanguage. The purpose of XML is to facilitate the automated exchange of complex content between heterogeneous information systems. |
| XSD | XML Schema Definition: file used to validate XML tags and data in an XML file. |

Document historical

| VERSION | DESCRIPTION |
|---------|---|
| V0.11 | Creation |
| V1.0 | Added VPN |
| V3.12 | Add MQTT data support Add LoRaWAN mode C |

1. About this Document

This guide describes the hub assembly, installation and configuration as well as its remote operation.

1.1 Scope

This technical description is valid for WebdynEasy LoRaWAN hubs from hardware version V1 and software version V1.0 onwards.

1.2 Target Audience

This guide is intended for WebdynEasy LoRaWAN hub installers and users, but also for people using our Sens'RF LoRaWAN sensors.

1.3 Product Versions

LoRaWAN hub:

| REFERENCES | VERSIONS |
|------------|--------------------|
| WG0610-A01 | WebdynEasy LoRaWAN |

LoRaWAN Webdyn compatible sensor:

| REFERENCES | DESCRIPTION |
|---------------|--|
| WG0307-D01-EU | Sens'RF-LoRaWAN-Pulse (no external power supply) |
| WG0307-D02-EU | Sens'RF-LoRaWAN-Pressure Humidity & Temp. (no external power supply) |
| WG0307-D03-EU | Sens'RF-LoRaWAN-TIC (no external power supply) |
| WG0307-D08-EU | Sens'RF-LoRaWAN-Analog (0-10V/4-20mA) (no external power supply) |
| WG0307-D11-EU | Sens'RF-LoRaWAN-Pulse (with external power supply) |
| WG0307-D12-EU | Sens'RF-LoRaWAN-Pressure Humidity & Temp. (with external power supply) |
| WG0307-D13-EU | Sens'RF-LoRaWAN-TIC (with external power supply) |
| WG0307-D18-EU | Sens'RF-LoRaWAN-Analog (0-10V/4-20mA) (with external power supply) |

1.3.1 Safety Instructions

It is imperative to follow all the safety instructions in this guide.

Failure to follow these instructions can damage equipment and endanger people.



- All wiring must be carried out only by a specialized qualified electrician.
- Please follow all the safety instructions featured in the equipment documentation.

The WebdynEasy product can be damaged by electrostatic discharges (ESD). When the equipment is open, do not carry out any operations other than those described in this manual. Avoid any contact with the components.

Class 3 equipment: the device operates on safety extra-low voltage (SELV) (50V maximum). The voltage reduction must be obtained using a safety transformer providing safe galvanic isolation between primary and secondary.

Do not install the equipment near a heat source or at a height greater than 2m.

To clean the product, only use a slightly damp cloth to gently clean and wipe the surfaces. Never use aggressive chemical agents or solvents that could alter the plastic material or corrode the metal parts.

To optimise radio and cellular modem reception sensitivity, it is imperative to leave 20 cm free space around the antennas.

1.4 Regulations

The product complies with the European directives according to the EU Declaration of Conformity available from Webdyn or on website: www.webdyn.com.



The European directives enacted into national law covering battery waste and electric and electronic equipment provide the framework for the actions needed to limit the negative impact of the product's end of life. These products are collected separately. Use an authorised battery collection and processing centre or contact Webdyn.

2. General Presentation

The WebdynEasy LoRaWAN hub is part of a line of Webdyn hubs specific to wireless networks. The hub's main function is to be a LoRaWAN gateway to create a LoRaWAN network and collect the data from the different LoRa sensors deployed nearby. The LoRaWAN gateway has 2 running modes:

- Packet Forwarder
- Packet Forwarder with embedded LoRaWAN server

The hub is also used to communicate with Modbus devices in IP or RTU mode.



2.1 The LoRaWAN Protocol

LoRaWAN is a communication protocol that uses LoRa modulation. This communication protocol uses several radio bands (ISM) that are available in the 868 MHz range in Europe without a licence.

In a LoRaWAN network, the radio modules are not paired to a single base station. The data they send is relayed by multiple base stations. Each one sends the information received from a radio module to the management server via a gateway. The intelligence and complexity are located on the server which manages data redundancy, integrity checks, receipt confirmation and the adaptation of the sensor data rate and emission power.

2.2 The Hub

The purpose of the hub is to collect LoRaWAN and/or Modbus data and regularly send it to a remote server (IS) using Ethernet or 3G/4G.

2.2.1 General description

Exterior

Box front face:



Interior

Interior of the box:



- 1. SIM card holder
- 2. Reset button
- 3. RJ45 connector and LEDs
- 4. BLE Bluetooth (future use)
- 5. Request button (identified FUNCTION on the board)
- 6. LoRa RF radio SMA antenna
- 7. Box output for the LoRa RF radio external antenna (option)
- 8. Box RS485/422 output

9. 1x RS485/422 port

10. Indicators:

- LED 8: Power
- LED 3: Modem
- LED 1: CPU
- LED 7: LoRa
- 11. Box output for external power supply
- 12. Terminal block for external 12/24V power supply
- 13.Box output for the 3G/4G modem external antenna (option)
- 14. 3G/4G Modem SMA Antenna
- 15. Mini-USB connector (reserved)

Indicators:

| LED | DESCRIPTION |
|-------|---|
| Power | Lights when the product is powered |
| CPU | Lights depending on the CPU activity |
| LoRa | Off by default and flashes to indicate LoRaWAN radio traffic |
| Modem | Lights when the Modem sets up an IP connection Lights for 1 second on receipt of a text message Following a long press on the Request button, it indicates the received signal level (RSSI) using a number of flashes (0 to 5 times) 0 - signal power ≤ -112 dBm 1 - signal power between -111 dBm and -96 dBm 2 - signal power between -96 dBm and -81 dBm 3 - signal power between -81 dBm and -66 dBm |
| | 4 – Signal power between -66 dBm and -51 dBm 5 - signal power > -51 dBm |

Buttons:

| BUTTON | DESCRIPTION |
|---------|---|
| Request | Short press (less than 2 seconds) => Connection request |
| | Long press (more than 2 seconds) => Displays the Modem signal reception level (see Modem LED) |
| | 3 successive long presses in less than 15 seconds => Return to factory settings |
| Reset | Hub reboot (Hard Reset) |

Never press the RESET button 7 times in less than 30 seconds. This would switch the hub to a special mode that prevents it from starting. To exit the mode, a new hub RESET is required.

End users must make sure their installation using remote antennas meets applicable EMC standards.

2.2.2 Technical Specifications

General Specifications

| PARAMETERS | VALUES |
|-----------------------|--|
| External power supply | +12/24V DC from an external power supply |
| Consumption | 10 Watts maximum |
| Flash memory | 50 Mb (shared between compressed and uncompressed files) |
| Dimensions | 160 x 150 x 55 mm |
| Box | ASA IP67 box |
| Weight | 0.450 kg |
| Operating temperature | -20°C/+55°C |
| Storage temperature | -20°C/+70°C |
| Humidity | 25 - 75 % |

| Pollution rating | 2 |
|------------------|---|
| Certification | RED ROHS REACH |
| Regulation | CE marking created in the framework of European technical harmonisation legislation. It is mandatory for all products covered by one or more European regulatory texts (directives or regulations). |
| | Symbol indicating that the waste must be collected via a specific channel and must not be disposed of as household waste. |
| | Symbol indicating that the product must be recycled. |

Technical Specifications

| PARAMETERS | VALUES |
|----------------------------|---|
| LoRa radio interface | 863MHz -870MHz |
| Modem interface | 3G: HSPA+, UMTS (B1, B8) 4G: Cat-1, Bands B1, B3, B7, B8, B20, B28 |
| -Serial interface | 1 RS422/RS485 Modbus RTU port |
| Ethernet network interface | 10/100 Mbit/s |

| RFBAND | EMISSION FREQUENCIES | MAX. POWER |
|-----------------|----------------------|-----------------|
| 3G 2100MHz (B1) | 1920-1980 MHz | 23 dBm class 3b |
| 3G 900 MHz (B8) | 880-915 MHz | 23 dBm class 3b |

| 4G 2100 MHz (B1) | 1920-1980 MHz | 23 dBm class 3 |
|------------------|---------------|----------------|
| 4G 1800 MHz (B3) | 1710-1785 MHz | 23 dBm class 3 |
| 4G 2600 MHz (B7) | 2500-2570 MHz | 23 dBm class 3 |
| 4G 900MHz (B8) | 880-915 MHz | 23 dBm class 3 |
| 4G 800MHz (B20) | 832-862 MHz | 23 dBm class 3 |
| 4G 700MHz (B28) | 703-748 MHz | 23 dBm class 3 |

LoRa Specifications

| PARAMETERS | VALUES |
|---------------------|--|
| Channels | 8 simultaneous channels: • 863-870 MHz (Europe) • 865-867 MHz (India) |
| Max sensitivity | -141dBm (125kHz in SF12) |
| Supported DataRate | DR0-DR5 |
| Supported Bandwidth | 125/250 kHz |
| Max TX power | +14dBm |
| Activation mode | ABP or OTAA |
| Default frequencies | Europe: 867.1 MHz, 867.3 MHz, 867.5 MHz, 867.7 MHz, 867.9 MHz, 868.1 MHz, 868.3 MHz, 868.5 MHz India: 865.0625 MHz, 865.4025 MHz, 865.985MHz |

Software Specifications

| PARAMETERS | VALUES |
|----------------|--|
| LoRaWAN server | LoRaWAN V1.0.2 class A protocol 1000 LoRaWAN sensors supported 10 gateways supported |
| Modbus | Monitoring in RTU and TCP mode |
| OpenVPN | V2.5.4 |

3. Installation and Maintenance

3.1 Unpacking

3.1.1 Product Contents

Start by checking the contents before starting any installation work. If there are missing or damaged items, contact Webdyn support. (see section 7: "Support")



WebdynEasy LoRaWAN hub

(Ref.: WG0610-A01)

The following are shipped with the hub:

- a curved SMA antenna for the modem (internal)
- a curved SMA antenna for the radio (internal)

3.1.2 Hub Identification

Identification Label

The WebdynEasy LoRaWAN hub can be identified from its identification label located on the box.





Underside view

This label features:

- Product name (WG0610-A01)
- The date of manufacture (in WW/YY format at the top right)
- The serial number in character and 128 barcode format
- The MAC (Ethernet) address in character format

Software Version

The software version can be found on the hub web interface. The software version is given on the "Overview" tab (See section 4.1.1: "Hub connectivity").

3.2 Assembly

It is important to comply with the environment conditions described in section 2.2.2.1: "General specifications" before installing, as well as the following conditions:

- Protect the product from dust, moisture, aggressive substances and corrosion.
- The distance between the hub and Modbus equipment must not exceed the maximum authorised distance for the corresponding interface type (RS485 or RS422) (See section 3.2.5.2: "RS485/RS422 Bus").
- If the Modem connection is used, make sure there is optimum reception when installing. Check the RSSI which is available on the embedded web page (See section 4.1.1.1: "Modem")

To optimise Modem and LoRa radio reception sensitivity, it is essential to leave 20 cm free space around the antennas.

3.2.1 Opening/Closing the Box

Follow these steps to open the hub box:

If the box is wall-mounted:

- Open the 2 doors on the front panel.
- Unscrew the 4 wall mounting screws in the recesses under the doors.

Then follow these steps:

- Unscrew the 4 screws behind the box.
- Remove the cover.

Follow these steps to close the hub box:

- Place the cover on the box base, make sure the seal is properly fitted.
- Screw in the 4 screws on the back of the box.

3.2.2 Wall Mounting

The WebdynEasy can be wall-mounted. Before wall-mounting, first close the box (see section 3.2.1: "Opening/closing the box")

Screws and anchors are not included in the kit. You must choose the correct type of screw for the type of wall you are fixing the hub to (4 mm diameter screw, minimum length 25 mm).

Follow the steps below to fix the hub to a wall:

• Open the 2 doors on the front panel.

- Screw the 4 wall mounting screws into the recesses under the doors.
- Close both doors on the front.

3.2.3 Cellular Network

The WebdynEasy hub includes a 3G and 4G network compatible modem.

3.2.3.1 Antenna

The hub has a female SMA connector labelled "4G" on the board to connect a modem antenna. The product is delivered with an internal antenna. An external antenna can be connected to the product. To do this, unscrew the cap on the box and fit a M16*1.5 cable gland (not included).

If the WebdynEasy hub were to be installed in a metal box or in a location that does not have proper signal reception, the use of a remote antenna is strongly recommended. Be careful to use an antenna compatible with the connector and frequencies used.





End users must make sure their installation using remote antennas meets applicable EMC standards.

3.2.3.2 SIM Card

To use the 3G or 4G modem connection to allow the hub to communicate with the remote server, the box must be opened (see section 3.2.1: "Opening/closing the box") and a mini SIM card inserted into the SIM card housing inside the hub.

The hub is compatible with all market operators as well as with all mini SIM 2FF 25 x 15mm format SIM cards.

To check that the WebdynEasy is operating properly, insert a SIM card with the following specifications:

- Possibility of receiving and sending text messages.
- 3G and 4G communication included.



To insert the SIM card into the product, slide the holder flap to the right (in the OPEN direction). Slide the SIM card into the flap. Then close the flap by sliding it to the left (in the LOCK direction)

Webdyn does not supply any SIM cards. Please contact an M2M operator that supports the 3G and LTE-M network.

Please contact your SIM card provider to find out what information to enter to configuration the modem.

By default, the hub configuration does not request a PIN code (PIN Mode: Off). If you want to enable the hub PIN code, it is preferable to configure it before the SIM card is installed. (see section 4.1.1: Hub connectivity)

There are three possibilities:

- The PIN code is disabled: modem communication is active.
- The PIN code is enabled and the entered PIN code is correct: modem communication is active.
- The PIN code is enabled and the entered PIN code is incorrect: modem communication is in error.

If the SIM card has an enabled PIN code and it is incorrect the first time the hub is started, it will be blocked after 3 attempts. It can be unlocked using a mobile phone using the PUK code provided by the operator.

3.2.4 LoRa

The hub has a female SMA connector labelled "RF" on the board to connect a radio antenna. The product is delivered with an internal antenna. An external antenna can be connected to the product. To do this, unscrew the cap on the box and fit a M16*1.5 cable gland (not included).

To optimise the radio range, it is important to install the radio antenna as high as possible and to place it carefully, avoiding obstacles as far as possible. As a priority, move it away from any metal (cupboard, beams...) or concrete (reinforced concrete, walls...) obstacles as they greatly attenuate radio waves.





External antenna

End users must make sure their installation using remote antennas meets applicable EMC standards.

3.2.5 Connection

3.2.5.1 Power Supply

The WebdynEasy hub must have a 12V or 24V DC power supply. Power is supplied from terminal block J11 on the bottom left side of the board.

End users must use a CE certified power supply of less than 15 watts. The distance between the power supply and the product must not exceed 3 metres. End users must make sure their installation meets applicable EMC standards.



Make sure the power supply wires are connected to the proper terminals.

Product power consumption varies depending on its configuration. Make sure the power supply used can provide a minimum power of 10Watts.

3.2.5.2 RS485/RS422 Bus

The RS485/RS422 communication bus is only used for RTU mode modbus, RS485 is screen printed at the bottom right of the board. This interface is Half Duplex (2 wires) and Full Duplex (4 wires) compatible.

If several modbus RTU devices are connected, the wiring must be "serial". The cable arrives at a modbus module and exits towards the next one.

To guarantee proper data bus operation, an RS485 bus must feature a 120 Ohm terminator at each end. The WebdynEasy hub can be located at the end of the RS485 communication bus or in the middle. As the hub has a 120 Ohms resistor, it made need to be enabled depending on the hub position on the bus (see wiring).

There are 3 separate considerations for the choice of cable type:

- On installations requiring short lengths with no electric interference, plan on using a 2 pair 6/10 rigid screened cable.
- On larger installations of which the cable length is less than 500 m, plan on a 2 pair 8/10 rigid screened cable.
- When the cable distance is more than 500 m, and even more so if there is electric interference, plan for a shielded 2 pair 0.34 mm2 cable.

 Δ The maximum RS485 bus length is 1000 metres.

Recommendations for RS485/RS422 BUS wiring:

- The modules must be connected one after the other.
- Star connections are prohibited.
- The cables must either be screened or shielded, twisted pair per pair (see above: "cable type for RS485 bus connection").
- The cable screen or shielding must be connected to the hub box earth and not to the 0 V (only connect one end of the screen).
- Avoid any return trips in the same cable.

RS485 wiring on the hub side:

- Strip the RS485 communication cable sheath over about 4cm.
- Shorten the shielding down to the cable sheath.
- Strip the wires over about 6 mm.
- Connect the conductors to the terminal block marked RS485, following the assignments in your RS485 communication bus.



3.2.5.3 Ethernet

To configure the hub, first open the box to access the RJ45 connector (see section 3.2.1: "Opening/ closing the box"). Once open, connect the hub to the computer using an Ethernet cable.



A static IP address needs to be configured on the computer in the same IP address range and the same subnet as the WebdynEasy LoRaWAN hub.

The WebdynEasy LoRaWAN hub default configuration parameters are the following: IP address: 192.168.1.12 Subnet mask: 255. 255. 255.0 DHCP: Deactivated

The next step is used to configure a PC network address to access the WebdynEasy LoRaWAN hub:

Configuring a second IP address on the PC:

- Under Windows 10, click Start/Settings/Network & Internet. The "Network Status" window is displayed.
- Click on "Ethernet" on the left of the window, then "Network and sharing centre" on the right.
- The "Network and sharing centre" window is displayed.
- Click "Ethernet" connections. The "Ethernet Status" window is displayed.
- Click "Properties".
- Select "Internet Protocol (TCP/IPv4)" then click the "Properties" button.
- Then click "Advanced".
- In the "IP Address" zone, click "Add".
- Enter IP address 192.168.1.xxx (xxx between 1 and 254 and not equal to 12) and the subnet mask 255. 255. 255.0.
- Click "Add".
- To validate the settings, click OK in each one of the three windows.
- Close the Network connection and remote access window.

It is now possible to easily modify the hub configuration using its embedded web interface using the computer's web browser. (See section 4.1.1 : "Hub connectivity")

4. Configuration

The first time the WebdynEasy LoRaWAN hub is configured, the Web interface embedded in the product is used.

4.1 Embedded web interface

To access hub's embedded web interface, proceed as follows:

- Launch the web browser. The web interface is compatible with the latest versions of the following browsers: Firefox, Chrome and Edge. Older versions may work but they are not supported (IE 7 for example).
- Enter the hub IP address in your browser (the default address is: http://192.168.1.12) to access the WebdynEasy LoRaWAN home page.
- An identification window should be displayed:

| Authentification | requise | × |
|------------------|--|---|
| | Le site http://192.93.121.159 demande un nom d'utilisateur et un mot de passe. Le site indique : « webdyn » | _ |
| Mot de passe : | | |
| | OK Annuler | |

Enter your login and the password:

| LOGIN | PASSWORD | RESTRICTIONS |
|---------|----------|---|
| admin | high | None |
| install | medium | System, LoRaWAN, Modbus, Actions Read-only schedules |
| data | low | Actions only |

Password: to secure access to the hub, we recommend changing the default passwords following the first configuration. Passwords are changed in the XML configuration file (see: "Appendix A: XML configuration file variables")

• The home page is displayed:

| | Gateway | | - Hodem | - | - Ethanet |
|-----------------------------|---|-------------|----------------------|-------------|----------------------|
| uto: | 010471 | Hodel | W97607-1 | 197 | (92,168.1.12 |
| Rame: | WG_010471 | Ferrware: | SW89X07Y_02.18.05.00 | DPv6: | Ne801205cf3R3e015471 |
| Firmware: | 3.2.0.36961 | DHET: | 359760080998747 | RX (bytes): | 862392 |
| Kernet | 3,18,44 | HSISDN: | 8944500706199332204 | TX (bytes): | 834770 |
| | | RSSI | 4 | | |
| | | CSQ (dtm); | -53 | | |
| | | IP: | 10.109.164.60 | | |
| | | RX (bytes): | 5968 · | | |
| | | TX (bytes); | 11390 | | |
| | | | - System | | Rallian Gateway |
| IP: | | Defaults: | | UID: | 00058389e01047 (|
| RX (bytes): | 2 | | | Ramming; | 0 |
| TX (Bytes): | P | | | | 0 |
| L | Rawan Server | | | | |
| Connected gateways: | | | | | |
| UD IP 3/3/ffed10471 127. | Last message 0.0.1 2023-12-13710:06:58 | | | | |

The "Overview" tab provides an overall view of WebdynEasy LoRaWAN operation

If web pages are accessed during the hub initialisation phase, the displayed. Wait for the hub to be fully initialised to access the web pages

4.1.1 Hub Connectivity

The "Connectivity" tab is used to configure the hub to communicate with the remote server.

4.1.1.1 Modem

| | Modem |
|-----------------------|------------|
| PIN Mode: | Off ~ |
| PIN Code: | 1234 |
| APN: | tm |
| Login: | |
| Password: | |
| Mode: | AlwaysOn ~ |
| Disconnect delay (s): | 60 |

| PARAMETERS | DESCRIPTION |
|------------|--|
| Pin Mode | Off: The SIM card PIN code must be disabled |
| | Manual: The SIM card PIN code must be entered in the PIN Code box |
| PIN Code | The SIM card PIN code must be entered if Manual is selected in PIN Mode |
| APN | Your mobile operator's APN name (required for an IP connection) |
| Login | Your mobile operator's user name (optional depending on the operator) |
| Password | Your mobile operator's password (optional depending on the operator) |
| Mode | OnDemand: The hub only connects when it needs to communicate with the remote server. It cuts the connection when the data transfer is complete after a duration that can be configured in Disconnect delay. |
| | AlwaysOn: The modem is always connected. The hub uses the modem continuously for all IP communications. |
| | AlwaysOff: This mode should be used if there is an Ethernet connection to the remote server, but with a SIM card inserted in the hub. The connection never uses the modem, but the hub can receive and send text messages. |

Disconnect delay (s)

Waiting time value in seconds for OnDemand mode between the end of data exchanges and disconnection

(1)

Refer to your mobile operator to obtain the information for your SIM card (APN, login, password).

4.1.1.2 Ethernet

| | Ethernet |
|--------------|---------------------|
| IP: | 192 • 168 • 1 • 12 |
| Netmask: | 255 • 255 • 255 • 0 |
| Gateway: | • • • |
| | Use DHCP |
| | DNS |
| DNS servers: | •••• |

| PARAMETERS | DESCRIPTION |
|-------------|---|
| IP | The IP address used to access the WebdynEasy LoRaWAN hub via the Ethernet network. |
| Netmask | Your Ethernet network subnet mask. This mask limits the Ethernet network to defined IP addresses and separates the network ranges from each other. |
| Gateway | Your Ethernet network gateway address. The gateway address is the IP address for the device that connects to the internet. The address entered here is usually your ADSL/fibre router address. |
| Use DHCP | Ethernet parameters can be obtained automatically if the network infrastructure allows. In that case, select dynamic mode and refer to your DHCP server configuration to find your hub IP address. |
| DNS servers | List of DNS servers. DNS (Domain Name System) servers translate explicit internet addresses (for example, www.webdyn.com) into their corresponding IP addresses. Enter the DNS server addresses you received from your internet service provider (ISP) here. You can also enter your router IP address. You can also use the google DNS: "8.8.8.8". |

The hub can only use the Ethernet connection to access the server if the modem connection is disabled ("off" or "alwaysoff"). Otherwise the hub will attempt to connect using the modem.

4.1.1.3 FTP

| | FTP |
|-----------|-----------------|
| Address: | ftp3.webdyn.com |
| Login: | login |
| Password: | password |
| Root: | /LoRaWAN |

| PARAMETERS | DESCRIPTION |
|------------|---|
| Address | IP address or remote FTP server name (default port: 21). The FTP port can be changed by adding ": " and then a port number. |
| Login | The login used by the hub to connect to the remote FTP server. |
| Password | The password used by the hub to connect to the remote FTP server. |
| Root | Remote FTP server root directory. |

The directory tree structure is to be created on the remote FTP server before any FTP connections. (see section 5.1.1.1: "The FTP server: Configuration")

4.1.1.4 Web Services

| V | /eb services | |
|------------------|------------------|-----------|
| URL: | http://192.93.12 | 1.120:500 |
| Login: | login | |
| Password: | password | |
| Proxy: | | |
| Trust model | Verify peer | ~ |
| pload POST path: | /upload | |

| PARAMETERS | DESCRIPTION |
|------------|--|
| URL | IP address or name of the remote web server (Default port: 80). Possibility to modify the port of the web server by adding ":" then the port number. |
| Login | Username used by the hub to connect to the remote web server. |
| Password | Password used by the concentrator to connect to the remote web server. |

| Proxy | Proxy IP address or hostname (Default port: 1080). Ability to modify the proxy port by adding ":" then the port number. The proxy is optional if it is not used, the empty field must be empty. |
|------------------|---|
| Trust model | Verification of authentication certificates (only for secure HTTPS connections): Verify peer: Verification of authentication certificates. Trust peer: Accepts all authentication certificates (not recommended). |
| Upload POST path | Path on the remote web server. |

4.1.1.5 MQTT

| PARAMETERS | DESCRIPTION |
|------------------------|--|
| Adress | IP address or name of the remote web server (Default port: 1883) |
| Auress | Possibility to modify the port of the mqtt server by adding ":" then the port number |
| Client ID | Client's MQTT identifier |
| Login | Username used by the hub to connect to the remote MQTT server |
| Password | Password used by the hub to connect to the remote MQTT server |
| Keepalive interval (s) | Time in seconds for sending keep-alive frame |
| Topic | Topic of MQTT messages used |
| | Verification of authentication certificates (only for MQTTS secure connections): |
| Trust model | • Verify peer: Verification of authentication certificates. |
| | • Trust peer: Accepts all authentication certificates (not recommended) |

4.1.1.6 NTP

| | Time |
|----------------------|--------------|
| Alarm threshold (s): | 0 |
| NTP servers: | pool.ntp.org |

| PARAMETERS | DESCRIPTION |
|---------------------|--|
| Alarm threshold (s) | Difference in seconds between the hub time and the NTP synchronisation time beyond which an alarm is issued. |
| NTP servers | Addresses of the NTP servers used for the hub clock synchronisation. |

At the first connection, NTP synchronisation is carried out and the next NTP synchronisation will be carried out during another connection after a minimum period of time. The minimum time between NTP synchronisations can be configured using the "min_syn_interval " variable in seconds.

4.1.1.7 Upload

| | Upload |
|-----------|-----------------|
| | Configuration |
| Method: | FTP v |
| s | upervision data |
| Method: | FTP V |
| | Alarms |
| Method: | FTP v |
| | Data |
| Method: | FTP V |
| Format: | XML ~ |
| Schedule: | NOT SET V |

The concentrator can deposit the following data on the remote server:

| NAMES | DESCRIPTION | FORMAT |
|------------------|----------------------------|-----------------|
| Configuration | Hub configuration data | • XML |
| Supervision data | Hub monitoring data | • XML |
| Alarms | Alarms | • XML |
| Data | LoRaWAN and/or modbus data | • XML • JSON |

For each type of data, the concentrator can deposit the data by:

- FTP
- Web Service

If commands are sent by Web Service, the concentrator responds to the commands through alarms. In this case, it is necessary to configure the alarms in Web Service.

The data repository must be associated with a Schedule by entering its configured unique identifier (see chapter 4.1.6: "Schedules").

Consult chapter 5.2: "Configuration" to find out about the format and content of the configuration, supervision, alarm and data files.

The directory tree on the remote FTP server must be created before any file upload. (see chapter 5.1.1.1: "The FTP server: SettingsSettings").

4.1.2 LoRaWAN

The "LoRaWAN" tab is used to configure the Packet Forwarder and the LoRaWAN server. These 2 parts are completely separate. The Packet Forwarder can be used with a remote server and the embedded LoRaWAN server can use an external Packet Forwarder.

4.1.2.1 Packet Forwarder

In Packet Forwarder mode, the WebdynEasy LoRaWAN has a gateway role. The gateway continuously polls the LoRa radio interface and sends all received frames to the LoRaWAN server (remote or embedded) using an IP connection.

For the Packet Forwarder to operate, it must set up a permanent IP connection to the server using its Ethernet interface or Modem in AlwaysOn mode.

| Pac | ket Forwarder | |
|----------------------------|---------------|--|
| Server address: | 127.0.0.1 | |
| Upstream server port: | 1700 | |
| Downstream server port: | 1700 | |
| Keepalive interval [s]: | 10 | |
| Push timeout [ms]: | 10 | |

| PARAMETERS | DESCRIPTION |
|------------------------|--|
| Server address | LoRaWAN server IP address or name. To use the embedded LoRaWAN server on the hub, use the following address: "127.0.0.1" |
| Upstream server port | Packet Forwarder outgoing UDP port number. |
| Downstream server port | Packet Forwarder incoming UDP port number. |
| Keepalive interval [s] | Time in seconds to send a keep alive frame. |
| Push timeout [ms] | Maximum waiting time in milliseconds to acknowledge the frame sent to the LoRaWAN server. |
| | |

The supported Packet Forwarder is the Semtech forwarder.

4.1.2.2 LoRaWAN server

The LoRaWAN server manages the LoRaWAN sensors as a private network. It includes all the LoRaWAN network functions (gateway, LoRaWAN server and application server). All received data is stored in files and all available data is uploaded at every FTP connection.

To use the hub Packet Forwarder enter the following IP address in "Server address": "127.0.0.1". Also check that the server ports ("Upstream server port" and "Downstream server port") are set to 1700.

| Serve | er Configuration | |
|---------------|------------------|--|
| Net ID: | 1532673 | |
| | | |
| Enable: | | |
| Margin [db]: | 5 | |
| Uplink count: | 20 | |

| PARAMETERS | DESCRIPTION |
|--------------|--|
| Net ID | 24 bit hexadecimal value used to identify LoRaWAN networks. If you enter 0, when the hub reboots, it will use its factory NetID. |
| Enable | Check to enable ADR (Adaptive Data Rate). |
| Margin [dB] | Margin in dB to calculate ADR between 1 and 30. |
| Uplink count | The number of uplinks needed for ADR between 1 and 65535 included. |

In order to optimize the sensor stacks and the LoRAWAN bandwidth, it is strongly recommended to leave ADR enabled and the default configuration of Margin and uplink count.

For the calculation of the ADR, the concentrator needs at least 20 uplinks, i.e. the Uplink Count variable is used after the first 20 uplinks received by the concentrator before sending ADR commands to the sensor LoRaWAN.

LoRaWAN sensor:

The server supports 2 activation modes:

- ABP (Activation By Personalization): the DevAddr, NwkSKey and AppSKey parameters must be entered.
- OTAA (Over The Air Activation): the DevEUI and AppKey parameters must be entered, the AppSKey and NwkSKey keys are generated and saved at JOIN time.

| DevEUI: | | |
|----------|---|--|
| AppKey: | | |
| DevAddr: | | |
| AppSKey: | _ | |
| NwkSKey: | | |

| PARAMETERS | DESCRIPTION | ABP | ABP |
|------------|--|-------|-----|
| DevEUI | Unique sensor identifier (EUI64) in 8 byte hexadecimal format | empty | • |
| АррКЕҮ | Hexadecimal 16 byte encryption key used by the network to derive the session keys. | empty | • |
| DevAddr | Sensor address in 4 byte hexadecimal format | • | auto |
|---------|--|---|------|
| AppSKey | Encryption key between the sensor and the application server in 16 byte hexadecimal format | • | auto |
| NwkSKey | Encryption key between the sensor and the LoRaWAN server in 16 byte hexadecimal format | • | auto |
| | | | |

AppEUI is not used by the embedded hub server.

The LoRaWAN sensor data is uploaded in XML format (see section 4.1.1.5: "Upload") to the DATA directory on the remote FTP server (see section 5.3 "The data").

4.1.3 System

| Mode: | Modbus | ~ | | |
|------------|--------|---|--|--|
| Baudrate: | 19200 | ~ | | |
| Data bits: | 8 | ~ | | |
| Parity: | Even | ¥ | | |
| Stop bits: | 1 | ~ | | |

When the Modbus protocol is enabled on the RS485 port, the serial port parameters must be defined.

| PARAMETERS | DESCRIPTION |
|------------|---|
| Mode | Off: RS485 disabled Modbus: RS485 enabled in Modbus mode |
| Baudrate | 4800 9600 |
| | 19200 (default value) |
| | 57600 |
| | 115200 |
| | |

| Data bits | 5 |
|-----------|----------------------|
| | 6 |
| | 7 |
| | 8 (default value) |
| | 9 |
| Parity | None |
| | Odd |
| | Even (default value) |
| Stop bits | 1 (default value) |
| | 2 |

4.1.4 VPN

The hub supports VPN from OpenVPN V2.5.4 (https://openvpn.net/).

| | OpenVPN |
|-----------|---|
| Enable: | |
| Protocol: | udp |
| | - Server |
| Address | vpn.webdyn.com |
| Port | 1194 |
| Cinhar | AEC 255 CPC |
| sipher. | ACS-230-COC |
| Autho | |
| CA: | MIIFMTCCAxmgAwIBAgIJALZAhXiaEan1MA0GCSqGSIb3DQEBCwUAMBQx EjAQBgNVBAMMCVdIYmR5biBDQTAgFw0xOTA2MTcxMTQzMTJaGA8yMTE 5MDUyNDExNDMxMlowFDESMBAGA1UEAwwJV2ViZHluIENBMIICIJANBgkq hkiG9w0BAQEFAAOCAg8AMIICCgKCAgEApTNkOoFT+HpF54vAlmUd2upT Ygobjfq0No51LxNLC79WFRydnwcf4sdGHvejXIZ3zGCFvDuzKabwJpS3BXFB nR9qWJPkDcB57+MFsay4QFBRzQ8O+Ibya4boLKRRI6Ivw0oLRi5vwSpfBsD Td36cvEq5Vp857Vzf44EJhbdGHhIaGmSJwZSk5IG9+lqbRBUD+/m3eZZU Dz2A8abvc1Px3mnNpiF0vUsiP4kG2+nz4V9R2oXuoU6HSqipPC4YoaF6YEP xXFLyGbZKGrEa0zvTc7QfTsQooYIL7aRMOuwgIaWFI4IzWaEU+o6rZXvfHLp TmaYk/ciloolGNJwdTfoca8WfYu3ZoIIkhRo0KEfL9II |
| Cert: | BEGIN CERTIFICATE MIIFUZCCAzugAwIBAgIQObraCQvrfPFZktu0g33L8TANBgkqhki69w0BAQsF ADAUMRIWEAYDVQQDDAXZWJkeW4gQ0EwHhcNMjAwMzEyMTA1MDQ1 WhcNMzAwMzEwMTA1MDQ1WjAfMR0wGwYDVQQDDBRq2WFuLWJhcHR pc3RLWxhcHRvcDCCAIwDQYJKoZIhvcNAQEBBQADggIPADCCAgoCggIBA NC8HfxITk2L8632P2e4SJitucTYy+WhOcoOr8M6KgNTQayVTU9jcobpQDM E6jLQo2nqeefp+bsApGow3wizTRpQSDcsXqsrzXr2Cja/Def8BBVu0B11PD WPmqDrEVkrvgZqfkZ5vJeMEvAwOeiwAf9NaMIL /jehWiAAI9EeEkigSqlLxWs4E0 /grYldBGmIE1ROUEX7JWQKR6DRUaMyNTQtXDMHMCh0CTzeToy5bRQWU NJ02Omh5IvnAemvOCh6vexrLvz1Cak69tAxP6ciFRzuOiOpidahxo5woUP3 |
| Key: | BEGIN RSA PRIVATE KEYMIIJKgIBAAKCAgEA0Lwd/GVOTYvzrfY /Z7hImW25xNjL5aE5yg6vwzoqA1NBrJVNT2NyhulAMwTqMtCjaep55+n5u wCkajDfCLNNGIBK0lyxeqyvNevYKNr8N5 /wEFW7QEjUBNY+aoOsRWSu+Bmp+Rnm8HwS8DA56LAB /01owgv+N6FaIACX0R4SSWBKqIVFazgTT+CtV0EauUTVE5QRfsIZApHoNF RozI1NC1dswcwKHQJPN50jLltFBZQ0DY6aHkjKcB6a84KHq97Gsu /PUJqTr20DE/pyMVHO46M6mJ1qHGjnClQ /dcWHeiHmaHEAzhKaZfyD8G1ze0eILPmPSrKCboB2hOScc+9xtkJ7V9K63X oGxTmSZUIRJ5sn4/B3Srm /AjfJbhhDcFTwluCN0ATWdnUAsWjrnyo0tgUXNZrrqGWIILQazKsdJm1ghV ATtpRzrCKKTVfA5iolU9v00UoacO9vLPwCeiDztfiCh4J0cJH6lhoEvosrv5ORD |
| | Channel Security |
| Method: | tls-auth 🗸 |
| | |
| Key: | with mentioned prime were to |

| PARAMETERS | DESCRIPTION |
|------------|---|
| Enable | Check to enable VPN |
| Protocol | Communication protocol used: • tcp • udp |
| Address | IP address or VPN server name |
| Port | VPN server port (usually 1194) |
| Cipher | Data packet encryption algorithm (optional). List available on OpenVPN ("openvpnshow-ciphers" command). |
| Auth | HMAC hash algorithm to authenticate data packets. If "TLS Auth" is entered then the hashing algorithm also applies to control packets. If the field is empty, the value used by default is "SHA1" (optional). List available on OpenVPN ("openvpnshow-digests" command). |
| CA | CA root certificate. In PEM file format |
| Cert | Local client signed certificate. In PEM file format |
| Кеу | Local client's private key. In PEM file format |

Channel Security:

| PARAMETERS | DESCRIPTION |
|------------|--|
| Method | List of methods for control channel security: • none: none • tls-auth: static key used for the HMAC hashing algorithm on control packets. • tls-crypt: Same as tls-auth, but also encrypts the TLS control channel. • tls-crypt-v2: Same as above, but uses one key per client instead of a shared group key. |
| Key | Key for control channel security. In PEM file format. |

To find out what information to enter for the VPN configuration, please contact the network administrator of the VPN server.

The configuration of an NTP server is mandatory for the use of a VPN in order to verify the validity of the certificates. (see chapter 4.1.1.5: "NTP").

4.1.5 Alarms

The hub can generate system alarms.

| Modem IP: | Off | |
|-------------|------------|---|
| MSISDN: | Off | • |
| SW Version: | On | |
| | - Defaults | |
| Ignored: | | |
| Delayed: | <u> </u> | |

There are 3 types of system alarm:

- Modem IP: alarm generated if the IP address obtained during a modem connection changes.
- MSISDN: alarm generated if the SIM card inserted in the hub is replaced.
- SW Version: alarm generated if the firmware or core versions change (following an update).

Each alarm source can be enabled separately and immediately transferred to the remote server (On) or transferred at the next connection (Delayed).

The hub malfunction alarms ("Default") are sent to the remote server immediately by default. They can however be disabled ("Ignored") or delayed ("Delayed") and sent at the next connection. To do that, the codes must be entered in the fields corresponding to the required behaviour.

Below are the available codes and faults:

| CODE | DESCRIPTION |
|-----------------------|-------------------------------|
| D_MODEM | Modem fault |
| D_MODEM_SIM_MISS | SIM card missing |
| D_MODEM_SIM_CODE_FAIL | SIM code error |
| D_MODEM_PUK | SIM card locked |
| D_MODEM_REG_DENIED | Network registration declined |

The fault codes ignored by the hub can be listed in the Ignored box. If several fault codes are entered, they must be separated by a comma ",".

The fault codes to be transferred by the hub at the next connection can be listed in the Delayed box. If several fault codes are entered, they must be separated by a comma ",".

4.1.6 Schedules

The scheduler is in charge of all regular tasks. The scheduler configuration is a list of schedules. Each schedule has a unique identifier which is used to link one or more tasks to a schedule. They can be used separately to trigger data collection and data uploads.

| 1d: | | | |
|---------------|-------|--|--|
| Label: | | | |
| Type: | Daily | | |
| Time: | | | |
| Interval (s): | | | |
| Count: | _ | | |

Each schedule is configured as follows:

| PARAMETERS | DESCRIPTION |
|--------------|---|
| ld | Unique schedule identifier. The identifier must be an integer. (between 1 and 2,147,483,647 included). |
| Label | Purely descriptive schedule name. |
| Туре | Daily, Weekly, Monthly, Yearly or Follower: see description below. |
| Time | Time of the first occurrence in "HH:MM:SS" format (not used for "Yearly" type schedules). |
| Day of Week | Number of the day in the week of the first occurrence (1=Monday, 7=Sunday) (only used for "Weekly" type schedules). |
| Day of Month | Number of the day in the month of the first occurrence (only used for "Monthly" type schedules). |
| Date & Time | Date and time of the first occurrence in a given period (only used for "Yearly" type schedules). |

| Interval (s) | Interval between occurrences (in seconds). |
|--------------|--|
| Count | Number of occurrences (at least 1). |
| Parent | Reference to the parent schedule for a "Follower" type schedule. |

Configuring the different schedule types:

• "Daily" type schedule:

Every day, the first occurrence is given by the time entered in the "Time" field. The number of events in the day is given by the "Count" field and the interval between each event by the "Interval" field



The Time format is the following: HH:MM:SS (for example 09:30:00)

The "Count" value is between 1 and 2,147,483,647 included

The "Interval" value is between 0 and 2,147,483,647 included

"Count": if the schedule is to be triggered throughout the day at regular intervals, you can enter the maximum value (namely 2,147,483,647) in "Count".

| NEED | ТҮРЕ | TIME | DAY/ WEEK | DAY/ MONTH | DATE/ TIME | INTERVAL | COUNT |
|-----------------------------|-------|----------|--------------|---------------|---------------|----------|-------|
| Every day at 14:00:00 | Daily | 14:00:00 | | | | 0 | 1 |

• Weekly type schedule:

Every week, the first occurrence is given by the day of the week entered in the "Day of week" field and the time entered in the "Time" field.



The "Day of week" is between Monday and Sunday

The Time format is the following: HH:MM:SS (for example 09:30:00)

The "Count" value is between 1 and 2,147,483,647 included

The "Interval" value is between 0 and 2,147,483,647 included

"Count": if the schedule is to be triggered throughout the week at regular intervals, you can enter the maximum value (namely 2,147,483,647) in "Count".

| NEED | TYPE | ТІМЕ | DAY/ WEEK | DAY/ MONTH | DATE/ TIME | INTERVAL | COUNT |
|---|--------|----------|--------------|---------------|---------------|----------|-------|
| Every Tuesday at 15:00:00 | Weekly | 15:00:00 | Tuesday | | | 0 | 1 |
| Every hour between 8:00 and 18:00 every Tuesday | Weekly | 08:00:00 | Tuesday | | | 3600 | 11 |

• Monthly type schedule:

Every month, the first occurrence is given by the day of the month entered in the "Day of month" field and the time entered in the "Time" field.



The "Day of month" format is between 1 and 31 included

The Time format is the following: HH:MM:SS (for example 09:30:00)

The "Count" value is between 1 and 2,147,483,647 included

The "Interval" value is between 0 and 2,147,483,647 included

"Count": if the schedule is to be triggered throughout the month at regular intervals, you can enter the maximum value (namely 2,147,483,647) in "Count".

| NEED | ТҮРЕ | TIME | DAY/ WEEK | DAY/ MONTH | DATE/ TIME | INTERVAL | COUNT |
|--|---------|----------|--------------|---------------|---------------|----------|-------|
| Every 2nd day of the month at 00:00:00 | Monthly | 00:00:00 | | 2 | | 0 | 1 |

• Yearly type schedule:

Every year, the first occurrence is given by the date entered in the "Date & Time" field.



The "Date & Time" format is the following: YEAR-MM-DDTHH:MM:SS (for example, for a first occurrence on 11 February at 13:00: Time = 2019-02-11T13:00:00).

The "Count" value is between 1 and 2,147,483,647 included

The "Interval" value is between 0 and 2,147,483,647 included

"Count": if the schedule is to be triggered throughout the year at regular intervals, you can enter the maximum value (namely 2,147,483,647) in "Count".

| NEED | TYPE | TIME | DAY/ WEEK | DAY/ MONTH | DATE/ TIME | INTERVAL | COUNT |
|---|--------|------|--------------|---------------|-----------------------------|----------|-------|
| Every 2 hours between 8:00 and 20:00 on 31 December | Yearly | | | | 2019- 12-31 T08:00:00 | 7200 | 7 |

• Follower type schedule:

A "Follower" type schedule will be triggered after the end of every reference schedule occurrence. The "Parent" schedule cannot be of the "Follower" type.



This type is used to trigger a data upload to the remote server after the scheduled data collection is complete, for example.

Example:

You want to collect all the Modbus module data every day at midnight and upload the data immediately afterwards. You can configure a "Daily" type schedule for the data collection and another "Follower" type schedule linked to the first schedule to upload the data.

4.1.7 Modbus

The WebdynEasy LoRaWAN hub is exclusively a Modbus RTU and TCP Master.

If Modbus RTU slaves are used, the Modbus protocol must be enabled on the RS485/RS422 port (see section 4.1.3: "System")

On the local web interface "Modbus" tab, you can configure the maximum response time for the Modbus RTU and TCP protocols.

| | Settings |
|------------------|-----------|
| | RTU |
| Timeout (ms): | 2000 |
| Turnaround (ms): | 100 |
| | — тср ——— |
| Timeout (ms): | 2000 |

| PARAMETERS | DESCRIPTION |
|-----------------|--|
| RTU | |
| Timeout (ms) | Modbus RTU response waiting time in ms |
| Turnaround (ms) | RTU turnaround time in ms |
| ТСР | |
| Timeout (ms) | Modbus TCP response waiting time in ms |

A Modbus slave is defined by a label, a dataset, a Modbus address and a schedule. For a Modbus TCP Modbus slave, an IP address is needed.

| Labek | | | |
|-----------|------------|---------|--|
| Dataset: | INVALID () | <i></i> | |
| Address: | | | |
| IP: | | | |
| Schedule: | 12 | w/ | |

| PARAMETERS | DESCRIPTION |
|------------|--|
| Label | Purely descriptive name. |
| Dataset | Associated dataset identifier (Declared dataset list). |
| Address | Modbus address (from 1 to 247). |
| IP | IP Address (empty for RTU devices). |
| Schedule | Schedule identifier (Declared schedule list) . |

A dataset defines the variables available on a Modbus slave and how to retrieve them. Dataset configuration:

| | Modbus Dataset |
|--------------------------|---|
| Id: Label: Poling: | |
| | Variables |
| Name Type | Address Size Format Flags Threshold low Threshold hysteresis V INVALID () V V V |
| | Cancel Apply |

| PARAMETERS | DESCRIPTION |
|------------|--|
| ld | Unique Modbus data set identifier (integer). |
| Label | Data set name (for information). |
| Polling | Continuous Modbus slave polling. |

Variable configuration, each variable being defined by the following parameters:

| PARAMETERS | DESCRIPTION |
|------------|--|
| Name | Variable name (for information only). |
| Туре | Variable type: • Coil (0x1/0x5,0xF) • Discrete input(0x2) • Holding register (0x3/0x6,0x10) • Input register (0x4) |
| Address | Extended 16-bit register address. |
| Size | Size in bits for Discrete inputs and Coils, and in bytes for Input and Holding registers. |

| Format | Variable format: | | | | |
|----------------------|---|--|--|--|--|
| | Raw (raw data) | | | | |
| | • Boolean: 0 or 1) | | | | |
| | Integer (whole number) | | | | |
| | Float (number with a decimal point) | | | | |
| | • ASCII (text) | | | | |
| Flags | List of options to apply: (optional) | | | | |
| | • cmd_only | | | | |
| | little_endian | | | | |
| | • no_opt | | | | |
| | • signed | | | | |
| | • is_status | | | | |
| | • is_alarm | | | | |
| Threshold low | Low threshold value (optional). | | | | |
| Threshold high | High threshold value (optional). | | | | |
| Threshold hysteresis | Hysteresis applied to both thresholds (optional). | | | | |

The "Polling" variable is used to enable continuous Modbus slave polling. When disabled, the Modbus slave is only polled when the associated schedule is triggered.

The variable type defines the function code to read or write the variable. See table below:

| ТҮРЕ | DESCRIPTION | READ (multiple) | WRITE (single) | WRITE (multiple) |
|------|------------------|-----------------|----------------|------------------|
| SO | Coil | 0x01 | 0x05 | OxOF |
| S1 | Discrete input | 0x02 | - | - |
| S3 | Input register | 0x04 | - | - |
| S4 | Holding register | 0x05 | 0x06 | 0x10 |

The available formats are the following:

| FORMAT | DESCRIPTION | COIL | REGISTER |
|---------|--|------|----------|
| raw | Data represented as: binary string for "Discrete input" and "Coils" hexadecimal string for "registers" | Х | Х |
| boolean | True or False | Х | |
| integer | 8, 16 or 32 bit whole number | | х |
| float | 16 or 32 bit floating point number (IEEE 754) | | Х |
| ascii | ASCII character string | | Х |

The "Flag " field can be supplemented by one or more options. For multiple options, the options must be separated by a comma ",". Below is a list of the available options:

| PARAMETERS | DESCRIPTION |
|---------------|---|
| cmd_only | The variable will not be read by the Modbus device, but can be written. |
| little_endian | Interprets registers in little-endian. |
| no_opt | A Modbus request will be used to read this variable. |
| signed | The variable contains a signed value. |
| is_status | Indicates that the variable contains an information status. |
| is_alarm | All changes to the status variable will trigger an alarm. |

When the "is_status" option is defined, or at least one threshold is defined, the variable is considered to be a status variable. This means that if the status changes, the variable value is saved in the data file. Below is a diagram describing the status changes depending on the thresholds and hysteresis.



If the variable is a status variable and the "is_alarm" option is present, an alarm file is generated each time the status changes. The "is_alarm" option has no effect if the variable is not a status variable ("is_status" option).

When the monitoring parameters Threshold low, Threshold high or Threshold hysteresis are used, the Polling mode must be enabled to monitor the variable continuously.

4.1.8 Run Actions

The web interface "Actions" tab is used to run certain actions locally.

4.1.8.1 Remote server connection request. Request



The "Request" button has the same effect as the physical button on the front of the product.

When this button is pressed, a pop-up window appears displaying all the connection steps, in particular NTP synchronisation, the INBOX directory check, and indicates all the uploaded files.

4.1.8.2 Reboot request: Reboot

This button is used to reboot the hub.

| Reboot | |
|---|--|
| This button will restart properly the router. | |
| Reboot | |
| | |

4.1.8.3 Log download: Download logs

This button is used to download the logs for the last actions run on the hub.

| <u>[</u> | Download logs | |
|----------|----------------------------------|--|
| | Download Gateway logs: trace.log | |

4.1.8.4 Manual time set: Set time

This form is used to update the hub time if an internet connection is unavailable or if an NTP server has not been entered.

| Se | time | |
|---------------------|-------------|--------|
| Set the | outer time. | |
| 2019-10-25T06:47:23 | Update | Submit |

By clicking the "Update" button, the computer date and time are copied into the form in the correct format.

If you want to enter the date and time manually, the format must be the following: YEAR-MM-DDThh:mm:ss

Where:

- YEAR: 4 digit year.
- MM: 2 digit month in the year.
- DD: 2 digit day in the month.
- hh: 2 digit hour.
- mm: 2 digit minutes.
- ss: 2 digit seconds.

The new date is only applied after the form has been validated by pressing the "Submit" button.

4.1.8.5 System file upload: File upload

This form is used to locally upload a file on the hub.

| r ac opioad | |
|---|--|
| your update or configuration file and click | Upload" to apply it. |
| Parcourir Aucun fichier sélectionné, | Upload |
| | your update or configuration file and click " Parcourir |

Only configuration files and updates are accepted using this form.

5. Operation

5.1 The remote server

The hub communicates with a remote server using the FTP protocol. This server is used to manage the hub remotely.

The remote server has several roles:

- Report data and alarms collected locally by the hub: each time a connection is made to the server, whether by manual request, the triggering of an alarm or the triggering of the Connection Schedule, the hub takes advantage of the connection to the server to upload its stored data.
- Save a copy of the configuration: a backup of the hub configuration is available in the server "CONFIG/" directory. Each time the hub configuration is changed (locally or remotely), the hub sends a copy of its configuration to this directory.
- Reconfigure the hub or trigger actions on it: the configuration or command files must be uploaded to the server in an INBOX directory associated with the hub.
- Monitor the hub and assist in diagnosis: the hub can upload hub status files and logs for diagnostic purposes.

5.1.1 The FTP Server

5.1.1.1Configuration

The FTP server is defined by the following parameters:

- An address: This can be an IP address or a domain name. If a domain name is used with an Ethernet connection, a DNS server must be configured in the hub so that the domain name can be translated to an IP address.
- The FTP connection port (default 21) can be changed by adding the port to be used after the ':' character to the end of the address. The format to be used is as follows: "address:port" (e.g. "192.168.1.2:8021").
- A login and a password: The parameters are used to define the FTP account to be used.
- A root directory: The root directory can be the FTP server root " / " or a series of subdirectories (for example "WebdynEasy_LoRaWAN/00C8B5/").

Below the root directory, the FTP server must have the following directories:

| NAME | RIGHTS | DESCRIPTION |
|---------------------|------------|--|
| CONFIG/ | Write | Contains the configuration image. The configuration is saved in a file called: " <uid>.xml"</uid> |
| DATA/ | Write | Contains collected data. The name of the data file respects the following format: " <uid>-<timestamp>.xml.gz" or "<uid>-<timestamp>.json.gz"</timestamp></uid></timestamp></uid> |
| ALARM/ | Write | Contains the alarms. The alarm file name is in the following format: " <uid>-<timestamp>.xml.gz"</timestamp></uid> |
| SUPERVISION/ | Write | Contains the status files and the logs. The file names are in the following format: " <uid>-<timestamp>.json.gz"</timestamp></uid> |
| INBOX/ <uid>/</uid> | Read/Write | Mailbox to send a configuration or a command to the hub. |
| BIN/ | Read | Contains the update files. |

Where:

- <uid>: Hub identifier
- <timestamp>: The timestamp format is "YEARMMDD-HHMMSS" so that an alphabetical sort of the directory gives the chronological order

The data, alarm and supervision files are compressed in Gzip ".gz" format.

The minimum access rights to the different directories must be defined as specified in the table above.

The hub will not create the directories if they are missing. If the directories are missing, or if the rights are insufficient, please contact the server administrator.

5.1.1.20peration

The hub always uploads files to the FTP server using a 2-step process:

- At the start of the transfer the file has an additional ".tmp" extension.
- When the file transfer is complete, it is renamed by removing the ".tmp" extension.

This process allows the remote server to easily differentiate between files being uploaded and files that are completely uploaded.

The files exchanged with the remote server comply with the formats described in the schema files (XSD files). Each firmware version is delivered with its associated schema files and is available on our web site (see section 7: "Support")

The XML schemas specifying the different XML file formats used by the hub may change in future versions when new functions are added. These changes will be made in such a way that the previous XML files remain compatible with the new XML schemas. Similarly, as the XML files generated by the hub may contain additional elements, their processing must be implemented so that the new elements are ignored.

5.1.1.3 File Format

The data, alarm, command and configuration files exchanged with the server are in XML format.

5.1.2 Web Service

5.1.2.1Settings

The Web Service is defined by the following parameters:

- A URL: the URL can be an IP address or the name of the remote web server. When using a domain name with an Ethernet connection, a DNS server must be configured in the concentrator to allow resolution of the domain name into an IP address.
- It is possible to modify the port of the web server (by default 80) by adding at the end of the URL, the port to use after the ':' character. The format to use is: "url:port" (for example: "192.168.1.2:5000").
- An identifier and a password: these parameters are used to define the Web Service account to be used.
- A path: the path on the web server.

| NAME | RIGHTS | DESCRIPTION |
|---------|--------|--|
| CONFIG/ | Write | Contains the configuration image. The configuration is saved in a file called: " <uid>.xml"</uid> |
| DATA/ | Write | Contains collected data. The name of the data file respects the following format: " <uid>-<timestamp>.xml.gz" or "<uid>-<timestamp>.json.gz"</timestamp></uid></timestamp></uid> |
| ALARM/ | Write | Contains the alarms. The alarm file name is in the following format: " <uid>-<timestamp>.xml.gz"</timestamp></uid> |

The web server must contain the following subpaths:

| SUPERVISION/ | Write | Contains the status files and the logs. The file names are in the following format: " <uid>-<timestamp>.json.gz"</timestamp></uid> |
|---------------------|------------|--|
| INBOX/ <uid>/</uid> | Read/Write | Mailbox to send a configuration or a command to the hub. |
| BIN/ | Read | Contains the update files. |

With:

- <uid>: Concentrator ID
- <timestamp>: The timestamp format is "YYYYMMDD-HHMMSS" so an alphabetical sorting of the directory gives the chronological order

Data, alarm and supervision files are compressed in Gzip ".gz" format.

The minimum access rights to the different access paths must be defined as specified in the table above.

5.1.2.2 Functioning

The hub uploads the files to the web server using an HTTP POST request in the following format:

- CONFIG : http://<ws_address>/<ws_upolad_path>/config
- DATA : http://<ws_address>/<ws_upolad_path>/data
- ALARM : http://<ws_address>/<ws_upolad_path>/alarm
- SUPERVISION : http://<ws_address>/<ws_upolad_path>/supervision
- INBOX : http://<ws_address>/<ws_upolad_path>/inbox ?uid=<uid>

The hub retrieves files from the web server using an HTTP GET request in the following format:

- INBOX : http://<ws_address>/<ws_upload_path>/inbox/<update_file>?uid=<uid>
- BIN: http://<ws_address>/<ws_upload_path>/bin/<update_file>?uid=<uid>

The files exchanged with the remote server comply with the formats described by the schema files (XSD files). Each firmware version is delivered with its associated schematic files and available on our website (see chapter 7: "Support").

The XML schemas specifying the format of the various XML files used by the hub may change in future releases when new features are added. These changes will be made so that the old XML files remain compatible with the new XML schemas. Also, since the XML files generated by the hub may contain additional elements, their processing must be implemented so that the new elements are ignored.

5.1.2.3 File format

The alarm, command and configuration files exchanged with the server are in XML format. The data files are either in XML format or in JSON format.

5.1.3 MQTT

5.1.3.1 Settings

• The MQTT Server is defined by the following parameters:

• An address: This address can be an IP address or the name of the remote web server. When using a domain name with an Ethernet connection, a DNS server must be configured in the concentrator to allow resolution of the domain name into an IP address.

• It is possible to modify the port of the MQTT server (by default 1883) by adding at the end of the address, the port to use after the ':' character. The format to use is: url:port (for example: "192.168.1.2:5000").

• An identifier and a password: These parameters are used to define the MQTT server account to use.

• The topic: The topic of the MQTT messages to use

With :

<uid>: Concentrator ID

5.1.3.2 Operation

The hub sends the data to the MQTT server in the format specified in the upload section. There is no configuration management in MQTT. There is no command in MQTT.

5.1.3.3 Data Format

Alarms, data and supervision are either in XML format or in JSON format.

Regarding the XML format:



The data exchanged with the remote server respects the formats described by the schema files (XSD files). Each firmware version is delivered with its associated schematic files and available on our website (see chapter 7: "Support")



The XML schemas specifying the format of the various XML files used by the hub may change in future versions when new features are added. The XML files generated by the concentrator may contain additional elements, their processing must be implemented so that the new elements are ignored.

5.2 The Configuration

The hub allows remote configurations using a configuration file or text messages

Configuration file:

The WebdynEasy LoRaWAN hub configuration file is in XML format. Please refer to the configuration XSD file for your firmware version to get the details of the configuration file formats.

The appendix to this manual (Appendix A - Variable list) contains the list of variables and their meaning.

A backup of the current configuration is available on the remote server in the "/CONFIG" directory. Whether after a local or remote modification of the configuration, the hub sends its new configuration to the remote server.

A configuration file can be sent locally via the web interface, or remotely via the FTP "INBOX" directory.

• Locally: on the Actions" tab, select the required configuration file using the "File Upload" form, then validate the selection by clicking the "Upload" button. The file will be sent to the hub and applied.

| File upload | |
|--|----------------------|
| Select your update or configuration file and click " | Upload" to apply it. |
| Parcourir Aucun fichier sélectionné, | Upload |
| | (return) |

- Remotely: upload the configuration file to the FTP "INBOX" directory on your hub ("INBOX/<uid>/", where <uid> is your hub identifier). On the next connection to the FTP server, the hub will carry out 3 steps:
 - Download the configuration file available on the server.
 - Delete the server configuration file.
 - Apply the new configuration.

| Site distant : | /webdynRF | LoRaWAN/IN | BOX/00C8B5 | | | |
|----------------|------------|--------------|-----------------|----------------------|--------------------|--------------|
| 8- W | bdynRF_LoR | WAN | | | | |
| | ALARM | | | | | |
| | BIN | | | | | |
| | CONFIG | | | | | |
| | DATA | | | | | |
| | INBOX | | | | | |
| | 00C884 | | | | | |
| | 00C885 | | | | | |
| | 00C902 | | | | | |
| | SUPERVISIO | N1 | | | | |
| Nom de fichi | er | Taille de fi | Type de fichier | Demière modification | Droits d'accès | Propriétaire |
| Y casta um | | 5 625 | Eichier VAR | 24/10/2019 13:43:00 | - PAGE AND ADDRESS | 1022 1005 |

A pre-defined name for the configuration file is not needed.

If there is an error in the configuration file (corrupt file, incorrect value, ...), the file will not be applied and an alarm will be generated on the server. Check the coherence of your configuration file with the XSD file for your firmware version before sending it to your hub. There is no need to send the entire configuration back to your hub. A configuration file can be complete or partial. A configuration file containing only one variable can therefore be sent.

By default, the configuration sent to the hub overwrites the current configuration. Only the variables in the configuration file will be overwritten. However, the default values can be applied to all the variables before the new values are applied. To do that, in the main "config" tag, add the "factory=true" attribute:

A

Refer to "Appendix A – Variable list" to see the list of variables and their possible values.

5.3 The Data

The data is uploaded to the "DATA/" directory of the remote server, in the form of files either in XML format or in JSON format, and compressed in Gzip ".gz" format.

Below is the format of the data file names: <uid>-<timestamp>.xml.gz or <uid>-<timestamp>.json.gz.

With :

- <uid>: Concentrator ID
- <timestamp>: The format of the timestamp is "YYYYMMDD-HHMMSS" so that an alphabetical sorting of the directory gives the chronological order

Example :

00C8B4-20191029-112704.xml.gz or 00C8B4-20191029-112704.json.gz

The format of the data files is described by the data XSD file. XSD files can evolve according to firmware

versions. They are delivered with each update.

The frequency of sending files to the remote server can be defined by a Schedule. (see chapter 4.1.6: "Schedules" and chapter 4.1.1.6: "Upload").

However, during a connection to the server, following a manual request or the triggering of an alarm, the concentrator takes advantage of the connection to deposit the data in memory.

5.4 Alarms

The alarms are uploaded in XML format files compressed to Gzip ".gz" format. They are uploaded to the "ALARM/" directory of the remote server.

The alarm file name format is identical to the data file format. Below is the Alarm file name format: <uid>-<timestamp>.xml.gz

Where:

- <uid>: Hub identifier
- <timestamp>: The timestamp format is "YEARMMDD-HHMMSS" so that an alphabetical sort of the directory gives the chronological order

Example: 00C8B4-20191029-090507.xml.gz

The alarm file format is described by the alarm XSD file. XSD files may change depending on firmware versions. They are shipped with every update.

Alarms can be configured to be uploaded immediately they are triggered (On), at the next connection (Delayed) or disabled (Off). (see section 4.1.5: "Alarms")

5.5 Commands

Actions can be run on the hub remotely. To do this, the hub must be send a command. This command can be sent using an XML format command file, or by text message.

• XML command file: the command file must be uploaded to the remote server "INBOX" directory for the hub ("INBOX/<uid>/", where <uid> is the hub identifier). In the same way as the configuration files. All the files in this directory will be downloaded before being deleted and run.

The command file format is described by the command XSD file. XSD files may change depending on firmware versions. They are shipped with every update.

• Test message: the text message format must be the following:

```
cmd=command
param1=value1
param2=value2
...
parami=valuei
```

or

cmd=command;param1=value1;param2=value;...;parami=valuei

Where:

- command: the command to be sent
- param1, param2, ..., parami: command parameters
- value1, value2, ..., valuei: parameter values



- command: command to send
- param1, param2, ..., parami: command parameters
- value1, value2, ..., valuei: parameter values

All commands accept two optional parameters "uid" and "cid":

- uid: unique hub identifier
- cid: command identifier

Commands will be rejected if the included uid parameter does not match the hub uid.

The cid can be freely chosen by the command issuer. It will be included with any associated download. Below is a list of the commands available on the hub:

| COMMAND | SUBCOMMAND | DESCRIPTION | RETURN |
|---------|------------|----------------------------|--------|
| reboot | | Restarting the product | Any |
| factory | | Return to factory settings | Any |
| update | | Hub software update | Alarm |

| connect | | Immediate connection to the remote server | Login |
|---------|--------|---|----------------|
| status | | Hub Status Recovery | Monitoring+SMS |
| log | | Logbook recovery | supervision |
| settime | | Concentrator time setting | Alarm |
| modbus | write | Writing to a modbus slave | Alarm |
| lorawan | send | Downlink LoRaWAN frame sending | Alarm |
| lorawan | add | Adding a sensor | Alarm |
| lorawan | delete | Deleting a sensor | Alarm |

List If several commands are sent at the same time, the "reboot", "factory" and "update" commands can result in the commands following them being lost.

5.5.1 "Reboot" Command

The "reboot" command is used to trigger an immediate product reboot. There is no return/ acknowledgement after this command is sent.

No subcommands or parameters are required for this command.

Example:

• By XML file:

• By text message:

cmd=reboot uid=00C8B4

5.5.2 "Factory" Command

The "factory" command is used to restore the hub factory settings. There is no return/acknowledgement after this command is sent.

No subcommands or parameters are required for this command.

Example:

• By XML file:

• By text message:

cmd=factory

5.5.3 "Update" Command

(see section 6.2: "Update Remote")

5.5.4 6"Connect" Command

The "connect" command is used to trigger an immediate product connection to the remote server. There is no return/acknowledgement after this command is sent.

No subcommands or parameters are required for this command.

Example:

By text message:

cmd=connect

5.5.5 "Status" Command

The "status" command is used to retrieve product status information. When the request is made using a file, a status file is uploaded to the remote server "SUPERVISION/" directory. When the request is made by text message, the answer is sent to the command issuer by text message.

No subcommands or parameters are required for this command.

Example:

• By XML file:

• By text message:

cmd=status cid=status cmd 1

5.5.6 "Log" Command

The "log" command is used to retrieve the hub log. The log is uploaded to the remote server "SUPERVISION/" directory.

No subcommands or parameters are required for this command.

Example:

• By XML file:

By text message:

cmd=log

5.5.7 "Settime" Command

The "settime" command allows you to update the date and time of the concentrator with the desired time.

To do this, in the "time" attribute, you must indicate the desired date and time in the following format: YYYY-MM-DDThh:mm:ss

With :

- YYYY: 4-digit year
- MM: Month in the year on 2 digits
- DD: Day in the month on 2 digits
- hh: Hour on 2 digits
- mm: Minutes in 2 digits
- ss: 2-digit seconds

Link If an NTP server is configured, the concentrator date and time will automatically update when connecting to the remote server.

Example:

• By XML file:

• By text message:

```
cmd=settime
time=2021-05-23T16:03:23
```

5.5.8 "Modbus" Command

The "modbus" command is used to write values to the Modbus slave registers configured on the hub.

To do that, the "write" sub-command, the data to be written in the "data" attribute, the list of slaves and registers in which the value must be written must be indicated.

The command is saved in the supervision actions and sent to the remote server "SUPERVISION/" directory.

The slave addresses must be in the following format:

• Modbus RTU:

```
<modbus address>/<register type>@<register address>
```

Example: 45/S3@0x0056

• Modbus TCP:

```
<device_ip>:<modbus_address>/<register_type>@<register_
address>
```

Example: 192.168.0.17:223/S3@0x0F52

Example:

• By XML file:

By text message:

cmd=modbus subcmd=write data=0xFF address=45/S4@0x0056 address=192.168.0.17:223/S3@0x0F52

5.5.9 "Lorawan" Command

The "lorawan" command is used to send commands to the concentrator. There are several sub-commands which are:

- "send": sends "downlink" frames to the sensor.
- "add": allows you to add a sensor to the concentrator.
- "delete": allows you to delete a sensor in the concentrator.

Following the command, an alarm is generated and placed in the "ALARM/" directory specifying the result of the command.

5.5.9.1 "Send" subcommand

The "send" sub-command sends "downlink" frames to the sensor.

For this, it is necessary to fill in the following attributes:

- "devaddr": the DEVADDR of the sensor which identifies the sensor (in hexadecimal format).
- "Deveui": the DEVEUI of the sensor which identifies the sensor (in hexadecimal format).
- "fport": the port number of the sensor to use sensor (in decimal format).
- "data": the data to be sent in hexadecimal format.

In class A, the concentrator sends "downlink" frames just after an "uplink" frame from the sensor. The concentrator prepares the message and stores it for a maximum of 48 hours. Pass this time, an alarm will be sent to notify that the time is exceeded. An alarm is also sent to signal the sending of the frame to the sensor.

Example :

By XML file:

```
<commands>
<cmd cid="cmd1">
<lorawan subcmd="send">
<devaddr>01020304</devaddr>
<fport>1</fport>
<data>0AF0C4</data>
</lorawan>
</cmd>
</commands>
```

• By text message:

cmd=lorwan
subcmd=send
devaddr=01020304
fport=1
data=0AF0C4

Example of alarms in case of success:

```
<alarms>
<command>
<date>2021-01-25T15:00:00</date>
<cid>change_send_period_to_10min</cid>
<source>ws</source>
<error>none</error>
<description>commande queued</description>
</command>
<date>2021-01-25T15:05:00</date>
<cid>change_send_period_to_10min</cid>
<source>ws</source>
<error>none</error>
<description>commande sent</description>
</command>
</alarms>
```

Example of an alarm in the event of times exceeded:

5.5.9.2 "Add" subcommand

The "add" subcommand adds a sensor to the concentrator.

For this, it is necessary to fill in the following attributes:

- "Deveui": the DEVEUI of the sensor which identifies the sensor (in hexadecimal format).
- "appskey": the APPSKEY of the sensor if the sensor is in ABP mode (in hexadecimal format).
- "nwkskey": the NWKSKEY of the sensor if the sensor is in ABP mode (in hexadecimal format).
- "appkey": the APPKEY of the sensor if the sensor is in OTAA mode (in hexadecimal format).

Example of adding a sensor in OTAA mode:

• By XML file:

• By text message:

```
cmd=lorawan
subcmd=add
deveui=E498ED000000000
appkey=000102030405060708090A0B0C0D0E0F
```

Example of adding a sensor in ABP mode:

• By XML file:

```
<commands
<cmd cid="change_send_period_to_10min">
<lorawan subcmd="send">
<devaddr>00000F6A</devaddr>
<appskey>000102030405060708090A0B0C0D0E0F<
appskey>
<nwkskey>000102030405060708090A0B0C0D0E0F</
nwkskey>
</lorawan>
</cmd>
```

• By text message:

```
cmd=lorawan
subcmd=add
devaddr=00000F6A
appskey=000102030405060708090A0B0C0D0E0F
nwkskey=000102030405060708090A0B0C0D0E0F
```

5.5.9.3 "Delete" subcommand

The "delete" subcommand allows you to delete a sensor from the concentrator.

For this, it is necessary to fill in the following attributes:

- "devaddr": the DEVADDR of the sensor which identifies the sensor (in hexadecimal format).
- "Deveui": the DEVEUI of the sensor which identifies the sensor (in hexadecimal format).

Example:

• By XML file:
• By text message:

cmd=lorawan
subcmd=delete
deveui=E498ED000000000

6. Update

The WebdynEasy LoRaWAN hub can be updated locally or remotely. The latest firmware version ("GatewayLoRaWAN_x.x.x.cwe") is available for download from our web site at the following address: https://www.webdyn.com/support/lorawan/

6.1 Local

To update the hub locally, use its web interface and go to the "Actions" tab and then follow the "File Upload" system file upload procedure (see section 4.1.8.5: "System file upload: File upload").

6.2 Remote

For a remote update, the file containing the update must be uploaded to the "BIN" directory on the remote server, and an "update" command must be sent to the hub.

The update command can be sent either in a command file or by text message. The command must include the name of the file containing the update ("firmware" field) and its associated MD5 code ("checksum" field).

It is strongly recommended to use a command file (XML).

Example:

• By XML file:

```
<commands

xmlns="http://www.webdyn.com/GWL_command_20190719"

xmlns:xsi="http://www.w3.org/2001/XMLSchema-instance"

xsi:schemaLocation="http://www.webdyn.com/GWL_

command_20190719 command.xsd">

<cmd>

<cmd>

<update>

<firmware>GatewayLoRaWAN_1.3.0.cwe</firmware>

<checksum>clfb7d81f3d53a8b7bf94098115249d3</checksum>

</update>

</cmd>

</commands>
```

• By text message:

```
cmd=update
firmware=GatewayLoRaWAN_1.3.0.cwe
checksum=c1fb7d81f3d53a8b7bf94098115249d3
```

7. Appendix: XML configuration file variables



All the "names +tree structures" highlighted in blue are lists and can be created multiple times.

| NAME+TREE STRUCTURE | DESCRIPTION | ТҮРЕ | DEFAULT VALUE | NOT USED (future use) |
|--------------------------|---|--|--|--------------------------|
| /uid | Hub identifier | Hexadecimal 3 bytes | 3 last bytes of the MAC address | |
| /name | Optional product name | Text | "WG_"+ 3 last bytes of the MAC address | |
| /enable_local_config | Enables/Disables access to the local configuration | Boolean (true, false) | false | |
| /com/modem/pin/mode | Enable/Disable the PIN | List: • Off • manual | off | |
| /com/modem/pin/code | PIN code | Whole number from 4 to 6 digits | | |
| /com/modem/apn | APN | Text | | |
| /com/modem/login | APN login | Text | | |
| /com/modem/password | APN password | Text | | |
| /com/modem/mode | Modem connection mode | List: • ondemand • alwaysOn • alwaysOff | alwaysOff | |
| /com/modem/delay | Time before disconnection in seconds | Integer (min 0 max 65535) | 60 | |
| /com/ethernet/use_dhcp | Enable/Disable the DHCP client | Boolean (false, true) | false | |
| /com/ethernet/ip | IP address | IP format: "xxx. xxx.xxx.xxx" | 192.168.1.12 | |
| /com/ethernet/netmask | Subnet mask | IP format: "xxx. xxx.xxx.xxx" | 255.255.255.0 | |
| /com/ethernet/gateway | Local network gateway | IP format: "xxx. xxx.xxx.xxx" | | |
| /com/ethernet/dns/server | List of DNS servers | IP format: "xxx. xxx.xxx.xxx" | | |
| /com/ftp/address | FTP server address + port (optional). If the port is not entered, by default FTP will use 21 | IP format: "xxx. xxx.xxx.xx" or domain name: "xxxxxxxxx.xxx" + port (optional): ":xxxx" | | |
| /com/ftp/login | FTP account login | Text | | |
| /com/ftp/password | FTP account password | Text | | |
| /com/ftp/mode | FTP passive or active connection mode | List: • passive • active | passive | |

| /com/ftp/secured | Enable/Disable secure mode (FTPS) | Boolean (true, false) | false |
|--------------------------|--|--|-------------|
| /com/ftp/trust_model | Secure mode operating mode | List: | verify_peer |
| /com/ftp/root_path | FTP server root directory | Text | |
| /com/ftp/ws_notification | Enable/Disable sending notifications | List: • none • put • get • both | none |
| /com/ws/address | Web Services server address | | |
| /com/ws/login | Web Services server login | | |
| /com/ws/password | Web Services server password | | |
| /com/ws/webservice_proxy | Proxy server address (optional) | | |
| /com/ws/trust_model | Secure mode operating mode: • Trust peer Verify peer | | |
| /com/ws/upload_path | Web Services root directory | | |
| /com/mqtt/address | MQTT server address + port (optional) | IP format: "xxx. xxx.xxx.xxx" | |
| | If the port is empty, by default the MQTT will use the 1883 | Or Domain name: "xxxxxxxxx" + port (optional): ":xxxx" | |
| /com/mqtt/client_id | Client identifier in the MQTT Text protocol | Text | |
| /com/mqtt/login | MQTT Account ID | Text | |
| /com/mqtt/password | MQTT account password | Text | |
| /com/mqtt/keepalive | Time in seconds to send keepalive frame | Integer (min 0, max 65535) | 60 |
| /com/mqtt/topic | MQTT message topic starts with this chain | | |
| /com/mqtt/trust_model | Safe Mode Operation Mode | List: • verify peer • trust peer | verify peer |
| /com/mqtt/ca | CA Root Certificate | PEM File Format | |
| /com/mqtt/cert | Local Client Signed Certificate | PEM File Format | |
| /com/mqtt/key | Local client private key | PEM File Format | |

| /com/keepalive/file | File type to send | List: • "log" • "supervision" • empty: keepalive au format "[UID]- [TIME %Y%m%d- %H%M%S]- keepalive" | • |
|-----------------------------------|---|--|-------|
| /com/keepalive/ Schedule | Schedule login to send regular keepalive | | • |
| /com/request/upload | Enable/Disable server connection after pressing the "REQUEST" button | | • |
| /com/request/include_status | Send a supervision file to the server after pressing the "REQUEST" button | | • |
| /com/request/sms_status_recipient | Phone number for the status text message recipient after the "REQUEST" button is pressed. International format phone number | | • |
| /com/time/ntp/server | List of NTP server addresses | IP format: "xxx. xxx.xxx.xxx" or domain name: "xxxxxxxxxx.xxx" | |
| /com/time/timezone | Timezone in tz format | List: (see http:// en.wikipedia.org/ wiki/Zone.tab) | • |
| /com/time/alarm_threshold | Alarm trigger threshold in seconds | Integer (min 0 max 65535) | 0 |
| /com/time/min_sync_interval | Minimum time between 2 NTP synchronisations (in seconds) | Whole number (min 0 max 4,294,967,295) | 86400 |
| /com/vpn/openvpn/enable | Enables the client OpenVPN | List: •true •false | false |
| /com/vpn/openvpn/protocol | VPN IP protocol | List: •tcp •udp | |
| /com/vpn/openvpn/server/address | IP address or name of the VPN server | IP format: "xxx. xxx.xxx.xxx" or domain name: "xxxxxxxxxx.xxx" | |
| /com/vpn/openvpn/server/port | VPN sever port (normally 1194) | Integer (min 1 max 65535) | |
| /com/vpn/openvpn/server/cipher | Data packet encryption algorithm (optional) | List: (see list in OpenVPN "openvpn –show- ciphers") | |
| /com/vpn/openvpn/server/auth | VPN authentication | List: (see the list in OpenVPN "openvpn –show- digests") | SHA1 |
| /com/vpn/openvpn/server/ca | CA certificate | PEM file format | |
| /com/vpn/openvpn/server/cert | Client certificate | PEM file format | |

| /com/vpn/openvpn/server/key | Client private key | PEM file format | | |
|---|---|--|-------|----|
| /com/vpn/openvpn/server/tls_auth (obsolete) | Static key used for the HMAC hashing algorithm on control packets (Obsolete, see Key variable below) | PEM file format | | |
| /com/vpn/openvpn/server/control_channel_ security/method | List of methods for control channel security | List: • none • tls-auth • tls-crypt • tls-crypt-v2 | none | |
| /com/vpn/openvpn/server/control_channel_ security/key | Key for control channel security | PEM file format | | |
| /com/firwall | Firewall | | | • |
| /com/mdns/enable | Activation of the mDNS protocol intended to resolve the name of the hub "UID" into an IP address. | List: •true •false | true | |
| /upload/config/method | Configuration file management communication protocol | List: • none • ftp • ws | ftp | WS |
| /upload/config/omit_password | Hide the "password" tags in the XML file | Boolean (true, false) | false | |
| /upload/supervision/method | Communication protocol to send supervision files | List: • MQTT • none • ftp • ws | ftp | WS |
| /upload/alarm/method | Communication protocol to send alarm files | List: • MQTT • none • ftp • ws | ftp | |
| /upload/data/method | Data file management communication protocol | List: • MQTT • none • ftp • ws | ftp | |
| /upload/data/format | Data file format for data | List: •xml •json | xml | |
| /upload/data/schedule | Schedule identifier for sending data | Integer (min 1 max 65535) | | |
| /upload/commun/size_limit | Maximum non compressed data file size in Mb in XML format. For JSON format the unit is kilobytes | Integer (min 0 max 30) for XML and 30000 for JSON | 10 | |
| /alarm/sources/modem_ip | Modem IP address change alarm configuration | List: • on • off • delayed | off | |

| /alarm/sources/msisdn | SIM card change alarm configuration • on: enabled and immediate send • off: disabled delayed: enabled and send at next connection | List: • on • off • delayed | off |
|---|--|---|-------|
| /alarm/sources/sw_version | Software update alarm configuration (firmware or core) • on: enabled and immediate send • off: disabled delayed: enabled and send at next connection | List: •on •off •delayed | on |
| /alarm/sources/defaults/ignored | List of fault to ignore: • D_MODEM • D_MODEM_SIM_MISS • D_MODEM_SIM_CODE_FAIL • D_MODEM_PUK • D_MODEM_REG_DENIED | Text (fault list separated by a comma ",") | |
| /alarm/sources/defaults/delayed | List of faults that cannot be sent immediately but only at the next connection: • D_MODEM • D_MODEM_SIM_MISS • D_MODEM_SIM_CODE_FAIL • D_MODEM_PUK • D_MODEM_REG_DENIED | Text (fault list separated by a comma ",") | |
| /scheduler/schedules/schedule/ | Schedule list | | |
| /scheduler/schedules/schedule/id | Schedule identifier | Whole number (min 1 max | |
| | | 2,147,483,647) | |
| /scheduler/schedules/schedule/label | Schedule name | 2,147,483,647) Text | |
| /scheduler/schedules/schedule/label /scheduler/schedules/schedule/type | Schedule name Schedule type | 2,147,483,647) Text List: • Daily • Weekly • Monthly • Yearly • Follower | Daily |
| /scheduler/schedules/schedule/label /scheduler/schedules/schedule/type /scheduler/schedules/schedule/parent | Schedule name Schedule type Parent schedule identifier for a "follower" type schedule | 2,147,483,647) Text List: • Daily • Weekly • Monthly • Yearly • Follower Integer (min 1 max 65535) | Daily |
| <pre>/scheduler/schedules/schedule/label /scheduler/schedules/schedule/type /scheduler/schedules/schedule/parent /scheduler/schedules/schedule/start/time</pre> | Schedule name Schedule type Schedule type Parent schedule identifier for a "follower" type schedule Trigger time for the first schedule iteration for a "daily", "weekly" or "monthly" type schedule | 2,147,483,647) Text List: • Daily • Weekly • Monthly • Yearly • Follower Integer (min 1 max 65535) Time format: "hh:mm:ss" | Daily |
| <pre>/scheduler/schedules/schedule/label /scheduler/schedules/schedule/type /scheduler/schedules/schedule/parent /scheduler/schedules/schedule/start/time /scheduler/schedules/schedule/start/datetime</pre> | Schedule name Schedule type Schedule type Parent schedule identifier for a "follower" type schedule Trigger time for the first schedule iteration for a "daily", "weekly" or "monthly" type schedule Trigger date and time for the first schedule iteration for a "yearly" type schedule | 2,147,483,647) Text List: Daily Weekly Monthly Yearly Follower Integer (min 1 max 65535) Time format: "hh:mm:ss" Date and time format: "year-mm- ddThh:mm:ss" | Daily |
| <pre>/scheduler/schedules/schedule/label /scheduler/schedules/schedule/type /scheduler/schedules/schedule/parent /scheduler/schedules/schedule/start/time /scheduler/schedules/schedule/start/datetime /scheduler/schedules/schedule/start/datetime</pre> | Schedule name Schedule type Schedule type Parent schedule identifier for a "follower" type schedule Trigger time for the first schedule iteration for a "daily", "weekly" or "monthly" type schedule Trigger date and time for the first schedule iteration for a "yearly" type schedule Trigger date and time for the first schedule iteration for a "yearly" type schedule Trigger date iteration for a "yearly" type schedule Trigger day in the week for the first schedule iteration for a "weekly" type schedule | 2,147,483,647) Text List: Daily Weekly Monthly Yearly Follower Integer (min 1 max 65535) Time format: "hh:mm:ss" Date and time format: "year-mm- dThh:mm:ss" List: Monday Tuesday Wednesday Friday Saturday Sunday | Daily |

| /scheduler/schedules/schedule/interval | Interval between occurrences (in seconds) | Integer (min 0 max 4,294,967,295) | |
|--|--|---|------|
| /scheduler/schedules/schedule/count | Number of occurrences | Integer (min 1 max 65535) | |
| /modbus/tcp/timeout | Max. time without response from Modbus/TCP slaves (in ms) | Integer (min 0 max 65535) | 2000 |
| /modbus/rtu/timeout | Max. time without response from Modbus RTU slaves (in ms) | Integer (min 0 max 65535) | 2000 |
| /modbus/rtu/turnaround | Modbus RTU turnaround time (in ms) | Integer (min 0 max 65535) | 100 |
| /modbus/datasets/dataset/ | List of Modbus datasets | Integer (min 1 max 65535) | |
| /modbus/datasets/dataset/id | Dataset identifier | Integer (min 1 max 65535) | |
| /modbus/datasets/dataset/label | Dataset name | Text | |
| /modbus/datasets/dataset/vars/var/ | List of Dataset variables | | |
| /modbus/datasets/dataset/vars/var/name | Variable name | Text | |
| /modbus/datasets/dataset/vars/var/type | Variable type | List: | |
| | | •S0: Coil (0X1/0X5,0XF) | |
| | | •S1: Discrete input (OX) | |
| | | •S3: Input register (0x3/0x6,0x10) | |
| | | •S4: Holding register (0x4) | |
| /modbus/datasets/dataset/vars/var/address | 1st variable register address | Hexadecimal 2 bytes | |
| /modbus/datasets/dataset/vars/var/size | Variable size | Unsigned integer | |
| /modbus/datasets/dataset/vars/var/format | Variable format | List: • raw • boolean • integer • float • ascii | |
| /modbus/datasets/dataset/vars/var/flags | Variable options (optional) | List: • cmd_only • little_endian • no_opt • signed • is_status • is_alarm | |
| /modbus/datasets/dataset/vars/var/threshold/ low | Low threshold (optional) | Number (double) | |
| /modbus/datasets/dataset/vars/var/threshold/ high | High threshold (optional) | Number (double) | |
| /modbus/datasets/dataset/vars/var/threshold/ hysteresis | Hysteresis (optional) | Number (double) | |

| /modbus/datasets/dataset/boundaries | | | • |
|-------------------------------------|---|---|--------|
| /modbus/datasets/dataset/polling | Enable continuous polling | Boolean (true, false) | false |
| /modbus/modules/module/ | List of Modbus modules | | |
| /modbus/modules/module/label | Modbus slave name | Text | |
| /modbus/modules/module/dataset | Identifier of the dataset to use | Integer (min 1 max 65535) | |
| /modbus/modules/module/address | Modbus slave Modbus address | Integer (min 1 max 247) | |
| /modbus/modules/module/ip | Modbus/TCP slave IP address | IP format: "xxx. xxx.xxx.xxx" or domain name: "xxxxxxxxxx.xxx" | |
| /modbus/modules/module/schedule | Modbus slave collection schedule identifier | Integer (min 1 max 65535) | |
| /system/log/level | Log trace level. Only for debug (contact support) | Level 1 (high) to 5 (low) | 5 |
| /system/password/admin | Administrator password | Text | high |
| /system/password/install | Installer password | Text | medium |
| /system/password/data | User password | Text | low |
| /system/ports/rs485/mode | RS485 port configuration | List: • Off • Modbus | Off |
| /system/ports/rs485/baudrate | RS485 port speed (in bauds) | List: •4800 •9600 •19200 •38400 •57600 •115200 | 19200 |
| /system/ports/rs485/data | RS485 port data bit number | List: •5 •6 •7 • | 8 |
| /system/ports/rs485/parity | RS485 port parity | List: • None • Odd • Even | Even |
| /system/ports/rs485/stop_bit | RS485 port stop bit number | List: •1 •2 | 1 |
| /system/upload/direct_mode | Forces the deposit of data on the remote server after receiving data from a sensor. | List: • 0: disabled • 1: enabled | 0 |
| /lorawan/region | Region name for LoRaWAN parameters | List: • EU868 • IN865 | EU868 |

| /lorawan/channels/channel | Channel 4 frequency (in Hz) | Whole number (min 863,000,000 max 870,000,0000) | 867100000 |
|--|--|--|--|
| /lorawan/channels/channel | Channel 5 frequency (in Hz) | Whole number (min 863,000,000 max 870,000,0000) | 867300000 |
| /lorawan/channels/channel | Channel 6 frequency (in Hz) | Whole number (min 863,000,000 max 870,000,0000) | 867500000 |
| /lorawan/channels/channel | Channel 7 frequency (in Hz) | Whole number (min 863,000,000 max 870,000,0000) | 867700000 |
| /lorawan/channels/channel | Channel 8 frequency (in Hz) | Whole number (min 863,000,000 max 870,000,0000) | 867900000 |
| /lorawan/packet_forwarder/server/address | LoRaWAN server address (embedded server: 127.0.0.1) | IP format: "xxx. xxx.xxx.xxx" or domain name: "xxxxxxxxx.xxx" | 127.0.0.1 |
| /lorawan/packet_forwarder/server/port_up | Packet Forwarder outgoing UDP port number | Integer (min 1 max 65535) | 1700 |
| /lorawan/packet_forwarder/server/port_down | Packet Forwarder incoming UDP port number | Integer (min 1 max 65535) | 1700 |
| /lorawan/packet_forwarder/keepalive_interval_s | Time in seconds to send a keepalive frame | Integer (min 0 max 65535) | 10 |
| /lorawan/packet_forwarder/push_timeout_ms | Maximum waiting time in milliseconds to acknowledge the frame sent to the LoRaWAN server. | Integer (min 0 max 65535) | 10 |
| /lorawan/packet_forwarder/forwarder_crc_valid | LoRaWAN packet processing with a valid CRC (do not modify, only used for testing) | Boolean (true, false) | true |
| /lorawan/packet_forwarder/forwarder_crc_error | LoRaWAN packet processing with error CRC (do not modify, only used for testing) | Boolean (true, false) | false |
| /lorawan/packet_forwarder/forwarder_crc_none | LoRaWAN packet processing without CRC (do not modify, only used for testing) | Boolean (true, false) | false |
| /lorawan/packet_forwarder/public | Type of LoRaWAN public network preamble (public: 0x34, private: 0x12) (do not modify, only used for testing) | Boolean (true, false) | true |
| /lorawan/server/netid | LoRaWAN network identifier (see LoRaWAN specification) If you enter 0, when the hub reboots, it will use its factory NetID. | Hexadecimal 3 bytes | Calculated automatically from its MAC address |
| /lorawan/server/adr/enable | Enable ADR | Boolean (true, false) | true |

| /lorawan/server/adr/margin_db | Margin in dB to calculate ADR | Integer (min 1 max 30) | 5 |
|---|---|--|-------|
| /lorawan/server/adr/uplink_count | The number of uplinks needed for ADR | Integer (min 1 max 65535) | 20 |
| /lorawan/server/udp_port | LoRaWAN server UDP port | Integer (min 1 max 65535) | 1700 |
| /lorawan/server/backup_interval | Automatic configuration backup interval with the Fcntup and Fcntdown counters. (in seconds) | Whole number (min 1 max 4,294,967,295) | 86400 |
| /lorawan/server/modules/module/ | List of LoRaWAN modules | | |
| /lorawan/server/modules/module/deveui | Unique sensor identifier (EUI64) | Hexadecimal 8 bytes | |
| /lorawan/server/modules/module/appkey | Encryption key used by the network to derive the session keys. | Hexadecimal 16 bytes | |
| /lorawan/server/modules/module/devaddr | Sensor address | Hexadecimal 4 bytes | |
| /lorawan/server/modules/module/appskey | Encryption key between the sensor and the application server | Hexadecimal 16 bytes | |
| /lorawan/server/modules/module/nwkskey | Encryption key between the sensor and the LoRaWAN server | Hexadecimal 16 bytes | |
| /lorawan/server/modules/module/fcntup | Uplink frame counter (to the server) | Whole number (min 0 max 4,294,967,295) | |
| /lorawan/server/modules/module/fcntdown | Downlink frame counter (to the sensor) | Whole number (min 0 max 4,294,967,295) | |
| /lorawan/server/modules/module/ lclass | LoRaWAN classe du capteur | a or c | а |

Offices & Support Contact

SPAIN

C/ Alejandro Sánchez 109 28019 Madrid

Phone: +34.915602737 Email: contact@webdyn.com

FRANCE

26 Rue des Gaudines 78100 Saint-Germain-en-Laye

Phone: +33.139042940 Email: contact@webdyn.com

INDIA

803-804 8th floor, Vishwadeep Building District Centre, Janakpurt, 110058 Delhi

Phone: +91.1141519011 Email: contact@webdyn.com

PORTUGAL

Av. Coronel Eduardo Galhardo 7-1°C 1170-105 Lisbon

Phone: +351.218162625 Email: comercial@lusomatrix.pt

TAIWAN

5F, No. 4, Sec. 3 Yanping N. Rd. Datong Dist. Taipei City, 103027

Phone: +886.965333367 Email: contact@webdyn.com

SUPPORT

Madrid Offices

Phone: +34.915602737 Email: iotsupport@mtxm2m.com

Saint-Germain-en-Laye Offices

Phone: +33.139042940 Email: support@webdyn.com

Delhi Offices

Phone: +91.1141519011 Email: support-india@webdyn.com

Taipei City Offices

Phone: +886.905655535 Email: iotsupport@mtxm2m.com