

MTX-3G-JAVA Family

User Manual



General Notes

Product is deemed accepted by recipient and is provided without interface to recipient's products. The documentation and/or product are provided for testing, evaluation, integration and information purposes. The documentation and/or product are provided on an "as is" basis only and may contain deficiencies or inadequacies. The documentation and/or product are provided without warranty of any kind, express or implied. To the maximum extent permitted by applicable law, Matrix Electronica S.L.U. further disclaims all warranties; including without limitation any implied warranties of merchantability, completeness, fitness for a particular purpose and non-infringement of third-party rights. The entire risk arising out of the use or performance of the product and documentation remains with recipient. This product is not intended for use in life support appliances, devices or systems where a malfunction of the product can reasonably be expected to result in personal injury. Applications incorporating the described product must be designed to be in accordance with the technical specifications provided in these guidelines. Failure to comply with any of the required procedures can result in malfunctions or serious discrepancies in results.

Furthermore, all safety instructions regarding the use of mobile technical systems, including GSM products, which also apply to cellular phones, must be followed. Matrix Electronica S.L.U. or its suppliers shall, regardless of any legal theory upon which the claim is based, not be liable for any consequential, incidental, direct, indirect, punitive or other damages whatsoever (including, without limitation, damages for loss of business profits, business interruption, loss of business information or data, or other pecuniary loss) arising out the use of or inability to use the documentation and/or product, even if Matrix Electronica S.L.U. has been advised of the possibility of such damages. The foregoing limitations of liability shall not apply in case of mandatory liability, e.g. under the Spanish Product Liability Act, in case of intent, gross negligence, injury of life, body or health, or breach of a condition which goes to the root of the contract. However, claims for damages arising from a breach of a condition, which goes to the root of the contract, shall be limited to the foreseeable damage, which is intrinsic to the contract, unless caused by intent or gross negligence or based on liability for injury of life, body or health. The above provision does not imply a change on the burden of proof to the detriment of the recipient. Subject to change without notice at any time. The interpretation of this general note shall be governed and construed according to Spanish law without reference to any other substantive law.

Important information

This technical description contains important information for the start up and use of the MTX-3G-JAVA modem.

Read it carefully before you start working with the MTX-3G-JAVA device.

The warranty will be void should damage occur due to non-compliance with these instructions for use.

We cannot accept any responsibility for consequential loss.

Service and Support

To contact customer support please use the contact details below:

Matrix Electrónica

Alejandro Sánchez, 109

28019 Madrid (SPAIN)

gsm-support@matrix.es

Information about the MTX-3G-JAVA product and its accessories is available on the following web site:

www.mtxm2m.com

Or contact your local distributor / sales agent.

Revision information

Revision	Date	Author	Changes
0.6	2014/01	JS	First preliminary release
0.9	2014/03	JS	Fixed index and RF card descriptions
1.0	2014/06	AEM	New document format and general revision
1.1	2014/10	AEM/TP	Language style revision Added MTX-3G-JAVA-GPS-BT device Added MTX-3G-JAVA-RS485-WC25 device
1.2	2014/12	AEM	Minor revision
1.3	2015/04	AEM	Fixed errata
1.4	2015/05	AEM	Minor revision
1.5	2015/10	AEM	Minor revision

Index

General Notes.....	2
Important information	2
Service and Support	2
Revision information	3
1. Introduction.....	8
1.1 Description	8
1.2 Ordering information	9
1.3 Features by model.....	10
1.4 Highlights.....	11
1.5 Product label	14
1.6 Main features and services	15
1.6.1 Key features at a glance	15
1.6.2 Operating modes.....	18
1.6.3 Power Consumption.....	19
1.6.4 RF antenna interface description	20
1.6.5 SIM Card	22
1.7 Precautions.....	22
1.8 Block diagram	23
1.8.1 Base MTX-3G-JAVA.....	23
1.8.2 RS485 models	23
1.8.3 ULP models.....	24
1.8.4 All other models	24
1.9 Hardware revisions.....	25
2. Mechanical description	26
2.1 MTX-3G-JAVA model and ULP models	26
2.1.1 Overview.....	26
2.1.2 Dimensions	27
2.2 MTX-3G-JAVA-RS485 models	29
2.2.1 Overview.....	29
2.2.2 Dimensions	30
2.3 All other models	32
2.3.1 Overview.....	32
2.3.2 Dimensions	33

3.	Electrical and environmental characteristics	35
3.1	Electrical specifications	35
3.1.1	Power supply	35
3.1.2	RS232 interface	35
3.1.3	RS485 interface	36
3.1.4	I2C interface	36
3.1.5	GPIO	37
3.1.6	Optoisolated Input/Output	37
3.1.7	Analog Input/Output	38
3.2	Operating temperatures.....	39
3.3	Storage conditions.....	40
4.	Interface description	41
4.1	Power supply connector.....	42
4.1.1	RJ11 (base MTX-3G-JAVA)	42
4.1.2	5 way plug-in terminal block (RS485 models)	43
4.1.3	RJ11 (ULP models)	44
4.1.4	RJ11 (all other models)	45
4.2	Mini USB connector	46
4.3	DB9 connector: main RS232 port	47
4.4	DB15 connector: I/O expansion port.....	49
4.4.1	Connector pinouts	49
4.4.2	RS232 interface	54
4.4.3	I2C bus	56
4.4.4	Analog-to-Digital and Digital-to-Analog converters	57
4.4.5	General Purpose and Optoisolated I/O	59
4.5	RS485 bus	62
4.6	GSM/GPRS/UMTS antenna connector	63
4.7	SIM card reader	63
4.8	3-Axis accelerometer	64
4.9	Internal Li-Po battery.....	65
4.10	Real Time Clock	68
4.10.1	ULP models.....	68
4.11	Internal Hardware Watchdog.....	69
4.12	GPS	70

4.12.1	GPS antenna connector	70
4.12.2	GPS application interface	70
4.12.3	GPS Parser (coming soon)	71
4.12.4	Power saving	71
4.13	Wireless RF modules	72
4.13.1	Bluetooth 2.1	72
4.13.2	Bluetooth Low Energy (4.0)	72
4.13.3	Coronis Wavcard 25/500mW	73
4.13.4	ISM (868/900MHz)	74
4.13.5	WiFi	74
4.13.6	ZigBee	74
4.14	Custom GPS+RF modules	74
4.15	Firmware updates	74
5.	Operation	75
5.1	Switching on the modem. New <i>"Automatic restart after shutdown"</i> feature	75
5.2	Switching off the modem	75
5.3	Ultra Low Power mode	76
5.4	Sleep mode	76
5.5	Status LEDs	77
6.	AT command interpreter	78
7.	Embedded applications	79
7.1	MTX-Tunnel software application	80
8.	Safety and product care	82
8.1	Safety instructions	82
8.2	General precautions	82
8.3	SIM card precautions	83
8.4	Antenna precautions	83
8.5	Radio Frequency (RF) exposure and SAR	84
8.6	Personal medical devices	84
9.	Modem installation	85
9.1	Where to install the modem	85
9.1.1	Environmental conditions	85
9.1.2	Signal strength	85
9.1.3	Connections of components to MTX-3G-JAVA Terminal	85

9.1.4	Network and subscription	85
9.2	How to install the modem	86
9.2.1	Power supply	86
9.2.2	Securing the modem	86
9.3	Antenna	86
9.3.1	General	86
9.3.2	Antenna type	86
9.3.3	Antenna placement	87
9.3.4	The antenna cable	87
9.3.5	Possible communications disturbances	87
10.	Conformity assessment	88
10.1	Standards of European Type Approval.....	88
10.2	PTCRB approval	89
10.3	FCC Compliant	90
10.3.1	SAR information	90
10.4	AT&T certification.....	91
11.	Declaración de conformidad (Spanish)	92
11.1	Estándares de homologación europea.....	92
11.2	Aprobación PTCRB.....	93
11.3	Conformidad FCC.....	94
11.3.1	Tasa de absorción específica (SAR)	94
11.4	Certificación AT&T.....	95
12.	Regulatory and type approval information	96
12.1	Directives and standards	96
12.2	SAR requirements specific to portable mobiles	98
12.3	SELV requirements	98
13.	RoHS Statement	99
14.	Disposal of old electrical & electronic equipment	99
15.	Abbreviations	100
16.	AT command summary	103
17.	Accessories	108
18.	Sales contact.....	109

1. Introduction

1.1 Description

The MTX-3G-JAVA modems family is an innovative and powerful all-in-one solution enabling GSM, SMS, fax and 3G (UMTS/HSPA) high speed data transmission. It has an intrinsic TCP/IP communication stack with Internet Services such as TCP, UDP, HTTP, FTP, SMTP, and POP3.

The MTX-3G-JAVA is Java J2ME programmable and has a complete set of interfaces (RS232, RS485, USB, GPIO, I2C, GPIO, optoisolated IOs, Analog-to-Digital converter) avoiding need for further hardware components, shortening time to market and reducing costs. It also has a wide range of options (depending on the model) allowing it to be used in infinite M2M applications:

- **Ultra Low Power:** 2.5µA power consumption in sleep mode. Ideal in remote-battery operated systems
- **GNSS module inside:** GPS and GLONASS receiver modules allows track & location applications. GLONASS feature must be ordered as an option
- **Hardware Watchdog** and internal **Li-Po battery**
- **RS485 port:** isolated input/output for industrial use
- **RF card:** allows for easy development of RF gateways (Wavenis, WiFi, Bluetooth, ZigBee, ISM 868/915)

Please read [Section 1.3](#) to view the specific features of each device.

The MTX-3G-JAVA family is industrially featured: the unit can be used in industrial environments due to its extended operating temperature range. It also features an automatic restart after shutdown function in case of power glitches or faulty conditions.

The MTX-3G-JAVA is a self contained modem with its own SIM card holder, USB 2.0 High Speed and RS232/485 interfaces (among others), which minimize the need for further hardware development. This device can be used as a powerful and flexible device that can be integrated in a wide range of telemetry applications that rely on the remote exchange of data, SMS or faxes via the GSM cellular network.

The Five-band functionality allows for operation in all relevant GSM frequencies across the world. Local European and America economic variants are available. When UMTS/3G network operation is not present, the MTX-3G-JAVA can operate in lower speed modes such EDGE Class 12 (max. 237kbps DL, max. 237kbps UL) or GPRS Class 12 (max. 85.6kbps DL, max. 85.6kbps).

The MTX-3G-JAVA can also be controlled via AT commands and standard interfaces such as USB 2.0 High Speed or RS232 with Linux and Windows® drivers.

The MTX-3G-JAVA family is RoHS & WEEE compliant and it is manufactured following the ISO 9001 & ISO 14001 Quality certifications.

A full list of antennas, cables and accessory supplies are available.

The MTX-3G-JAVA modems are powered by an internal Cinterion® EHS6 module

1.2 Ordering information

199801320: MTX-3G-JAVA

2xRS232, USB, I2C, 2xADC, 1xDAC, 4xGPIO

199801330: MTX-3G-JAVA-RS485

1xRS485, 1x RS232, USB, I2C, 2xADC, 4xOptoIO, Sleep mode

199801364: MTX-3G-JAVA-RS485-WC25

Coronis Wavecard 25mW, 1xRS485, 1x RS232, USB, I2C, 2xADC, 4xOptoIO, Sleep mode

199801331: MTX-3G-JAVA-BAT

Li-Po battery, 1xRS232, USB, I2C, 2xADC, 1xGPIO, 6xOptoIO, Accelerometer, Sleep mode, Hardware Watchdog

199801332: MTX-3G-JAVA-GPS

GPS, 1xRS232, USB, I2C, 2xADC, 1xGPIO, 6xOptoIO, Accelerometer, Sleep mode, Hardware Watchdog

199801342: MTX-3G-JAVA-GPS-BAT

GPS, Li-Po battery, 1xRS232, USB, I2C, 2xADC, 1xGPIO, 6xOptoIO, Accelerometer, Sleep mode, Hardware Watchdog

199801353: MTX-3G-JAVA-GPS-BT

GPS, Bluetooth 2.1, USB, I2C, 2xADC, 1xGPIO, 6xOptoIO, Accelerometer, Sleep mode, Hardware Watchdog

199801343: MTX-3G-JAVA-ULP

Ultra Low Power, 2xRS232, USB, I2C, 2xADC, 1xDAC, 5xGPIO, 4xOptoIO

199801340: MTX-3G-JAVA-ULP-GPS

GPS, Ultra Low Power, 1xRS232, USB, I2C, 2xADC, 1xDAC, 5xGPIO, 4xOptoIO

199801344: MTX-3G-JAVA-ULP-WC25

Coronis Wavecard 25mW (868MHz), Ultra Low Power, 1xRS232, USB, I2C, 2xADC, 1xDAC, 5xGPIO, 4xOptoIO

199801136: MTX-3G-JAVA-WC25

Coronis Wavecard 25mW, 1xRS232, USB, I2C, 2xADC, 1xGPIO, 6xOptoIO, Accelerometer, Sleep mode, Hardware Watchdog

199801137: MTX-3G-JAVA-WC500

Coronis Wavecard 500mW, 1xRS232, USB, I2C, 2xADC, 1xGPIO, 6xOptoIO, Accelerometer, Sleep mode, Hardware Watchdog

199801345: MTX-3G-JAVA-BT

Bluetooth 2.1, 1xRS232, USB, I2C, 2xADC, 1xGPIO, 6xOptoIO, Accelerometer, Sleep mode, Hardware Watchdog

199801346: MTX-3G-JAVA-BLE

Bluetooth Low Energy, 1xRS232, USB, I2C, 2xADC, 1xGPIO, 6xOptoIO, Accelerometer, Sleep mode, Hardware Watchdog

199801347: MTX-3G-JAVA-XBEE

XBee, 1xRS232, USB, I2C, 2xADC, 1xGPIO, 6xOptoIO, Accelerometer, Sleep mode, Hardware Watchdog

199801348: MTX-3G-JAVA-868

European ISM (868MHz), 1xRS232, USB, I2C, 2xADC, 1xGPIO, 6xOptoIO, Accelerometer, Sleep mode, Hardware Watchdog

199801349: MTX-3G-JAVA-900

USA ISM (900MHz), 1xRS232, USB, I2C, 2xADC, 1xGPIO, 6xOptoIO, Accelerometer, Sleep mode, Hardware Watchdog

199801350: MTX-3G-JAVA-WMBUS

Wireless MBUS, 1xRS232, USB, I2C, 2xADC, 1xGPIO, 6xOptoIO, Accelerometer, Sleep mode, Hardware Watchdog

199801351: MTX-3G-JAVA-WIFI

WiFi, 1xRS232, USB, I2C, 2xADC, 1xGPIO, 6xOptoIO, Accelerometer, Sleep mode, Hardware Watchdog

Notes:

1. A battery can be included upon request in models without one
2. Economy versions of European or American bands can be ordered upon request

1.3 Features by model

Depending on the device model you have selected, there is a set of features available as described in the table below. Please ask us at gsm-support@matrix.es if you need any other combination of features, or one that is not listed here.

	MTX-3G-JAVA	MTX-3G-JAVA-RS485	MTX-3G-JAVA-RS485-WC25	MTX-3G-JAVA-BAT	MTX-3G-JAVA-GPS	MTX-3G-JAVA-GPS-BAT	MTX-3G-JAVA-GPS-BT	MTX-3G-JAVA-ULP	MTX-3G-JAVA-ULP-GPS	MTX-3G-JAVA-ULP-WC25	MTX-3G-JAVA-WC25	MTX-3G-JAVA-WC500	MTX-3G-JAVA-BT	MTX-3G-JAVA-BLE	MTX-3G-JAVA-XBEE	MTX-3G-JAVA-868	MTX-3G-JAVA-900	MTX-3G-JAVA-WMBUS	MTX-3G-JAVA-WIFI
RS232 (8-wire)	X						X	X	X										
RS232 (4-wire)	X	X		X	X	X	X			X	X	X	X	X	X	X	X	X	X
RS485		X	X																
USB	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
I2C	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
ADC	x2	x2	x2	x2	x2	x2	x2	x1	x1	x1	x2	x2	x2	x2	x2	x2	x2	x2	x2
DAC	x1							x1	x1	x1									
GPIO	x4			x1	x1	x1	x1	x5	x5	x5	x1	x1	x1	x1	x1	x1	x1	x1	x1
Optoisolated IO		x4	x4	x6	x6	x6	x6				x6	x6	x6	x6	x6	x6	x6	x6	x6
Accelerometer				X	X	X	X				X	X	X	X	X	X	X	X	X
RTC	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
Sleep mode		*1	*1	X	X	X	X				X	X	X	X	X	X	X	X	X
Ultra Low Power mode								X	X	X									
Wake Up (by RTC)		*1	*1	X	X	X	X				X	X	X	X	X	X	X	X	X
Wake Up (by Accelerometer)				X	X	X	X				X	X	X	X	X	X	X	X	X
Power On (by RTC)								X	X	X									
Power On (by Opto IO)								X	X	X									
Li-Po Battery				X		X					*2	*2	*2	*2	*2	*2	*2	*2	*2
HD WatchDog				X	X	X	X				X	X	X	X	X	X	X	X	X
Auto On	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
Internal RF module			X				X		X	X	X	X	X	X	X	X	X	X	X
GPS					X	X	X		X		*3	*3	*3	*3	*3	*3	*3	*3	*3
GPS/GLONASS					*4	*4	*4		*4		*4	*4	*4	*4	*4	*4	*4	*4	*4

*1: only if AUTO ON is disabled by hardware

*2: battery option can be ordered upon request

*3: GPS can be ordered upon request

*4: GLONASS can be ordered upon request

1.4 Highlights

Interfaces

- GSM FME M antenna connector
- SMA F antenna connector for GPS or other RF options (*)
- USB 2.0 High Speed port up to 480Mbps
- SIM card interface 1.8V and 3V
- DB9 female connector: complete 8-wire RS232 modem interface (*)
- DB15 female connector:
 - 1x RS232 (4-wire) port (*)
 - 1x I2C port
 - 5x GPIO (*)
 - 6x Optoisolated I/Os (*)
 - 2x analog inputs (*)
 - 1x analog output (*)
- 1x RS485 port (5-way plug-in terminal block) (*)
- Operating status LEDs
- Plug-in power supply (RJ11 connector)

General features

- World Wide Version (default)
 - UMTS/HSPA+: Five-Band 800/850/900/1900/2100MHz
 - GSM/GPRS/EDGE: Quad band 850/900/1800/1900MHz
- European Version
 - UMTS/HSPA+: Dual-Band 900/2100MHz
 - GSM/GPRS/EDGE: Dual band 900/1800MHz
- American Version
 - UMTS/HSPA+: Dual-Band 850/1900MHz
 - GSM/GPRS/EDGE: Dual band 850/1900MHz
- 3GPP Release 6, 7
- SIM Application Toolkit, 3GPP release 99
- Control via AT commands (Hayes, TS 27.007, TS 27.005)
- TCP/IP stack access via AT commands
- Internet services: TCP, UDP, HTTP, FTP, SMTP, POP3
- Power consumption at 12V (average)
 - Ultra Low Power: 2.5µA (*)
 - Sleep mode: 7mA (*)
 - Idle: 12mA
 - HSPA data transfer: 152mA
- Temperature range
 - Operating: -30°C to +85°C
- Dimensions, excluding connectors: 78.1 x 66.8 x 37.2mm
- Weight: < 190 g
- IP30 enclosure

- Internal Hardware Watchdog (*)
- Internal 1650mAh Li-Po battery (*)
- 3-Axis Accelerometer ($\pm 2g/\pm 4g/\pm 8g$) (*)
- Powered by Cinterion EHS6 modules

Specifications

- HSPA (3GPP Release 6,7)
 - DL 7.2Mbps, UL 5.7Mbps
 - HSDPA Cat.8 / HSUPA Cat.6 data rates
 - Compressed mode (CM) according to 3GPP TS25.212
- UMTS (3GPP Release 4)
 - PS data rate – 384 kbps DL, UL 384kbps
 - CS data rate – 64 kbps DL, UL 64kbps
- HSPA (3GPP Release 6,7)
 - DL 7.2Mbps, UL 5.7Mbps
 - HSDPA Cat.8 / HSUPA Cat.6 data rates
- GPRS
 - GPRS class 12
 - Mobile station class B
 - PBCCH support
 - Coding schemes CS 1-4
- EGPRS
 - Multislot class 12
 - EDGE E2 power class for 8PSK
- CSD data transmission
 - Up to 9.6kbps
 - V.110
 - Non-transparent mode
 - USSD support
- SMS
 - Point-to-point MO and MT
 - SMS cell broadcast
 - Text and PDU mode
- Fax
 - Group 3, class 1,2

Drivers

- USB, MUX driver for Microsoft® Windows XP™, Vista™, Windows 7™
- RIL, USB driver for Microsoft® Windows Embedded Handheld™ >= 6.x
- USB, MUX driver for Microsoft® Windows Embedded Compact™ >= 5.x
- USB serial/CDC-ACM driver for Linux

Java™ features

- Oracle Java ME Embedded 3.2
- Compliant to CLDC 1.1 HI and IMP-NG standards
- Capable of running multiple MIDlets in parallel with inter-MIDlet communication
- Additional Java standards APIs:
 - JSR75 (FileConnection)
 - JSR177 (CRYPTO)
 - JSR280 (XML)
- Additional accessible periphery for Java applications
 - I/O pins, I2C, ADC/DAC
 - Serial interfaces (API): ASC0, ASC1, USB
- Memory space for Java applications
 - Flash File System: 8MB
 - RAM: 6MB
 - Just-in-Time (JIT) Compiler execution optimization


Special features

- USB interfaces support multiple composite modes and a Linux -/Mac- compliant mode
- Firmware update via USB/RS232
- Real time clock with alarm functionality
- Multiplexer according 3GPP TS 27.010
- RLS Monitoring (Jamming detection)
- Informal Network Scan
- Customer IMEI/SIM-Lock as variant
- Integrated FOTA, configurable and royalty free

*: depending on model, see [Section 1.3](#)

1.5 Product label

The label fixed to the bottom of a MTX Terminal comprises the following information:



No.	Information
1	MTX Terminals logo
2	Product name (model)
3	Product ordering number
4	Hardware and Firmware Revisions
5	FCC ID
6	Year/Week of fabrication
7	Barcode (Code 128) (IMEI)
8	Product IMEI
9	RoHS symbol
10	Pb-Free symbol
11	WEEE symbol
12	CE logo
13	PTCRB Certification logo

1.6 Main features and services

The MTX-3G-JAVA performs a set of telecom services (TS) according to GSM standard phase 2+, ETSI and ITU-T. The services and functions of the MTX-3G-JAVA are implemented by issuing customized applications embedded on the device, by AT commands issued internally or over the USB, RS232 or RS485 interface.

1.6.1 Key features at a glance

The MTX-3G-JAVA is a UMTS/HSPA and also GSM/GPRS/EDGE bands mobile station with the characteristics shown in the table below.

Feature	Implementation
General	
Frequency bands	UMTS/HSPA+: Five band, 800/850/900/1900/2100MHz GSM/GPRS/EDGE: Quad band, 850/900/1800/1900MHz
GSM class	Small MS
Output power	Class 4 (+33dBm \pm 2dB) for EGSM850 Class 4 (+33dBm \pm 2dB) for EGSM900 Class 1 (+30dBm \pm 2dB) for GSM1800 Class 1 (+30dBm \pm 2dB) for GSM1900 Class E2 (+27dBm \pm 3dB) for GSM 850 8-PSK Class E2 (+27dBm \pm 3dB) for GSM 900 8-PSK Class E2 (+27dBm +3dB/-4dB) for GSM 1800 8-PSK Class E2 (+27dBm +3/-4dB) for GSM 1900 8-PSK Class E2 (+26dBm +3/-4dB) for GSM 1800 8-PSK Class 3 (+24dBm +1/-3dB) for UMTS 2100, WCDMA FDD Bdl Class 3 (+24dBm +1/-3dB) for UMTS 1900, WCDMA FDD BdII Class 3 (+24dBm +1/-3dB) for UMTS 900, WCDMA FDD BdVIII Class 3 (+24dBm +1/-3dB) for UMTS 850, WCDMA FDD BdV Class 3 (+24dBm +1/-3dB) for UMTS 800, WCDMA FDD BdVI
Power supply	Single supply voltage Maximum: 6.5 to 40V (without damaging the device)* Recommended: 7 to 35V <i>*(Device operation from 6.5 to 7V is not guaranteed over the whole temperature range / Supplies from 35 to 40V may damage the device during an extended use)</i>
Physical	Dimensions: 78,1 x 66,8 x 37,2 mm Weight: approx. 190g
RoHS	All hardware components are fully compliant with the EU RoHS Directive
HSPA features	
3GPP Release 6,7	DL 7.2Mbps, UL 5.7Mbps HSDPA Cat.8 / HSUPA Cat.6 data rates Compressed mode (CM) supported according to 3GPP TS25.212
UMTS features	
3GPP Release 8	PS data rate – 384 kbps DL / 384 kbps UL CS data rate – 64kbps DL / 64 kbps UL

GSM / GPRS / EGPRS features	
Data transfer	<p>GPRS</p> <ul style="list-style-type: none"> • Multislot Class 12 • Full PBCCH support • Mobile Station Class B • Coding Scheme 1 – 4 <p>EGPRS</p> <ul style="list-style-type: none"> • Multislot Class 12 • EDGE E2 power class for 8 PSK • Downlink coding schemes – CS 1-4, MCS 1-9 • Uplink coding schemes – CS 1-4, MCS 1-9 • SRB loopback and test mode B • 8-bit, 11-bit RACH • PBCCH support • 1 phase/2 phase access procedures • Link adaptation and IR • NACC, extended UL TBF • Mobile Station Class B <p>CSD</p> <ul style="list-style-type: none"> • V.110, RLP, non-transparent • 9.6kbps • USSD
SMS	<p>Point-to-point MT and MO</p> <p>Cell broadcast</p> <p>Text and PDU mode</p> <p>Storage: SIM card plus SMS locations in mobile equipment</p>
Software	
AT commands	<p>Hayes, 3GPP TS 27.007, 27.005, Gemalto M2M</p> <p>AT commands for RIL compatibility</p>
Java™ Open Platform	<p>Java™ Open Platform with</p> <ul style="list-style-type: none"> • Java™ profile IMP-NG & CLDC 1.1 HI • Secure data transmission via HTTPS/SSL • Multi-threading programming and multi-application execution <p>Major benefits: seamless integration into Java applications, ease of programming, no need for application microcontroller, extremely cost-efficient hardware and software design – an ideal platform for industrial GSM applications.</p> <p>The memory space available for Java programs is around 8MB in the flash file system and around 6MB of RAM. Application code and data share the space in the flash file system and in the RAM.</p>
Microsoft™ compatibility	RIL for Pocket PC and Smartphone
SIM Application Toolkit	SAT Release 99
Firmware update	Firmware update from host application over USB.
Interfaces (depending on models)	
USB	Supports a USB 2.0 High Speed (480Mbit/s) device interface, Full Speed (12Mbit/s) compliant
RS232 (8-wire)	<p>Adjustable baud rates: 1200bps to 921600bps</p> <p>Autobauding: 1200 to 230400bps</p> <p>Supports RTS/CTS hardware flow control</p> <p>Multiplex ability according to GSM 07.10 Multiplexer Protocol</p>

RS232 (4-wire)	Adjustable baud rates: 1200bps to 921600bps Autobauding: 1200 to 230400bps Supports RTS/CTS hardware flow control Multiplex ability according to GSM 07.10 Multiplexer Protocol
RS485	Adjustable baud rates: 1200bps to 921600bps Autobauding: 1200 to 230400bps Half-duplex
I2C interface	Supports I2C serial interface up to 400kbps
GPIO	Up to 5 GPIO lines and 6 Optoisolated I/O's
ADC	Up to 2 analog-to-digital converters
DAC	1 digital-to-analog converter
Status	Bi-color LED to indicate network connectivity status.
UICC interface	Supported chip cards: UICC/SIM/USIM 3V, 1.8V
Antenna	50 Ohms. GSM/UMTS main antenna
Power on/off, Reset	
Power on/off	Automatic switch-on at power supply Switch off by AT command Switch off by hardware signal TURN_OFF Automatic switch-off in case of critical temperature or voltage conditions
Software Reset	Orderly shutdown and reset by AT command
Hardware Reset	Emergency reset by hardware signal TURN_OFF
Special features	
Antenna	SAIC (Single Antenna Interference Cancellation) / DARP (Downlink Advanced Receiver Performance) Rx Diversity (receiver type 3i – 64-QAM) / MIMO

1.6.2 Operating modes

The table below briefly summarizes the various operating modes referred to in the following chapters.

Limits	Function	
Normal operation	GSM / GPRS / UMTS / HSPA SLEEP	Power saving automatically activated when no calls are in progress, the USB connection is suspended by the host or not present, and there is no active communication via ASCO
	GSM / GPRS / UMTS / HSPA IDLE	Power saving is disabled if a USB connection is not suspended, but no call is in progress.
	GSM TALK / GSM DATA	Connection between two subscribers is in progress. Power consumption depends on the GSM network coverage and several connection settings (e.g. DTX off/on, FR/EFR/HR, hopping sequences and antenna connection). The following applies when power is to be measured in TALK_GSM mode: DTX off, FR and no frequency hopping.
	GPRS DATA	GPRS data transfer in progress. Power consumption depends on network settings (e.g. power control level), uplink / downlink data rates and GPRS configuration (e.g. used multislot settings).
	EGPRS DATA	EGPRS data transfer in progress. Power consumption depends on network settings (e.g. power control level), uplink / downlink data rates and EGPRS configuration (e.g. used multislot settings).
	UMTS TALK / UMTS DATA	UMTS data transfer in progress. Power consumption depends on network settings (e.g. TPC Pattern) and data transfer rate.
	HSPA DATA	HSPA data transfer in progress. Power consumption depends on network settings (e.g. TPC Pattern) and data transfer rate.
Sleep mode	Normal shutdown after sending the power down command. The internal GSM engine enters in a power down mode where only a voltage regulator is active for powering the internal RTC. Software is not active. Interfaces are not accessible.	
Ultra Low Power mode	Only available in MTX-3G-JAVA-ULP devices. All the electronic systems remain disconnected from the power supply input, with the exception of a little piece of logic which allows for waking up the unit again.	
Airplane mode	Airplane mode shuts down the radio part of the device, causes the modem to log off from the GSM/GPRS network, and disables all AT commands whose execution requires a radio connection. Airplane mode can be controlled by AT command	

1.6.3 Power Consumption

It is recommend to use 12V/1.5A power supply.

	Description	Conditions		Typical	Unit
IIN ¹	ULP mode supply current	Ultra Low Power Mode		2.5	μA
	Sleep mode supply current	Internal GSM module powered down		7	mA
	Average GSM/GPRS supply current	IDLE (UART activated but no communication) @ DRX=2	USB disconnected	11	mA
			USB active	12	mA
		GPRS Data transfer GSM850/900; PCL=5; 1Tx/4Rx	ROPR=4 (max. reduction)	67	mA
			ROPR=0 (no reduction)		
		GPRS Data transfer GSM850/900; PCL=5; 2Tx/3Rx	ROPR=4 (max. reduction)	84.5	mA
			ROPR=0 (no reduction)	115	mA
		GPRS Data transfer GSM850/900; PCL=5; 4Tx/1Rx	ROPR=4 (max. reduction)	90	mA
			ROPR=0 (no reduction)	205	mA
		EDGE Data transfer GSM850/900; PCL=5; 1Tx/4Rx	ROPR=4 (max. reduction)	50	mA
			ROPR=0 (no reduction)		
		EDGE Data transfer GSM850/900; PCL=5; 2Tx/3Rx	ROPR=4 (max. reduction)	64.5	mA
			ROPR=0 (no reduction)	81	mA
		EDGE Data transfer GSM850/900; PCL=5; 4Tx/1Rx	ROPR=4 (max. reduction)	97	mA
			ROPR=0 (no reduction)	136	mA
		GPRS Data transfer GSM1800/1900; PCL=0; 1Tx/4Rx	ROPR=4 (max. reduction)	52	mA
			ROPR=0 (no reduction)		
		GPRS Data transfer GSM1800/1900; PCL=0; 2Tx/3Rx	ROPR=4 (max. reduction)	57	mA
			ROPR=0 (no reduction)	85	mA
		GPRS Data transfer GSM1800/1900; PCL=0; 4Tx/1Rx	ROPR=4 (max. reduction)	67	mA
			ROPR=0 (no reduction)	145	mA
		EDGE Data transfer GSM1800/1900; PCL=0; 1Tx/4Rx	ROPR=4 (max. reduction)	45	mA
			ROPR=0 (no reduction)		
		EDGE Data transfer GSM1800/1900; PCL=0; 2Tx/3Rx	ROPR=4 (max. reduction)	62	mA
			ROPR=0 (no reduction)	70	mA
		EDGE Data transfer GSM1800/1900; PCL=0; 4Tx/1Rx	ROPR=4 (max. reduction)	95	mA
			ROPR=0 (no reduction)	115	mA
	Average WCDMA supply current	IDLE (UART activated but no communication) @ DRX=6	USB disconnected	10	mA
			USB active	16	mA
			UMTS Data transfer Band I @ 23dBm		132
		UMTS Data transfer Band II @ 23dBm		150	mA
		UMTS Data transfer Band V/VI @ 23dBm		150	mA
		UMTS Data transfer Band VIII @ 23dBm		152	mA
		HSPA Data transfer Band I @ 23dBm		132	mA
		HSPA Data transfer Band II @ 23dBm		150	mA
		HSPA Data transfer Band V/VI @ 23dBm		150	mA
		HSPA Data transfer Band VIII @ 23dBm		152	mA

1. With an impedance of $Z_{LOAD}=50\Omega$ at the antenna port.
2. Measurements start 6 minutes after switching ON the modules
Average times: SLEEP and ULP mode – 3 minutes, transfer modes – 1.5 minutes
Communication tester settings: no neighbor cells, no cell reselection etc., RMC (reference measurement channel)

Description	Conditions	Typ	Max	Unit
ULP mode supply current	T _A = 25°C	2.5	5	μA
	T _A = 85°C	8.5	34	μA

1.6.4 RF antenna interface description

The table below briefly summarizes the RF Antenna interface GSM/UMTS

Parameter		Conditions	Min.	Typical	Max.	Unit
UMTS/HSPA connectivity		Band I, II, V, VI, VIII				
Receiver Input Sensitivity @ ARP		UMTS 800/850 Band VI/V	-104.7/-106.7	-110		dBm
		UMTS 900 Band VIII	-103.7	-110		dBm
		UMTS 1900 Band II	-104.7	-109		dBm
		UMTS 2100 Band I	-106.7	-110		dBm
RF Power @ ARP with 50Ohm Load		UMTS 800/850 Band VI/V	21	24	25	dBm
		UMTS 900 Band VIII	21	24	25	dBm
		UMTS 1800 Band III	21	24	25	dBm
		UMTS 2100 Band I	21	24	25	dBm
GPRS coding schemes		Class 12, CS1 to CS4				
EGPRS		Class 12, MCS1 to MCS9				
GSM Class		Small MS				
Static Receiver Input Sensitivity @ ARP		GSM 850 / E-GSM 900	-102	-109		dBm
		GSM 1800 / GSM 1900	-102	-108		dBm
RF Power @ ARP with 50Ohm Load	GSM	GSM 850 / E-GSM 900		33		dBm
		GSM 1800 / GSM 1900		30		dBm
RF Power @ ARP with 50Ohm Load, (ROPR = 0, i.e. no reduction)	GPRS, 1 TX	GSM 850 / E-GSM 900		33		dBm
		GSM 1800 / GSM 1900		30		dBm
	EDGE, 1 TX	GSM 850 / E-GSM 900		27		dBm
		GSM 1800 / GSM 1900		26		dBm
	GPRS, 2 TX	GSM 850 / E-GSM 900		33		dBm
		GSM 1800 / GSM 1900		30		dBm
	EDGE, 2 TX	GSM 850 / E-GSM 900		27		dBm
		GSM 1800 / GSM 1900		26		dBm
	GPRS, 3 TX	GSM 850 / E-GSM 900		33		dBm
		GSM 1800 / GSM 1900		30		dBm
	EDGE, 3 TX	GSM 850 / E-GSM 900		27		dBm
		GSM 1800 / GSM 1900		26		dBm
	GPRS, 4 TX	GSM 850 / E-GSM 900		33		dBm
		GSM 1800 / GSM 1900		30		dBm
	EDGE, 4 TX	GSM 850 / E-GSM 900		27		dBm
		GSM 1800 / GSM 1900		26		dBm
RF Power @ ARP with 50Ohm Load, (ROPR = 1)	GPRS, 1 TX	GSM 850 / E-GSM 900		33		dBm
		GSM 1800 / GSM 1900		30		dBm
	EDGE, 1 TX	GSM 850 / E-GSM 900		27		dBm
		GSM 1800 / GSM 1900		26		dBm
	GPRS, 2 TX	GSM 850 / E-GSM 900		33		dBm
		GSM 1800 / GSM 1900		30		dBm
	EDGE, 2 TX	GSM 850 / E-GSM 900		27		dBm
		GSM 1800 / GSM 1900		26		dBm

	GPRS, 3 TX	GSM 850 / E-GSM 900		33		dBm
		GSM 1800 / GSM 1900		30		dBm
	EDGE, 3 TX	GSM 850 / E-GSM 900		27		dBm
		GSM 1800 / GSM 1900		26		dBm
	GPRS, 4 TX	GSM 850 / E-GSM 900		31		dBm
		GSM 1800 / GSM 1900		28		dBm
RF Power @ ARP with 500hm Load, (ROPR = 2)	EDGE, 4 TX	GSM 850 / E-GSM 900		27		dBm
		GSM 1800 / GSM 1900		26		dBm
	GPRS, 1 TX	GSM 850 / E-GSM 900		33		dBm
		GSM 1800 / GSM 1900		30		dBm
	EDGE, 1 TX	GSM 850 / E-GSM 900		27		dBm
		GSM 1800 / GSM 1900		26		dBm
	GPRS, 2 TX	GSM 850 / E-GSM 900		33		dBm
		GSM 1800 / GSM 1900		30		dBm
	EDGE, 2 TX	GSM 850 / E-GSM 900		27		dBm
		GSM 1800 / GSM 1900		26		dBm
	GPRS, 3 TX	GSM 850 / E-GSM 900		33		dBm
		GSM 1800 / GSM 1900		30		dBm
	EDGE, 3 TX	GSM 850 / E-GSM 900		27		dBm
		GSM 1800 / GSM 1900		26		dBm
	GPRS, 4 TX	GSM 850 / E-GSM 900		29		dBm
		GSM 1800 / GSM 1900		26		dBm
	EDGE, 4 TX	GSM 850 / E-GSM 900		27		dBm
		GSM 1800 / GSM 1900		26		dBm
RF Power @ ARP with 500hm Load, (ROPR = 3)	GPRS, 1 TX	GSM 850 / E-GSM 900		33		dBm
		GSM 1800 / GSM 1900		30		dBm
	EDGE, 1 TX	GSM 850 / E-GSM 900		27		dBm
		GSM 1800 / GSM 1900		26		dBm
	GPRS, 2 TX	GSM 850 / E-GSM 900		33		dBm
		GSM 1800 / GSM 1900		30		dBm
	EDGE, 2 TX	GSM 850 / E-GSM 900		27		dBm
		GSM 1800 / GSM 1900		26		dBm
	GPRS, 3 TX	GSM 850 / E-GSM 900		33		dBm
		GSM 1800 / GSM 1900		30		dBm
	EDGE, 3 TX	GSM 850 / E-GSM 900		27		dBm
		GSM 1800 / GSM 1900		26		dBm
RF Power @ ARP with 500hm Load, (ROPR = 4, i.e. maximum reduction)	GPRS, 4 TX	GSM 850 / E-GSM 900		27		dBm
		GSM 1800 / GSM 1900		24		dBm
	EDGE, 4 TX	GSM 850 / E-GSM 900		27		dBm
		GSM 1800 / GSM 1900		24		dBm
	GPRS, 1 TX	GSM 850 / E-GSM 900		33		dBm
		GSM 1800 / GSM 1900		30		dBm
	EDGE, 1 TX	GSM 850 / E-GSM 900		27		dBm
		GSM 1800 / GSM 1900		26		dBm
	GPRS, 2 TX	GSM 850 / E-GSM 900		30		dBm

		GSM 1800 / GSM 1900		27		dBm
	EDGE, 2 TX	GSM 850 / E-GSM 900		24		dBm
		GSM 1800 / GSM 1900		23		dBm
	GPRS, 3 TX	GSM 850 / E-GSM 900		28.2		dBm
		GSM 1800 / GSM 1900		25.2		dBm
	EDGE, 3 TX	GSM 850 / E-GSM 900		22.2		dBm
		GSM 1800 / GSM 1900		21.2		dBm
	GPRS, 4 TX	GSM 850 / E-GSM 900		27		dBm
		GSM 1800 / GSM 1900		24		dBm
	EDGE, 4 TX	GSM 850 / E-GSM 900		21		dBm
		GSM 1800 / GSM 1900		20		dBm

1.6.5 SIM Card

The MTX-3G-JAVA supports an external SIM card through the integrated SIM holder. Both 3V and 1.8V SIM technology is supported. Older 5V SIM technology is not supported.


1.7 Precautions

MTX-3G-JAVA as a standalone item is designed for indoor use only. For outdoor use it must be integrated into a weatherproof enclosure. Do not exceed the environmental and electrical limits as specified in Technical Data

1.8 Block diagram


1.8.1 Base MTX-3G-JAVA

The base MTX-3G-JAVA modem's block diagram is shown in the following figure:




1.8.2 RS485 models

The MTX-3G-JAVA-RS485 modem's block diagram is shown in the following figure:




1.8.3 ULP models

The MTX-3G-JAVA-ULP modem's block diagram is shown in the following figure:



1.8.4 All other models

The general MTX-3G-JAVA family block diagram is shown in the following figure:



1.9 Hardware revisions

Base MTX-3G-JAVA and MTX-3G-JAVA-ULP models

Hardware Revision	Starting production date	Changes
2.03	01/2014	Initial version

Base MTX-3G-JAVA-RS485 models

Hardware Revision	Starting production date	Changes
1.02	01/2014	Initial version

All other models


Hardware Revision	Starting production date	Changes
5.02	01/2014	Initial version

2. Mechanical description


2.1 MTX-3G-JAVA model and ULP models

2.1.1 Overview

The pictures below show the mechanical design of the unit along with the positions of the different connectors and mounting holes. The device case is made of durable PC/ABS plastic.



2.1.2 Dimensions



All dimensions are in millimeters




All dimensions are in millimeters



2.2 MTX-3G-JAVA-RS485 models

2.2.1 Overview


The pictures below show the mechanical design of the unit along with the positions of the different connectors and mounting holes. The modem case is made of durable PC/ABS plastic.



2.2.2 Dimensions



All dimensions are in millimeters




All dimensions are in millimeters



2.3 All other models

2.3.1 Overview


The pictures below show the mechanical design of the unit along with the positions of the different connectors and mounting holes. The device case is made of durable PC/ABS plastic.



2.3.2 Dimensions



All dimensions are in millimeters



All dimensions are in millimeters

3. Electrical and environmental characteristics

3.1 Electrical specifications

3.1.1 Power supply

ABSOLUTE MAXIMUM RATINGS					
Symbol	Parameter	Conditions	Min.	Max.	Unit
V _{IN}	Supply voltage	All models except ULP devices	0	45	V
V _{IN}	Supply voltage	All ULP devices	0	10	V

CHARACTERISTICS						
Symbol	Parameter	Conditions	Min.	Typ.	Max.	Unit
V _{IN}	Supply voltage (all models except ULP)	Maximum	6.5		40	V
		Recommended	7		35	V
V _{IN}	Supply voltage (all ULP devices)	Maximum	6		10	V
		Recommended	6.5	7.2	9.5	V
I _{IN}	Supply current		-	*	-	A
η	Efficiency	V _{IN} =12V, I _{IN} =2A, 25°C		80		%
f _o	Switching Frequency		127	150	173	kHz

* See [section 1.6.3](#)

3.1.2 RS232 interface

ABSOLUTE MAXIMUM RATINGS					
Symbol	Parameter	Conditions	Min.	Max.	Unit
V _I	Input voltage range	Drivers	-0.3	6	V
		Receivers	-25	25	V
V _O	Output voltage range	Drivers	-13.2	13.2	V
		Receivers	-0.3	5	V
	Electrostatic discharge	Human body model		2	kV

CHARACTERISTICS						
Symbol	Parameter	Conditions	Min.	Typ.	Max.	Unit
V _{OH}	Driver high-level output voltage	R _L =3kΩ to GND	5	5.4		V
V _{OL}	Driver low-level output voltage	R _L =3kΩ to GND	-5	-5.4		V
r _o	Driver output resistance	V _{IN} = 0V	300	10M		Ω
V _{IT+}	Receiver positive-going input threshold voltage			1.5	2.4	V
V _{IT-}	Receiver negative-going input threshold voltage		0.6	1.2		V
V _{hys}	Receiver input hysteresis (V _{IT+} - V _{IT-})			0.3		V
r _i	Receiver input resistance	Input voltage ±3 to ±25V	3	5	7	kΩ

3.1.3 RS485 interface

ABSOLUTE MAXIMUM RATINGS					
Symbol	Parameter	Conditions	Min.	Max.	Unit
V_I	Voltage input range, transient pulse, A and B, through 100 Ω			± 50	V
I_O	Receiver output current			± 11	mA
	Electrostatic discharge	Human body model		± 16	kV
		Charged-device model		± 1	kV

CHARACTERISTICS						
Symbol	Parameter	Conditions	Min.	Typ.	Max.	Unit
$ V_{OD} $	Driver differential output voltage	$I_O = 0$	2		3	V
		$R_L = 54k\Omega$	-5	-5.4		V
$C_{(OD)}$	Driver differential output capacitance	$V_{OD} = 0.4\sin(4\pi t) + 0.5V$		16		pF
I_{OS}	Driver short-circuit output current		-250		+250	mA
V_{IT+}	Receiver positive-going input threshold voltage	$I_O = -8mA$		-0.065	-0.01	V
V_{IT-}	Receiver negative-going input threshold voltage	$I_O = 8mA$	-0.2	-0.1		V
V_{hys}	Receiver input hysteresis ($V_{IT+} - V_{IT-}$)			35		mV
$C_{(ID)}$	Receiver differential input capacitance	$V_{OD} = 0.4\sin(4\pi t) + 0.5V$		15		pF

3.1.4 I2C interface

ABSOLUTE MAXIMUM RATINGS					
Symbol	Parameter	Conditions	Min.	Max.	Unit
V_I	Input voltage range		-0.5	+6.5	V
I_O	Continuous output current			± 50	mA
I_{IK}	Input clamp current	$V_I < 0V$		-50	mA
I_{OK}	Output clamp current	$V_O < 0V$		-50	mA
SCLK frequency	Clock frequency	$V_I < 0V$		100	kHz

CHARACTERISTICS						
Symbol	Parameter	Conditions	Min.	Typ.	Max.	Unit
V_{IH}	High-level input voltage		2.6		3	V
V_{IL}	Low-level input voltage		0		0.15	V
V_{OH}	High-level output voltage		2.01			V
V_{OL}	Low-level output voltage				0.4	V
C_{IO}	Input/Output capacitance	$T_A = 25^\circ C$		6		pF
		-40 to 85 $^\circ C$	7.5			pF

3.1.5 GPIO

ABSOLUTE MAXIMUM RATINGS					
Symbol	Parameter	Conditions	Min.	Max.	Unit
V_I	Input voltage range		-0.5	3.5	V
V_O	Output voltage range		-0.5	3.5	V
I_{IK}	Input clamp current	$V_I < 0V$		-20	mA
I_{OK}	Output clamp current	$V_O < 0V$		-20	mA
I_{IOK}	Input/Output clamp current	$V_O < 0V$ or $V_O > 3V$		± 20	mA
I_{OL}	Continuous output low current	$V_O = 0V$ to $3V$		50	mA
I_{OH}	Continuous output high current	$V_O = 0V$ to $3V$		-50	mA

CHARACTERISTICS						
Symbol	Parameter	Conditions	Min.	Typ.	Max.	Unit
V_{IH}	High-level input voltage		2.1		5.5	V
V_{IL}	Low-level input voltage		-0.5		0.9	V
I_{OH}	High-level output current				-10	mA
I_{OL}	Low-level output current				25	mA
V_{OH}	High-level output voltage	$I_{OH} = -10mA$	2.5			V
C_{IO}	Input/Output capacitance	$V_{IO} = 3V$ or GND		3.7	9.5	pF

3.1.6 Optoisolated Input/Output

ABSOLUTE MAXIMUM RATINGS (TCMD4000 OPTOCOUPLER)					
Symbol	Parameter	Conditions	Min.	Max.	Unit
Input					
V_R	Reverse voltage			6	V
I_F	Forward current			60	mA
I_{FSM}	Forward surge current			1.5	A
P_{diss}	Power dissipation			100	mW
Output					
V_{CEO}	Collector-emitter voltage			35	V
V_{ECO}	Emitter-collector voltage			7	V
I_C	Collector current			80	mA
I_{CM}	Collector peak current	$t_p/T = 0.5$, $t_p \leq 10ms$		100	mA
P_{diss}	Power dissipation			150	mW
Coupler					
V_{ISO}	AC isolation test voltage (RMS)			3750	V_{RMS}
P_{tot}	Total power dissipation			250	mW

CHARACTERISTICS (TCMD4000 OPTOCOUPLER)						
Symbol	Parameter	Conditions	Min.	Typ.	Max.	Unit
Input						
V_F	Forward voltage	$I_F = 50\text{mA}$		1.25	1.6	V
C_j	Junction capacitance	$V_R = 0\text{V}$, $f = 1\text{MHz}$		50		pF
Output						
V_{CEO}	Collector-emitter voltage	$I_C = 100\mu\text{A}$	35			V
V_{ECO}	Emitter-collector voltage	$I_E = 100\mu\text{A}$	7			V
I_{CEO}	Collector dark current	$V_{CE} = 10\text{V}$, $I_F = 0$			100	nA
Coupler						
V_{CESat}	Collector-emitter saturation voltage	$I_F = 20\text{mA}$, $I_C = 5\text{mA}$			1	V
f_c	Cut-off frequency	$I_F = 10\text{mA}$, $V_{CE} = 5\text{V}$, $R_L = 100\Omega$		10		kHz
C_k	Coupling capacitance	$f = 1\text{MHz}$		0.3		pF
I_C / I_F	Current transfer ratio	$V_{CE} = 2\text{V}$, $I_F = 1\text{mA}$	600	800		%
t_r	Rise time	$V_{CE} = 2\text{V}$, $I_F = 1\text{mA}$, $R_L = 100\Omega$		300		μs
t_{off}	Turn-off time	$V_{CE} = 2\text{V}$, $I_F = 1\text{mA}$, $R_L = 100\Omega$		250		μs

Please see equivalent circuits in [Section 4.4.5](#) to view voltage input/output ranges and determine operating conditions in each case.

3.1.7 Analog Input/Output

ABSOLUTE MAXIMUM RATINGS					
Symbol	Parameter	Conditions	Min.	Max.	Unit
V_I	Input voltage		-0.5	3.5	V
I_I	Input current			± 10	mA
I_O	Output current			± 20	mA
	Electrostatic discharge	Human body model		± 3000	V
		Machine model		± 300	V
P_{OUT}	DAC output power dissipation			100	mW

CHARACTERISTICS						
Symbol	Parameter	Conditions	Min.	Typ.	Max.	Unit
V_{oa}	Analog output voltage range	No resistive load	0		3	V
		$R_L = 10\text{k}\Omega$	0		2.7	V
E_O	DAC Offset error	$T_A = 25^\circ\text{C}$			50	mV
E_L	DAC Linearity error				± 1.5	LSB
E_G	DAC Gain error	No resistive load			1	%
$t_{s(DAC)}$	DAC settling time	To $\frac{1}{2}$ LSB full scale			90	μs
$f_{c(DAC)}$	DAC conversion frequency				11.1	kHz
V_{ia}	Analog input voltage range		0		3	V
I_{LIA}	Analog input leakage current				100	nA
$C_{i(a)}$	Analog input capacitance			10		pF
E_O	ADC Offset error	$T_A = 25^\circ\text{C}$			20	mV
E_L	ADC Linearity error				± 1.5	LSB
E_G	ADC Gain error				1	%
		Small signal; $\Delta V_i = 16\text{LSB}$			5	%
CMRR	ADC Common Mode Rejection Ratio			60		dB
$f_{c(ADC)}$	ADC conversion frequency				50	kHz
NBITS	ADC & DAC converter bits number		8	8	8	bits

3.2 Operating temperatures

Please note that the modem's lifetime, i.e., the MTTF (mean time to failure) may be reduced if operated outside the extended temperature range.

Parameter	Min	Typ	Max	Unit
Normal operation	-30	+25	+85	°C
Extended operation ¹	-40		+90	°C
Automatic shutdown ²	<-40		>+90	°C

1. Extended operation allows normal mode speech calls or data transmissions for a limited time until the automatic thermal shutdown mode takes effect. Within the extended temperature range (outside the operating temperature range) the specified electrical characteristics may be increased or decreased.
2. Due to uncertainty in temperature measurement, a tolerance of $\pm 3^{\circ}\text{C}$ on the stated shutdown thresholds may occur.

Note that within the specified operating temperature ranges the unit temperature may vary to a great extent depending on the operating mode, used frequency band, radio output power and current supply voltage.

3.3 Storage conditions

The conditions stated below are only valid for modems in their original packed state in weather protected, non-temperature-controlled storage locations. Normal storage time under these conditions is a maximum of 12 months. The units will be delivered in a packaging that meets the requirements according “IPD/JEDEC J-STD-033B.1” for Low Temperature Carriers.

Type	Condition	Unit	Reference
Air temperature: Low	-30	°C	ETS 300 019-2-1: T1.2, IEC 60068-2-1 Ab
High	+75		ETS 300 019-2-1: T1.2, IEC 60068-2-2 Db
Relative humidity: Low	10	%	---
High	90 at 30°C		ETS 300 019-2-1: T1.2, IEC 60068-2-56 Cb
Condensation	90-100 at 30°C		ETS 300 019-2-1: T1.2, IEC 60068-2-30 Db
Air pressure: Low	70	kPa	IEC TR 60271-3-1:1K4
High	106		IEC TR 60271-3-1:1K4
Movement of surrounding air	1.0	m/s	IEC TR 60271-3-1:1K4
Water: rain, dripping, icing and frosting	Not allowed	-	-
Radiation: Solar	1120	W/m2	ETS 300 019-2-1: T1.2, IEC 60068-2-2Bb
Heat	600		ETS 300 019-2-1: T1.2, IEC 60068-2-2Bb
Chemically active substances	Not recommended		IEC TR 60271-3-1:1C1L
Mechanically active substances	Not recommended		IEC TR 60271-3-1:1S1
Sinusoidal vibration:			IEC TR 60271-3-1:1M2
Displacement	1.5	mm	
Acceleration	5	m/s2	
Frequency range	2-9 9-200	Hz	
Shocks:			IEC 60068-2-27 Ea
Shock spectrum	semi-sinusoidal		
Duration	1	ms	
Acceleration	50	m/s2	

4. Interface description

All electrical connections to the modem are protected in compliance with the standard air and contact Electrostatic Discharge (ESD).

The modem family uses the following industry standard connectors:

- USB mini connector
- DB9 female (main RS232 port)
- DB15 female (main RS232 and/or I/O expansion connector)
- RJ11 6-way (power supply connector)
- 5 way plug-in terminal block (power supply and RS485 bus)
- SIM card reader
- FME male coaxial jack (antenna connector)
- SMA female coaxial jack (GPS/GNSS antenna connector) or other RF options

4.1 Power supply connector

Depending on the specific modem you are using, you will dispose of one of the connectors described in the sections below. Please read them carefully.

4.1.1 RJ11 (base MTX-3G-JAVA)

An RJ11 6-way connector, as shown and described below, serves as a means of supplying and controlling DC power to the modem.

The power supply voltage (VCC) required by the modem is in the range of 6.5 to 40VDC. We recommend a 12V DC power supply. The power supply has to be a single voltage source capable of providing a current peak during an active transmission. The uplink burst causes strong ripples (drop) on the power lines.

By default, the MTX-3G-JAVA will automatically switch on when power supply is applied at PIN 1 and PIN 6.




Pin	Signal	Direction	Limits	Description
1	VIN	Input	6.5-40VDC	Positive power input
2	Not connected			Reserved for future uses
3	TURN_OFF	Input	Vmax: VIN	Active high control line used to switch off or reset the modem VIH>5V, VIL<2V Power off: t >10ms
4	Not connected			Reserved for future uses
5	Not connected			Reserved for future uses
6	GND	Input		Negative power (ground)

4.1.2 5 way plug-in terminal block (RS485 models)

A 5 way plug-in terminal block connector shared with RS485 bus, as shown and described below, supplies and controls the D.C. power to the modem.

The supply voltage, VCC, required by the modem is in the range of 6.5 to 40VDC. We recommend a 12VDC power supply. The power supply has to be a single voltage source capable of providing a peak during an active transmission. The uplink burst causes strong ripples (drop) on the power lines.

By default, the MTX-3G-JAVA-RS485 will automatically switch on when power supply is applied at PIN 4 and PIN 5.



Pin	Signal	Direction	Limits	Description
1	-RxB	I/O		RS485 B signal (see section 4.5 for details)
2	+RxA	I/O		RS485 A signal (see section 4.5 for details)
3	AUTO ON	Input	0-VIN	Automatic Restart after Shutdown Enable Signal
4	VIN	Input	6.5-40VDC	Positive power input
5	GND	Input		Negative power (ground)

4.1.3 RJ11 (ULP models)

An RJ11 6-way connector, as shown and described below, serves as a means of supplying and controlling DC power to the modem.

The power supply voltage (VCC) required by the modem is in the range of 6.5 to 10VDC (9.8 to 13.9VDC can be ordered upon request). The power supply has to be a single voltage source capable of providing a current peak during an active transmission. The uplink burst causes strong ripples (drop) on the power lines.

Application of the power supply voltage to PIN 1 does not switch the modem on by default. The user has to use whatever wake-up source once the modem is powered.



Pin	Signal	Direction	Limits	Description
1	VIN	Input	6.5-10VDC 7.2 typ.	Positive power input
2	Wake-up 1 (GPIO6)	Input	0-VIN	Optoisolated wake up active low input signal
3	Wake-up 2 (GPIO7)	Input	0-VIN	Optoisolated wake up active low input signal
4	Wake-up 3 (GPIO8)	Input	0-VIN	Optoisolated wake up active high input signal (VIH min 3V, max VIN)
5	Wake-up 4 (GPIO9)	Input	0-VIN	Optoisolated wake up active high input signal (VIH min 3V, max VIN)
6	GND	Input		Negative power (ground)

4.1.4 RJ11 (all other models)

An RJ11 6-way connector, as shown and described below, serves as a means of supplying and controlling DC power to the modem.

The power supply voltage (VCC) required by the modem is in the range of 6.5 to 40VDC. We recommend a 12V DC power supply. The power supply has to be a single voltage source capable of providing a current peak during an active transmission. The uplink burst causes strong ripples (drop) on the power lines.

By default, MTX-3G-JAVA devices are shipped to automatically switch on only with supply at PIN 1 and PIN 6. If you disable the “Automatic power up” feature you will need to use the additional active-low control signal TURN_ON, which must be applied for a time of 0.2 seconds or greater.



Pin	Signal	Direction	Limits	Description
1	VIN	Input	6.5-40VDC	Positive power input
2	OUT4	Output	Vmax: VIN	Opto-isolated output GPIO6 + Red LED Logic 0: Hi-Z Logic 1: Active = VIN-0.2
3	TURN_OFF	Input	0-VIN	Opto-isolated active low control line used to switch off or reset the modem Power off: t >10ms
4	TURN_ON	Input	0-VIN	Opto-isolated active low control line used to switch on the modem (only when automatic restart is disabled) Power on: t >0.4s
5	IN4	Input	0-VIN	Opto-isolated input GPIO5 7 to VIN: logic 0
6	GND	Input		Negative power (ground)

4.2 Mini USB connector

The MTX-3G.JAVA supports a USB 2.0 High Speed (480Mbit/s) device interface. The USB interface is primarily intended for use as a command and data interface and for downloading firmware. The USB I/O pins are capable of driving the signal at a minimum of 3.0V. They are 5V I/O compliant.

The USB port has different functions depending on whether Java is running or not. With Java, the lines may be used for debugging purposes. If Java is not used, the USB interface is available as a command and data interface and for downloading firmware.

To properly connect the module's USB interface to the host, a USB 2.0 compatible connector is required. Furthermore, the USB modem driver which is delivered with MTX-3G-JAVA must be installed as described below.

The USB host is responsible for supplying power across the VUSB_IN line to the module's USB interface. This is because MTX-3G-JAVA is designed as a self powered device compliant with the *"Universal Serial Bus Specification Revision 2.0"*.

The MTX-3G-JAVA cannot be powered by a USB port. If you need this feature, contact gsm-support@matrix.es. Only modems that have a mounted internal Li-Po battery (-BAT) can operate with USB power voltage.

There are drivers available for Windows and Linux environment applications. Visit the MTX-3G-JAVA web page at www.mtxm2ms.com.

4.3 DB9 connector: main RS232 port

Applicable models:

MTX-3G-JAVA	MTX-3G-JAVA-RS485	MTX-3G-JAVA-RS485	MTX-3G-JAVA-BAT	MTX-3G-JAVA-GPS	MTX-3G-JAVA-GPS-BAT	MTX-3G-JAVA-GPS-BT	MTX-3G-JAVA-ULP	MTX-3G-JAVA-ULP-GPS	MTX-3G-JAVA-ULP-WC25	MTX-3G-JAVA-WC25	MTX-3G-JAVA-WC500	MTX-3G-JAVA-BT	MTX-3G-JAVA-BLE	MTX-3G-JAVA-XBEE	MTX-3G-JAVA-868	MTX-3G-JAVA-900	MTX-3G-JAVA-WMBUS	MTX-3G-JAVA-WIFI
X						X	X	X										

The modem supports a standard RS232 8-wire serial interface (EIA/TIA 574) via its 9 pin Sub-D connector, shown below. It is connected to the modem's ASC0 main port using a level shifter converter.



The MTX-3G-JAVA modem is designed to be used as a DCE (data circuit-terminating equipment). Based on the conventions for DCE-DTE connections, it communicates with the customer application (DTE- data terminating equipment) using the following signals:

- Port TxD @ application sends data to TXD of MTX-3G-JAVA Terminal
- Port RxD @ application receives data from RXD of MTX-3G-JAVA Terminal

The RS-232 interface is implemented as a serial asynchronous transmitter and receiver conforming to ITU-T V.24 Interchange Circuits DCE. It is configured for 8 data bits, no parity and 1 stop bit and can be operated at fixed bit rates from 1200bps to 921600bps.

Autobauding supports bit rates from 1200bps to 230400bps. Autobauding is not compatible with multiplex mode. Hardware handshake using the /RTS and /CTS signals and XON/XOFF software flow control are supported.

In addition, the modem control signals DTR, DSR, DCD and RING are available. The MODEM control RING signal (Ring Indication) can be used to indicate, to the cellular device application, that an incoming call or Unsolicited Result Code (URC) is received. It can also be used to send pulses to the host application; for example, to wake the application up from the power saving mode.

The DB9 connector pinout is shown in the table below:

Pin	Signal	Direction	Description
1	DCD	Output	Data carrier detected
2	RD 0	Output	Received data
3	TD 0	Input	Transmitted data
4	DTR	Input	Data terminal ready
5	GND	-	Ground connection
6	DSR	Output	Data set ready
7	RTS	Input	Request to send
8	CTS	Output	Clear to send
9	RI	Output	Ring indicator

Features

- Includes the data lines TXD0 and RXD0, the status lines RTS0 and CTS0 and also the modem control lines DTR0, DSR0, DCD0 and RING0.
- ASC0 is primarily designed for controlling voice calls, transferring CSD, fax and GPRS data and for controlling the GSM engine with AT commands.
- Full Multiplex capability allows the interface to be partitioned into three virtual channels, but with CSD and fax services only available on the first logical channel. Please note that when the ASC0 interface runs in Multiplex mode, ASC1 cannot be used.
- The DTR0 signal will only be polled once per second from the internal firmware of MTX-3G-JAVA.
- The RING0 signal serves to indicate incoming calls and other types of URCs (Unsolicited Result Code). It can also be used to send pulses to the host application; for example, to wake the application up from the power saving mode. To configure the RING0 line, use the following AT Command: AT^SCFG.
- The default configuration is 8 data bits, no parity and 1 stop bit. The setting can be changed using the AT command AT+ICF and, if required, AT^STPB.
- ASC0 can be operated at fixed bit rates from 1200bps to 921600bps.
- **The default serial speed for MTX-3G-JAVA is 115200bps.**

4.4 DB15 connector: I/O expansion port

4.4.1 Connector pinouts

Depending on the specific modem you are using, the DB15 connector pinout will be different and there will be different resources available on it.



Common terminals available in all models

Pin	Signal	Direction	Description
1	I2CCLK	Output	I2C clock signal
2	DOM		
3	DOM		
4	DOM		
5	DOM		
6	I2CDAT	I/O	I2C data line
7	DOM		
8	DOM		
9	DOM		
10	DOM		
11	DOM		
12	DOM		
13	DOM		
14	GND		Ground connection
15	ADC 1	Input	Analog to Digital converter input 1

DOM: depending on model

Base MTX-3G-JAVA

Pin	Signal	Direction	Description
1	I2CCLK	Output	I2C clock signal
2	RD 1	Output	Secondary RS232 ASC1 UART signal: Received data
3	TD 1	Input	Secondary RS232 ASC1 UART signal: Transmitted data
4	GPIO 1	I/O	CMOS General Purpose Digital Input/Output 1
5	GPIO 3	I/O	CMOS General Purpose Digital Input/Output 3
6	I2CDAT	I/O	I2C data line
7	RTS 1	Input	Secondary RS232 ASC1 UART signal: Request to send
8	CTS 1	Output	Secondary RS232 ASC1 UART signal: Clear to send
9	VEXT	Output	Output voltage reference (3V)
10	DAC_OUT	Output	Digital to Analog converter
11	GPIO 2	I/O	CMOS General Purpose Digital Input/Output 2
12	GPIO 4	I/O	CMOS General Purpose Digital Input/Output 4
13	ADC 2	Input	Analog to Digital converter input 2
14	GND		Ground connection
15	ADC 1	Input	Analog to Digital converter input 1

ULP models

Pin	Signal	Direction	Description
1	I2CCLK	Output	I2C clock signal
2	RD 1	Output	Secondary RS232 ASC1 UART signal: Received data
3	TD 1	Input	Secondary RS232 ASC1 UART signal: Transmitted data
4	GPIO 1	I/O	CMOS General Purpose Digital Input/Output 1
5	GPIO 3	I/O	CMOS General Purpose Digital Input/Output 3
6	I2CDAT	I/O	I2C data line
7	RTS 1	Input	Secondary RS232 ASC1 UART signal: Request to send
8	CTS 1	Output	Secondary RS232 ASC1 UART signal: Clear to send
9	DAC_OUT	Output	Digital to Analog converter
10	VEXT	Output	Output voltage reference (3V)
11	GPIO 2	I/O	CMOS General Purpose Digital Input/Output 2
12	GPIO 4	I/O	CMOS General Purpose Digital Input/Output 4
13	GPIO 10	I/O	CMOS General Purpose Digital Input/Output 10
14	GND		Ground connection
15	ADC 1	Input	Analog to Digital converter input 1

ULP-GPS models

Pin	Signal	Direction	Description
1	I2CCLK	Output	I2C clock signal
2	NC		
3	NC		
4	GPIO 1	I/O	CMOS General Purpose Digital Input/Output 1
5	GPIO 3	I/O	CMOS General Purpose Digital Input/Output 3
6	I2CDAT	I/O	I2C data line
7	NC		
8	NC		
9	VEXT	Output	Output voltage reference (3V)
10	DAC_OUT	Output	Digital to Analog converter
11	GPIO 2	I/O	CMOS General Purpose Digital Input/Output 2
12	GPIO 4	I/O	CMOS General Purpose Digital Input/Output 4
13	ADC 2	Input	Analog to Digital converter input 2
14	GND		Ground connection
15	ADC 1	Input	Analog to Digital converter input 1

RS485 models

Pin	Signal	Direction	Description
1	I2CCLK	Output	I2C clock signal
2	RD 0	Output	Main RS232 ASC0 UART signal: Received data
3	TD 0	Input	Main RS232 ASC0 UART signal: Transmitted data
4	NC		
5	OUT 3	Output	Opto-isolated output GPIO8 (open collector)
6	I2CDAT	I/O	I2C data line
7	RTS 0	Input	Main RS232 ASC0 UART signal: Request to send
8	CTS 0	Output	Main RS232 ASC0 UART signal: Clear to send
9	IN 10	Input	Opto-isolated input GPIO10
10	VEXT	Output	Output voltage reference (4.1V)
11	IN 2	Input	Opto-isolated input GPIO7
12	OUT 4	Output	Opto-isolated output GPIO4 (open collector)
13	ADC 2	Input	Analog to Digital converter input 2
14	GND		Ground connection
15	ADC 1	Input	Analog to Digital converter input 1

GPS-BT models

Pin	Signal	Direction	Description
1	I2CCLK	Output	I2C clock signal
2	NC		
3	NC		
4	IO 1 (GPIO 9)	I/O	CMOS General Purpose Digital Input/Output 1
5	OUT 2	Output	Opto-isolated output GPIO8 (open collector)
6	I2CDAT	I/O	I2C data line
7	NC		
8	NC		
9	ADC 2	Input	Analog to Digital converter input 2
10	VEXT	Output	Output voltage reference (3.86V)
11	IN 2	Input	Opto-isolated input 2 GPIO7
12	OUT 3	Output	Opto-isolated output GPIO4 (open collector)
13	IN 3	Input	Opto-isolated input 3 GPIO10
14	GND		Ground connection
15	ADC 1	Input	Analog to Digital converter input 1

Rest of models

Pin	Signal	Direction	Description
1	I2CCLK	Output	I2C clock signal
2	RD 0	Output	Main RS232 ASC0 UART signal: Received data
3	TD 0	Input	Main RS232 ASC0 UART signal: Transmitted data
4	IO 1 (GPIO 9)	I/O	CMOS General Purpose Digital Input/Output 1
5	OUT 2	Output	Opto-isolated output GPIO8 (open collector)
6	I2CDAT	I/O	I2C data line
7	RTS 0	Input	Main RS232 ASC0 UART signal: Request to send
8	CTS 0	Output	Main RS232 ASC0 UART signal: Clear to send
9	ADC 2	Input	Analog to Digital converter input 2
10	VEXT	Output	Output voltage reference (3.86V)
11	IN 2	Input	Opto-isolated input 2 GPIO7
12	OUT 3	Output	Opto-isolated output GPIO4 (open collector)
13	IN 3	Input	Opto-isolated input 3 GPIO10
14	GND		Ground connection
15	ADC 1	Input	Analog to Digital converter input 1

4.4.2 RS232 interface

The modem supports a standard RS232 4-wire serial interface (EIA/TIA 574) via its 15 pin Sub-D connector, shown below. This interface is connected to the ASC0 port using a level shifter converter, except on the base MTX-3G-JAVA and MTX-3G-JAVA-ULP, which use an ASC1 port instead of ASC0.

The MTX-3G-JAVA modem is designed to be used as a DCE (data circuit-terminating equipment). Based on the conventions for DCE-DTE connections, it communicates with the customer application (DTE- data terminating equipment) using the following signals:

- Port TxD @ application sends data to MTX-3G-JAVA Terminal's TD.
- Port RxD @ application receives data from MTX-3G-JAVA Terminal's RD.

The RS-232 interface is implemented as a serial asynchronous transmitter and receiver conforming to ITU-T V.24 Interchange Circuits DCE. It is configured for 8 data bits, no parity and 1 stop bit and can be operated at fixed bit rates from 300bps to 460.8kbps.

Autobauding supports bit rates from 1.2kbps to 460.8kbps. Hardware handshake using the /RTS and /CTS signals and XON/XOFF software flow control are supported.

The electrical characteristics of the serial port signals are shown below:

Signal	Direction	Description
RD0	Output	Received data
TD0	Input	Transmitted data
GND	-	Ground connection
RTS	Input	Request to send
CTS	Output	Clear to send

Features (ASC1)

- Includes data lines TD1 and RD1 (2-wire/4-wire)
- Includes the status lines RTS0 and CTS0 and supports hardware flow control (4-wire only)
- On ASC1 no RING line is available. The indication of URCs on the second interface depends on the settings made with the AT^SCFG command.
- Configured for 8 data bits, no parity and 1 or 2 stop bits.
- ASC1 can be operated at fixed bit rates from 1200 bps to 921600 bps. Autobauding is not supported on ASC1.

Features (ASC0)

- Includes the data lines TD0 and RD0, the status lines RTS0 and CTS0 and also the modem control lines DTR0, DSR0, DCDD0 and RING0.
- ASC0 is primarily designed for controlling voice calls, transferring CSD, fax and GPRS data and for controlling the GSM engine with AT commands.
- Full Multiplex capability allows the interface to be partitioned into three virtual channels, but with CSD and fax services only available on the first logical channel. Please note that when the ASC0 interface runs in Multiplex mode, ASC1 cannot be used.
- The DTR0 signal will only be polled once per second from the internal firmware of MTX-3G-JAVA.
- The RING0 signal serves to indicate incoming calls and other types of URCs (Unsolicited Result Code). It can also be used to send pulses to the host application; for example, to wake the application up from the power saving mode. To configure the RING0 line, use the following AT Command: AT^SCFG.
- The default configuration is 8 data bits, no parity and 1 stop bit. The setting can be changed using the AT command AT+ICF and, if required, AT^STPB.
- ASC0 can be operated at fixed bit rates from 1200bps to 921600bps.
- **The default serial speed for MTX-3G-JAVA is 115200bps.**

4.4.3 I2C bus

I2C is a serial, 8-bit oriented data transfer bus for bit rates up to 400kbps in Fast mode. It consists of two lines, the serial data line I2CDAT and the serial clock line I2CCLK.

The MTX-3G-JAVA modem acts as a single master device, e.g. the clock I2CCLK is driven by the modem. I2CDAT is a bi-directional line.


Each device connected to the bus is software which is identified by a unique 7-bit address. Simple master/slave relationships exist at all times; the modem operates as a master-transmitter or as a master-receiver. The customer application transmits or receives data only at the modem's request.

Signal	Direction	Description
I2CCLK	Output	I2C bus clock signal ¹²³⁴
I2CDAT	I/O	I2C data bus ¹²³⁴
GND	-	Ground connection

1. 2C lines are Open Drain. Internal 10kOhm pull-up resistors are mounted, so there is no need to fit them to the host application.
2. According to the I2C Bus Specification Version 2.1, a maximum rise time of 300ns is permitted for the fast mode. There is also a maximum VOL=0.4V at 3mA specified.
3. The value of the pull-up depends on the capacitive load of the whole system (I2C Slave + lines). The maximum sink current of I2CDAT and I2CCLK is 4mA.
4. If lines are unused, keep pins open

Use the AT^SSPI command or Java class to configure and activate the I2C bus.

The picture below shows the I2C interface is powered from an internal VEXT supply line so the I2C interface will be properly shut down when the modem enters the Power-down mode.



4.4.4 Analog-to-Digital and Digital-to-Analog converters

The ADC/DAC of the MTX-3G-JAVA consists of two independent, unbalanced, multiplexed analog inputs as well as one unbalanced analog output, which can be used for measuring external DC voltages in the range of 0mV...+2988.3mV, or generate them in the same range. Both ADC and DAC have a resolution of 8 bits, which means that the voltage resolution in the given range is 11.71875mV.

The MTX-3G-JAVA has an internal ADC/DAC chip (PCF8591) connected to its I2C bus, at a 7-bit address 0x48 hexadecimal. Maximum bus frequency allowed is 100kHz.

The A/D converter uses the successive approximation conversion technique. The D/A converter and a high-gain comparator are used temporarily during the A/D conversion cycle.

The D/A converter consists of a resistor divider chain connected to the external reference voltage with 256 taps and selection switches. The tap-decoder switched one of these taps to the DAC output line. The analog output voltage is buffered by an auto-zeroed unity gain amplifier.

In order to release the DAC for an A/D conversion cycle the unity gain amplifier is equipped with a track and hold circuit. This circuit holds the output voltage while executing the A/D conversion.

You can configure and use the ADC/DAC converters by issuing I2C related AT commands or via the I2C Java class.

The maximum A/D and D/A conversion rate is given by the actual speed of the I2C bus.

You can find Java code examples in the *Downloads* section at www.mtxm2m.com

- **D/A conversion**

In order to write a new sample to the DAC buffer, you have to send three bytes over the I2C bus before sending the I2C STOP condition

1. Address byte (write mode): 0x90 hexadecimal
2. Control byte: 0x40 hexadecimal
3. Data byte: the 8-bit sample value in straight binary format

You can calculate the sample value you have to write to the D/A converter using the following expression:

$$D = \frac{256}{3} V_{DACOUT}$$

where D is the sample value in decimal format ($0 \leq D \leq 255$) and V_{DACOUT} is the voltage value you want to generate ($0 \leq V_{DACOUT} \leq 2988.3\text{mV}$)

- **A/D conversion**

In order to read samples from the ADC buffer, you have to send three bytes over the I2C bus before sending the I2C STOP condition


1. Address byte (write mode): 0x90 hexadecimal
2. Control byte:
 - a. 0x00 hexadecimal to read from ADC1
 - b. 0x01 hexadecimal to read from ADC2
3. Address byte (read mode): 0x91 hexadecimal
4. Dummy byte 1: 0x00 hexadecimal
5. Dummy byte 2: 0x10 hexadecimal

After that you should have three bytes in the I2C read buffer: the second one is the 8-bit sample value retrieved from the AD converter, in straight binary format.

You can calculate the voltage value from the A/D input using the following expression:

$$V_{ADC} = \frac{3}{256} D$$

where V_{ADC} is the voltage value present at the A/D converter input ($0 \leq V_{ADC} \leq 2988.3\text{mV}$) and D is the sample value in decimal format ($0 \leq D \leq 255$)



4.4.5 General Purpose and Optoisolated I/O

Depending on the model you use, you will dispose of the following set of GPIOs and Optoisolated IOs:

Model	Power Connector	DB15 connector
Base MTX-3G-JAVA & ULP models		4x CMOS inputs/outputs (bidirectional GPIO)
RS485 models		2x Optoisolated inputs 2x Optoisolated outputs
Rest of models	1x Optoisolated input 1x Optoisolated output	2x Optoisolated inputs 2x Optoisolated outputs 1x CMOS input/output (bidirectional GPIO)

Please refer to [Section 4.1](#) and [Section 4.4.1](#) to view the exact location of each I/O.

Both the GPIOs and Optoisolated I/Os are controlled by an internal I/O expander chip (TCA9535) attached to the I2C bus at a 7-bit address 0x20 hexadecimal. Please refer to the device datasheet or the Java code examples available at www.mtxm2m.com in the *Downloads* section, in order to learn how to use I/Os.

In the case of the Base MTX-3G-JAVA and ULP models, the GPIOs 1 to 4 are directly connected to the P00..P03 pins in the TCA9535 chip. You can configure them independently as inputs or outputs by issuing I2C related AT commands or via the I2C Java class.

For the RS485 models there are two optoisolated inputs and two optoisolated outputs available, which are mapped to TCA9535 pins as shown in the following table:


Terminal's optoisolated I/O	GPIO number	TCA9535 chip port
IN 2	GPIO 7	P06
IN 10	GPIO 10	P11
OUT 3	GPIO 8	P07
OUT 4	GPIO 4	P03

For the rest of models there are six optoisolated I/Os and one CMOS bidirectional I/O available, which are mapped to the TCA9535 chip pins as shown in the following table:

Terminal's optoisolated I/O	GPIO number	TCA9535 chip port
IO 1	GPIO 9	P10
IN 2	GPIO 7	P06
IN 3	GPIO 10	P11
IN 4	GPIO 5	P04
OUT 2	GPIO 8	P07
OUT 3	GPIO 4	P03
OUT 4	GPIO 6	P05


Please take care with the following points:

- Each GPIO port (Pxx port) can be configured as an input (Hi-Z) or output (strong drive push-pull drivers)
- Interrupt available, generated by any rising or falling edge of the port inputs in the input mode. This line is connected to GPIO8 of the EHS6 module.
- When optoisolated I/Os are available, you always must assure that:
 - RS485 models:
 - GPIO 4 and GPIO 8 are configured as outputs
 - GPIO 7 and GPIO 10 are configured as inputs
 - Rest of models:
 - GPIO 4, GPIO 6 and GPIO 8 are configured as outputs
 - GPIO 5, GPIO 7 and GPIO 10 are configured as inputs




*: see [Section 4.4.1](#) for exact location of pins in DB15 connector

The electrical equivalent circuits for GPIOs connected to the DB15 connector for all MTX-3G-JAVA family modems are shown in the following figure



GPIO equivalent circuit

The electrical equivalent circuits for MTX-3G-JAVA-RS485 models are shown in the following figure



Optoisolated inputs/outputs equivalent circuit


INPUT

$0V \leq V_{IN} \leq 2.5V \rightarrow \text{Logic '0'}$
 $2.7V \leq V_{IN} \leq 40V \rightarrow \text{Logic '1'}$

OUTPUT

Logic '0' $\rightarrow V_{OUT} = \text{HiZ}$
 Logic '1' $\rightarrow V_{OUT} = 1V (\text{max})$

The electrical equivalent circuits for all other models which have optoisolated input/outputs are shown in the following figures




Optoisolated IN/OUT 2&3 equivalent circuit

INPUT

$0V \leq V_{IN} \leq 2.5V \rightarrow \text{Logic '0'}$
 $2.7V \leq V_{IN} \leq 40V \rightarrow \text{Logic '1'}$

OUTPUT

Logic '0' $\rightarrow V_{OUT} = \text{HiZ}$
 Logic '1' $\rightarrow V_{OUT} = 1V (\text{max})$



Optoisolated IN/OUT 4 equivalent circuit

INPUT

$0V \leq V_{IN} \leq 1.1V \rightarrow \text{Logic '1'}$
 $1.5V \leq V_{IN} \leq 40V \rightarrow \text{Logic '0'}$

OUTPUT


Logic '0' $\rightarrow V_{OUT} = \text{HiZ}$
 Logic '1' $\rightarrow V_{OUT} = V_{IN} - 1V (\text{min})$

4.5 RS485 bus

A terminal block with a 5-way connector and shared Power Section, as shown and described below, is used to implement the RS485 interface

The RS485 bus is connected to the modem's ASC1 port using a level shifter converter.


It meets or exceeds the requirements of ANSI TIA/EIA-485-A.



Pin	Signal	Direction	Limits	Description
1	-RxB	I/O		RS485 B signal
2	+RxA	I/O		RS485 A signal
3	AUTO ON	Input	0-VIN	Automatic Restart after Shutdown Enable Signal
4	VIN	Input	6.5-40VDC	Positive power input
5	GND	Input		Negative power (ground)

4.6 GSM/GPRS/UMTS antenna connector


The antenna connector allows radio frequency (RF) transmission signals between the modem and an external customer-supplied antenna. The modem is fitted with a 50Ω, FME male coaxial jack.



The external antenna must be matched properly to achieve the best performance regarding radiated power, DC-power consumption, modulation accuracy and harmonic suppression.

4.7 SIM card reader

The MTX-3G-JAVA modem is fitted with a SIM card reader designed for 1.8V and 3V SIM cards. It is the flip-up type which is lockable in the horizontal position and is accessed through a removable panel as shown below.



The card holder is a five wire interface according to GSM 11.11. It has a SIM card detector switch to detect whether or not the SIM card drawer is inserted.

Removing and inserting the SIM card during operation requires the software to be reinitialized. Therefore, after reinserting the SIM card it is necessary to restart the MTX-3G-JAVA modem.

The full operation of the MTX-3G-JAVA relies on a SIM card being inserted. Some MTX-3G-JAVA functionality may be lost if you try to operate the control modem without a SIM card.

Applicable models:


[illegible]

Also, the device may be configured to generate an interrupt signal by inertial wake-up/free-fall events as well as by the position of the device itself. Thresholds and timing of interrupt generators are programmable by the user on the fly. This feature could be used by the MTX-3G-JAVA modem family to wake-up the GSM engine module from the sleep mode.

The LIS331DLM is connected to the EHS6 module via the internal I2C bus, at a 7-bit address 0x09 hexadecimal. You can configure and use it by issuing I2C related AT commands or via the I2C Java class.

Please refer to the device datasheet or the Java code examples available at www.mtxm2m.com in the *Downloads* section, in order to learn how to use I/Os.

In the following picture you can see how the accelerometer axes are located within the modem box.



4.9 Internal Li-Po battery

In the MTX-3G-JAVA modem family, the BAT suffix means that the internal 3.7V 1650mAh Li-Po battery is attached. The unit is shipped with the battery disconnected. Please open the unit and connect the battery connector to the main board and then plug in the power supply to the RJ power connector for around 5 hours to fully charge the battery.

Internal batteries can be ordered for MTX-3G-JAVA modems with either GPS or RF variants. In any case, you can ask to remove the GPS or RF.

The battery level can be known using the AT command `AT^SBV`. The command result is given in mV. When charging, the previous value is increased by +200mV. It is also possible to know whether the charger is connected by testing the DTR signal.


With the battery attached, the VEXT voltage value (DB15 connector, pin 10) is approximately 3.86V when the charger is plugged in. If not, this value drops to approximately 3.46V.

We do not guarantee fully working features for battery voltages below 3.6V. We strongly recommend that you switch the modem off completely when this occurs. To do this, please follow this procedure:

- Disable Automatic restart after shutdown. Please remember that this feature is active by default and so the modem will try to switch on again automatically
- Close all threads
- Close all sockets or internet services
- Call garbage collector
- Switch off modem using the `AT^SMSO` command

Note: the VEXT voltage will be only present when external power is applied (i.e. charging battery)

When the battery is attached, as “automatic restart” is featured by default, the modem will always be powered on and cannot be switched off. If you need to stop the Java application when Automatic Restart is enabled, you should press the switch button located near the SIM holder as shown in the picture below.




The duration of discharge depends on the end application. It is very sensitive to transmission (Voice and Data) so we recommend making as few as possible and keeping them as short as possible. Please disable GPS, or keep it in a low power mode when possible to extend battery life when longer periods of use (without charging) are required.

Keep in mind that the battery will be 100% operative once a few charge and discharge cycles have been performed.

Example 1. Li-Po battery attached, 25°C ambient temperature

**External power connected from 0:00 to 7:00 and only battery powered from 7:00 to 18:15.
JAVA application running and storing the GPS position on the flash storage every minute, and transmitting positions by GPRS every 10 minutes. Connected to the Movistar GPRS network.**



The blue colored circle shows when the battery is being charged. When it reaches 4.40V (to be checked using the AT^SBV command), the battery is fully charged (green colored circle). In the above example, charging time is 6 hours 30 minutes.


If the charger is disconnected, the battery starts to discharge. The duration of the battery is very dependent upon the applications used; in the example above, the battery lasts approximately 11 hours and 30 minutes. Please note that the minimum battery level module switches off automatically, when the battery voltage is around 3.65V (please remember to check using the AT^SBV command).

Example 2. Li-Po battery attached, 25°C ambient temperature

Example 2 has the same charging time (indicated by the blue arrow) as in example 1 (6 hours 30 minutes); at this time the battery is fully charged; checking using the AT^SBV command, we discover that it is around 4.40V (indicated by the green arrow).

Discharging time in these conditions is around 12 hours, so the more often you connect to GPRS, the shorter the battery will last. Keep GPRS connections short and infrequent where possible to extend battery life if you require longer periods of use without charging.

**External power connected from 0:00 to 7:00 and only battery powered from 7:00 to 20:00.
JAVA application running and storing the GPS position on the flash storage every five minutes,
and transmitting positions by GPRS every 30 minutes. Connected to the Movistar GPRS network.**



Note: there are two internal LEDs that provide information about the battery status:

- A red LED will illuminate when the battery is charging.
- A green LED will illuminate when external power is applied.

4.10 Real Time Clock

The EHS6 module attached to MTX-3G-JAVA modems contains a real time clock (RTC) to maintain accurate timekeeping and to enable you to “time stamp” messages.

This RTC is supplied by a separate voltage regulator which is also active when the MTX-3G-JAVA is in power down mode and the power supply VIN is available. An alarm function is provided that allows the MTX-3G-JAVA to wake up in Airplane mode without logging onto the GSM/UMTS network.

The MTX-3G-JAVA modems can also accommodate an independent battery or super-cap inside to maintain the date and time of the RTC when the power supply is disconnected. Both the battery and the super-cap will be charged when power supply is present again.

The size of the capacitor determines the duration of buffering when no voltage is applied to MTX-3G-JAVA; the larger the capacitor, the longer the date and time will be saved. A serial 1k Ω resistor placed on the board next to VDDL P limits the charged current of an empty capacitor or battery.

This capacitor is not fitted by default and must be ordered separately. Please contact gsm-support@matrix.es for more details.

4.10.1 ULP models

In addition to the module’s internal RTC, ULP modems have its own external low-power, battery operated RTC. The RTC used is a DS1337 connected to the module’s I2C bus at a 7-bit address 0x68 hexadecimal.

Please refer to the DS1337 datasheet for details about using the RTC. You can configure it using I2C related AT commands or via the I2C Java class. You can also contact gsm-support@matrix.es

You can program alarms to wake-up the modem at a specified date and time. Please refer to [Section 4.10](#) for more information about Ultra Low Power features.

4.11 Internal Hardware Watchdog

Applicable models:

MTX-3G-JAVA	
MTX-3G-JAVA-RS485	
MTX-3G-JAVA-RS485	X
MTX-3G-JAVA-BAT	X
MTX-3G-JAVA-GPS	X
MTX-3G-JAVA-GPS-BAT	X
MTX-3G-JAVA-GPS-BT	
MTX-3G-JAVA-ULP	
MTX-3G-JAVA-ULP-GPS	
MTX-3G-JAVA-ULP-WC25	X
MTX-3G-JAVA-WC25	X
MTX-3G-JAVA-WC500	X
MTX-3G-JAVA-BT	X
MTX-3G-JAVA-BLE	X
MTX-3G-JAVA-XBEE	X
MTX-3G-JAVA-868	X
MTX-3G-JAVA-900	X
MTX-3G-JAVA-WMBUS	X
MTX-3G-JAVA-WIFI	X

The MTX-3G-JAVA has a new internal hardware watchdog component which allows the module to be reset when the internal Java program is not refreshed in 120 ± 60 seconds, meaning that it has hang-ups or that it does not respond in this time.

The MTX-3G-JAVA has the watchdog disabled by default in the factory settings.

In order to use this watchdog, two GPIOs must be handled:

- GPIO1 (which must be configured as output) sets/resets watchdog. A logic '1' disables the watchdog functionality.
- GPIO2 (which must be configured as output) must change cycle in less than 120 seconds

To enable this feature, ask gsmsupport@matrix.es about our I2C-GPIO handling JAVA code or visit the Downloads section at www.mtxm2m.com

You can configure both the "Automatic Restart" and the "Watchdog" features in your Java routine source code using initialization code.

4.12 GPS

The MTX-3G-JAVA has an internal GPS receiver which offers the full performance of GPS technology. The GPS receiver continuously tracks all satellites in view, thus providing accurate satellite positioning data.

4.12.1 GPS antenna connector

The antenna connector allows for the transmission of radio frequency (RF) signals between the modem and an external customer-supplied antenna. The modem is fitted with a 50Ω, SMA F coaxial jack.

It is possible to connect active or passive GPS antennas. In either case they must have 50 Ohm impedance.



4.12.2 GPS application interface

The MTX-3G-JAVA has an internal GPS receiver which offers the full performance of GPS technology. The GPS receiver continuously tracks all satellites in view, thus providing accurate satellite positioning data.

The GPS receiver supports implemented NMEA protocols. It is able to recognize input messages from any of these protocols (e.g., GGA, RMC GSA, GSV) and respond to them accordingly. Input messages can be arbitrarily mixed.

The NMEA protocol is an industry standard protocol developed for marine electronics. It was originally designed to allow data exchange between various sensors and navigation equipment aboard ships. Nowadays, it is a de-facto standard for GPS receiver data output. For more information on the NMEA Standard please refer to www.nmea.org.

Venus8 offer special proprietary NMEA protocol for special features like AGPS or GPS antenna status: (connected/unconnected)

The GPS receiver can be software controlled using NMEA protocol. We recommend the use of Java code to read NMEA sentences.

The GPS receiver is connected to the EHS6 ASC1 port and NMEA data at 9600 bauds is present. JAVA code needs to open the ACS1 port and collect all these protocols and parses to calculate latitude and longitude positions.

There are also two signals available to control the RF card:

- RESET_GPS: active low, driven by GPIO12_P13 of the IO extender (see [section 4.4.5](#)). It allows the RF module to be reset.
- DISABLE_GPS: active low, driven by GPIO11_P12 of the IO extender (see [section 4.4.5](#)). It allows the RF module to be powered off.

To help all customers, Matrix Electronica provides “as is” (without further technical support, warranties, etc.) PARSER source code to improve the time to market in JAVA developing code.

4.12.3 GPS Parser (coming soon)

Matrix Electronica provides MTXParser3G for developing purposes at no cost.

MTXParser3G is JAVA source code which basically handles the GPS unit installed on the internal module and translates this into useful information such as positioning, as well as carrying out other useful features like:

- Obtaining GPS positioning in the same format as XT65
- A function to activate/deactivate AutoPowerON feature.
- A function to activate/deactivate/refresh the Hardware Watchdog feature.
- A function to read X,Y,Z acceleration values.
- A function to configure MTX-3G-JAVA-GPS and power up the alarm: after switching off, the modem will power UP when one axis (X, Y, Z) reaches the trigger acceleration value. Useful to save battery power consumption.
- A function to assist GPS (AGPS). Please ask gsmsupport@matrix.es
- A function to switch ON/OFF secondary red LED for user purposes.

MTXParser3G can be used as a library/example. We supply this code “as is”: this means that there will be no documentation, no further support will be provided and no warranties will be given regarding functionality. Matrix has tested it and uses it for internal purposes and customer support. It is not commercial software/code.

Please ask gsmsupport@matrix.es to obtain a free copy.

4.12.4 Power saving

Power saving can be enabled on the GSM part (using the AT+CFUN function). On the GPS receiver it is possible to use a special NMEA command. For more information on the AT command AT+CFUN, see the AT command manual.

For more information about the NMEA internal GPS module please ask gsmsupport@matrix.es

4.13 Wireless RF modules

MTX-3G-JAVA can be shipped with an internal RF card installed which allows for use with almost all protocols that exist nowadays, such as Bluetooth, WiFi, ISM, ZigBee, etc.

The RF card is connected to the internal ASC1 port. This means that models mounting an RF card, ASC1 will not be available to be used by the DB15 connector. There is, however, another signal available to control the RF card:

- RESET_RF: active low, driven by GPIO12_P13 of the IO extender (see [section 4.4.5](#)). This allows the RF module to be reset.

RF card modules can have internal or external antennas. In the case of modules mounting external antennas, an SMA Female connector will be available.

4.13.1 Bluetooth 2.1

It is based on a Bluegiga WT12, which is a next-generation, class 2, Bluetooth 2.1 + EDR module. By default WT12 is shipped with a powerful and easy-to-use iWRAP firmware. This firmware enables users to access Bluetooth functionality with simple ASCII commands delivered to the module over the ASC1 serial interface.

- Bluetooth Class 2 radio
- Integrated chip antenna
- Transmit power: 3dBm
- Receiver sensitivity: -86dBm
- Enhanced Data Rates (EDR) with data throughput up to 2-3Mbps
- Support for Adaptive Frequency Hopping (AFH) and 802.11 co-existence
- UART with bypass mode
- 8Mbits of flash memory
- Supported Bluetooth profiles: SPP, DUN, OBEX OPP, HFP v1.5, DID, and HID + HCI

You can find more information about using the module and how to communicate with it by consulting the module specific user manual available at [ftp.matrix.es](ftp://ftp.matrix.es) or by asking our engineers at gsm-support@matrix.es

4.13.2 Bluetooth Low Energy (4.0)

It is based on Bluegiga WT113, which is a Bluetooth Smart module targeted for small and low-power sensors and accessories. It integrates all the features required for a Smart application, including radio, software stack and GATT-based profiles. The BLE113 can also host end-user applications.

- Bluetooth 4.0 low energy radio
- Transmit power: 0dBm

- Receiver sensitivity: -93dBm
- Integrated antenna
- BGAPI host protocol
- BGScript programming for standalone applications
- Bluetooth Smart (low energy) support
- L2CAP, ATT, GTT, GAP and Security Manager
- Bluetooth Smart profiles
- Client and master mode
- 100kbps+ throughput
- Over-the-air firmware upgrade

You can find more information about using the module and how to communicate with it by consulting the module specific user manual available at <ftp.matrix.es> or by asking our engineers at gsm-support@matrix.es

4.13.3 Coronis Wavecard 25/500mW

It is based on Elster Coronis WCA868-OEM-25 (25mW output power) or WCA868-OEM-500 (500mW output power), which allows users to add Wavenis wireless functionality to their products. It can also be used in ad hoc networking for sensor network applications, smart objects, alarms and security, metering and more. The Wavecard is accessed via the ASC1 port of the internal EHS6 module

- Operates in license-free ISM 868MHz
- Typical data rate 9.6kbps
- Frequency Hopping Spread Spectrum (FHSS)
- GFSK modulation
- Single channel operation for narrowband applications (alarms)
- Point-to-Point and Point-to-Multipoint (broadcast, polling) modes and native repeater (up to 3 hops)
- Tree and star network topologies
- Supports asynchronous and synchronous modes
- EN300-220/FCC15.247 certified & compliant

You can find more information about using the module and how to communicate with it by consulting the module specific user manual available at <ftp.matrix.es> or by asking our engineers at gsm-support@matrix.es

4.13.4 ISM (868/900MHz)

This option is only available upon request. Please contact gsmsupport@matrix.es for further information.

4.13.5 WiFi

This option is only available upon request. Please contact gsmsupport@matrix.es for further information.

4.13.6 ZigBee

This option is only available upon request. Please contact gsmsupport@matrix.es for further information.

4.14 Custom GPS+RF modules

OEM customizations allow both GPS and RF modules to be mounted together within the same modem. In this case both the ASC0 and the ASC1 are connected to the RF and the GPS modules respectively, so they are not available at the DB9 and the DB15 connectors.

This is an optional feature that can be ordered only upon request. Please contact gsmsupport@matrix.es for more information.

4.15 Firmware updates

It is possible and sometimes necessary to update the MTX-3G-JAVA firmware.

Updates must be carried out by an approved technician.

Please contact gsmsupport@matrix.es for details regarding Service/Programming.

5. Operation

5.1 Switching on the modem. New “Automatic restart after shutdown” feature

There is no special way to turn the modem on: just apply power to the VIN terminal via a power connector (see [Section 4.1](#)). The modem will be fully operational after 4 to 9 seconds. Logging onto a network may take longer than this and is out of the modem's control.

The *Automatic Restart after Shutdown* feature is enabled as part of the default factory settings. This means that if/when the modem has to be switched off, due to a critical power supply, the modem will restart itself within a few seconds. This feature allows an application to be switched on all the time and also allows it to restart itself.

The *Automatic Restart after Shutdown* feature cannot be disabled in the base MTX-3G-JAVA and ULP models. In RS485 models there is an AUTO_ON terminal in the Power Connector (see [Section 4.1](#)) which allows for the enabling or disabling of this function. In all other models this feature can be disabled by software using GPIO3 and then you can switch on the modem with the TURN_ON pin at the power connector.

5.2 Switching off the modem

There are several ways to switch off (power down) the modem:

- Using the TURN_OFF pin (see [section 4.1](#) to see the terminals that use it). Continuously pressing the TURN_OFF pin (for at least 1 second) causes the modem to enter power down mode. Its use is not recommended except in an emergency. A delay of up to 10 seconds is experienced until the modem logs out of the network. The RTC stays active.
- AT^SMSO command: this allows the modem to log out of from the network and allows the software to enter into a secure state and save data before disconnecting the power supply. A delay of up to 10 seconds is experienced until the modem logs out of the network. The RTC stays active.
- In ULP models, the only way to switch off the modem and enter into the Ultra Low Power mode is to clean the input latches and execute the AT^SMSO command.

5.3 Ultra Low Power mode

MTX-3G-JAVA-ULP modems can enter into an Ultra Low Power mode. In this mode, all the board devices are disconnected from the power supply, except a little portion of digital logic and the RTC that allows the modem to exit from this mode and go back into the normal mode.

The first time the MTX-3G-JAVA-ULP modem is powered up, it will switch on normally. When an ULP modem enters in power down mode, you can wake up again in several ways:

- By **optoisolated inputs** (see [Section 4.1.3](#)): there are two active-high inputs and two active-low inputs allowing the modem to power up again.
- By the **RTC alarm** (see [Section 4.10](#)): you can configure the RTC to power on the modem at a specified date and time

It is possible to know if the modem has been woken up by inputs or the RTC alarm by reading the status latches with AT commands or the Java application.

WAKEUP input	GPIO number
Wake-up 1	GPIO 6
Wake-up 2	GPIO 7
Wake-up 3	GPIO 8
Wake-up 4	GPIO 9

Keep in mind that those inputs and the RTC can only be programmed when MTX-3G-JAVA-ULP is in normal mode.

The only way to enter in Ultra Low Power mode is to clean/reset the input latches and execute the AT^SMSO command.

5.4 Sleep mode

The modems that can disable the *Automatic Restart after Shutdown* feature are able to enter into a sleep mode. In this mode all the electronic systems are powered and enabled, but the GSM engine enters into a power down mode where only the module's internal RTC stays active (see [Section 4.10.1](#)).

To enter in Sleep mode, follow these steps:

1. Disable Automatic Restart after Shutdown
2. Use the AT^SMSO command to disconnect the modem from the cellular network and shutdown the modem

There are several ways to wake up the modem:

- Programming a time/date alarm in the module's internal RTC (AT+CALA command)
- Using TURN_ON signal at the power connector
- With an acceleration threshold interrupt from the internal accelerometer (see [Section 4.8](#))

5.5 Status LEDs

The MTX-3G-JAVA modem family has a bicolor status LED (green and red).

The green color LED is handled automatically by the modem and indicates its different operating modes, as shown in table below. The LED mode configuration is set by the AT^SLED command.

Terminal status	<mode>=1	<mode>=2 <flash>=default	<mode>=2 <flash>=user defined
<ul style="list-style-type: none"> GSM CS data call in progress or established GSM voice call in progress or established UMTS voice call in progress or established UMTS CS data call in progress 	Permanently ON	10ms ON 990ms OFF	<flash> ms ON 990 ms OFF
<ul style="list-style-type: none"> GSM PS data transfer UMTS data transfer 	Permanently ON	10ms ON 1990ms OFF	<flash> ms ON 1990 ms OFF
<ul style="list-style-type: none"> ME registered to a network. No call, no data transfer 	Permanently ON	10ms ON 1990ms OFF	<flash> ms ON 3990 ms OFF
<ul style="list-style-type: none"> Limited Network Service (e.g. no SIM, no PIN or during network search) 	500ms ON 500ms OFF	10ms ON 990ms OFF	<flash> ms ON 990 ms OFF

The red color LED (not available in ULP modes) is connected to the GPIO5 in the base MTX-3G-JAVA modem and 485 models, and to the GPIO6 in all other models (shared with an OUT4 optoisolated output). This allows the user to define the functionality of this LED by issuing AT commands or through a Java embedded code (see [Section 4.4.5](#)).

6. AT command interpreter

After a successful installation of the EHS6 driver package, the physical USB interface of the modem is represented in the operating system by two virtual interfaces, each assigned to a virtual COM port of its own:

- **Modem interface:**

This interface is referred to as "Modem" if queried using the AT^SQPORT command. In the quick reference tables it is named USB0-MDM.

The Modem interface is intended particularly for data transmission (UMTS or GPRS).

All URCs are normally issued on the Application interface. URCs related to data calls (RING, NO CARRIER) as well as the ^SYSSTART URC are issued on the Modem interface.

- **Application interface:**

This interface is referred to as "Application" if queried using the AT^SQPORT command. In the quick reference tables it is named USB0-APP.

The Application interface is designed especially for controlling the MTX-3G-JAVA, i.e. for entering AT commands, receiving URCs, or sending and receiving short messages. It cannot be used as a data interface for UMTS, or GPRS.

Please note that URCs are normally indicated only on this interface, no matter whether the Modem interface or the Application interface was used to send the AT commands to activate their presentation. This URC management scheme is the default configuration recommended for a typical MTX-3G-JAVA application.

Bear in mind that the Modem interface and the Application interface are handled by the same AT command interpreter.


As a result, AT commands entered on both interfaces are not executed in parallel but sequentially, one after the other. So, an AT command issued on one interface will be buffered on this interface to be executed after the other interface has completed processing earlier AT command(s).

When a data connection is established over the Modem interface, the Application interface can be used simultaneously for any control functions. This eliminates the need for the user to enter AT commands, such as +++ and ATO, as well as switching back and forth between command and online mode when working on one interface only.

See the MTX-3G-JAVA Quick Start guide for a complete step by step installation process.

7. Embedded applications

The MTX-3G-JAVA can embed an internal application written in popular JAVA language. Java technology and several peripheral interfaces on the modem allow you to easily integrate your application. This way, the customer application can be reduced because all the resources (Microcontroller, Flash & RAM memory and all kind of I/O and bus peripheral) can be used by the customer. This solution saves the external intelligence with all the associate costs and also saves space and power consumption.



Features:

- Oracle Java ME Embedded 3.2 Compliant to CLDC 1.1 HI (JSR139) and IMP-NG (JSR228) Java standards.
- Capable of running multiple MIDlets in parallel with inter-MIDlet communication.
- Additional Java standard APIs:
 - JSR75 (FileConnection)
 - JSR177 (CRYPTO)
 - JSR280 (XML)
- Additional Java proprietary APIs:
 - AT Command API
 - Watchdog API
- Additional accessible periphery for Java applications
 - I/O pins- I2C Interface, SPI interface, DAC,ADC
 - Serial interfaces (API): (ASCO, ASC1, USB*) can be used to connect external devices
- Memory space for Java programs:
 - Flash File System: around 8 MB
 - RAM: around 6MB
 - Just-in-Time Compiler execution optimization
- Over-the-air update
 - Application SW: OTAP
 - Firmware: FOTA (OMA compliant)


Ask gsmsupport@matrix.es for application notes and a free Cinterion SDK (Software Development Kit); we will provide Matrix FTP server to download it.

7.1 MTX-Tunnel software application

If you are not a JAVA expert and you do not have experts on hand in your company, we have a readily compiled JAVA code which fits into 99% of M2M applications: MTX-TUNNEL. This is optional and must be ordered separately.


MTX-TUNNEL is an application running in the GSM/GPRS/UMTS modems and is based on the Cinterion EHS6 module which is designed for communicating with remote devices that have RS232/I2C ports.


Frequently, remote meters, network switches, routers or other devices need to connect to the network, but they only have an RS232 port and the only possible way to reach them is using the GSM/GPRS Network. MTX-TUNNEL is ready-to-go solution for such cases.



It acts as a transparent RS232 port. You will see your remote devices as if they were directly connected to the computer.

MTX-TUNNEL V8 has extra features like WebServer, SMS telemetry, Telnet, DNS, ModBus and Gateway RF.





```

C:\> Telnet mtxtunnel.dyndns.org
#login:admin
#password:1234
Welcome to MTXTunnel
#AT
AT
OK
#ATI
ATI
Cinterion
TC65i
REVISION 01.100

OK
#AT+CSQ
AT+CSQ
+CSQ: 27,99

OK
#_

```

Features:

- GPRS-SERIAL TUNNEL
 - TCP Client
 - TCP Server
 - UDP Client / Server
- GPRS connection modes:
 - Permanent mode
 - Upon request (SMS or missed calls, authorized or blocked phone numbers)
 - Change on an input digital level
 - An analog input is out of the selected level window (MIN, MAX)
 - Serial data present on RS232/RS485 port
 - Scheduled date/hour timing
- WebServer
- Telnet
- SMS Alarms and Output control
- IPs dynamic resolution:
 - DynDNS
 - Private DNS
 - SMS
- SSL Security
- Firewall IP
- User API
- Telemetry (GPIOs and GPS)
- Serial RS232/485 – HTTP tunnel
- Serial RS232/485 – SMS tunnel
- Timing synchronization
- ModBus
- RF Gateway

8. Safety and product care

Please read the information in this section and the information in “Installation of the Modem”, before starting your integration work!

8.1 Safety instructions

PLEASE READ THESE SAFETY INSTRUCTIONS AND KEEP A COPY OF THEM

- Always ensure that use of the modem is permitted. The modem may present a hazard if used in proximity to personal electronic medical devices. As a rule, the modem must not be used in hospitals, airports or planes.
- Never use the modem at a gas station, refuelling point, blasting area or in any other environment where explosives may be present.
- Operating the modem close to other electronic devices, such as antennas, television sets, and radios may cause electromagnetic interference.
- This product is intended to be used with the antenna or other radiating element at least 20cm away from any part of the human body. In applications where this rule cannot be applied, the application designer is responsible for providing the SAR measurement test report and declaration.
- You are responsible for observing your country's safety standards, and where applicable, the relevant wiring rules.

8.2 General precautions

The MTX-3G-JAVA Terminal as a standalone item is designed for indoor use only. For outdoor use it must be integrated into a weatherproof enclosure. Do not exceed the environmental and electrical limits as specified in “Technical Data”.

- Avoid exposing the modem to lighted cigarettes, naked flames or to extreme hot or cold temperatures.
- Never try to dismantle the modem yourself. There are no components inside the modem that can be serviced by the user. If you attempt to dismantle the modem, you may invalidate the warranty.
- The MTX-3G-JAVA Terminal must not be installed nor located in areas where the surface temperature of the plastic case could exceed 85°C.

- In order to provide strain relief and to avoid transmitting excessive vibration to the modem during installation, all cables connected to the MTX-3G-JAVA Terminal must be secured or clamped immediately adjacent to the modem's connectors.
- To protect the power supply cables, and in order to comply with fire safety requirements, when the unit is powered from a battery or a high current supply, a fast 1.25A fuse should be connected in line with the positive supply.
- Any incompatible components or products must not be connected to the MTX-3G-JAVA modem.

Note! MTX-3G-JAVA distributors and sales offices may refuse warranty claims where evidence of product misuse is found.

8.3 SIM card precautions

Before handling the SIM card in your application, ensure that you are not charged with static electricity. Use proper precautions to avoid electrostatic discharges.

- When the SIM card hatch is opened, the SIM card connectors lie exposed under the SIM card holder.

Caution! Do not touch these connectors! If you do, you may release an electrical discharge that could damage the modem or the SIM card.

- When designing your application, the SIM card's accessibility should be taken into account. We always recommend that you have the SIM card protected by a PIN code. This will ensure that the SIM card cannot be used by an unauthorized person.

8.4 Antenna precautions

If the antenna is to be mounted outside, consider the risk of lightning. Follow the instructions provided by the antenna manufacturer.

- Never connect more than one modem to a single antenna. The modem can be damaged by radio frequency energy from the transmitter of another modem.
- Like any mobile station, the antenna of the modem emits radio frequency energy. To avoid EMI (electromagnetic interference), you must determine whether the application itself, or equipment in the application's proximity, needs further protection against radio emission and the disturbances it might cause. Protection is secured either by shielding the surrounding electronics or by moving the antenna away from the electronics and the external signal cable.

- The modem and antenna may be damaged if either come into contact with ground potentials other than the one in your application. Beware: ground potentials are not always what they appear to be.

8.5 Radio Frequency (RF) exposure and SAR

Your wireless modem device is a low-power radio transmitter and receiver (transceiver). When it is turned on, it emits low levels of radio frequency energy (also known as radio waves or radio frequency fields).

Governments around the world have adopted comprehensive international safety guidelines, developed by scientific organizations such as ICNIRP (International Commission on Non-Ionizing Radiation Protection) and IEEE (The Institute of Electrical and Electronics Engineers Inc.), through periodic and thorough evaluation of scientific studies. These guidelines establish permitted levels of radio wave exposure for the general population. The levels include a safety margin designed to assure the safety of all persons, regardless of age and health, and to account for any variations in measurements.

Specific Absorption Rate (SAR) is the unit of measurement for the amount of radio frequency energy absorbed by the body when using a transceiver. The SAR value is determined at the highest certified power level in laboratory conditions, but the actual SAR level of the transceiver while operating can be well below this value. This is because the transceiver is designed to use the minimum power required to reach the network.

The MTX-3G-JAVA wireless modem device has been approved for applications where the antenna is located more than 20cm from the body. In all other configurations **the user** is responsible for meeting the local SAR regulations.

Users of the MTX-3G-JAVA wireless modem device are responsible for ensuring that they meet the SAR regulatory requirements of the countries in which they intend to operate the device and that their documentation contains the relevant SAR declaration, certification information and user guidance as appropriate.

8.6 Personal medical devices

Wireless modem devices may affect the operation of cardiac pacemakers, hearing aids and certain other implanted equipment. If a minimum distance of 15 cm (6 inches) is maintained between the MTX-3G-JAVA modem radiating antenna and a pacemaker, the risk of interference is limited. If the user's application is likely to be situated in the vicinity of personnel, a suitable warning should be contained in the equipment manual to this effect.

9. Modem installation

This chapter gives you advice and helpful hints on how to integrate the MTX-3G-JAVA Terminal into your application from a hardware perspective.

9.1 Where to install the modem

There are several conditions which need to be taken into consideration when designing your application as they might affect the modem and its function. They are:

9.1.1 Environmental conditions

The modem must be installed so that the environmental conditions stated in the Technical Data chapter such as temperature, humidity and vibration are satisfied.

Additionally, the electrical specifications in the Technical Data section must not be exceeded.

9.1.2 Signal strength

The modem has to be placed in a way that ensures sufficient signal strength. To improve signal strength, the antenna can be moved to another position. Signal strength may depend on how close the modem is to a radio base station. You must ensure that where you intend to use the modem is within the network coverage area. Degradation in signal strength can be the result of disturbance from another source; for example, an electronic device in the immediate vicinity. More information about possible communication disturbances can be found in [section 9.3.5](#).

When an application is completed, you can verify the signal strength by issuing the AT command AT+CSQ.

Tip! Before installing the modem, use an ordinary mobile telephone to check a possible location for it. In determining the location for the modem and antenna, you should consider signal strength as well as cable length.

9.1.3 Connections of components to MTX-3G-JAVA Terminal

The user is responsible for the final integrated system. If not correctly designed or installed, external components may cause radiation limits to be exceeded. For instance, improperly made connections or improperly installed antennas can disturb the network and lead to malfunctions in the modem or equipment.

9.1.4 Network and subscription

Before your application is used, you must ensure that your chosen network provides the necessary telecommunication services. Contact your service provider to obtain the necessary information.

- If you intend to use SMS in the application, ensure this is included in your (voice) subscription.
- Consider the choice of supplementary services

9.2 How to install the modem

9.2.1 Power supply

Use a high-quality power supply cable with low resistance. This ensures that the voltages at the connector pins are within the allowed range, even during the maximum peak current.

When the unit is powered from a battery or a high current supply, connect a fast 1.25A fuse in line with the positive supply. This protects the power cabling and modem.

9.2.2 Securing the modem

Before securing the modem take into account the amount of additional space required for the mating connectors and cables that will be used in the application.

- Where access is restricted, it may be easier to connect all the cables to the modem prior to securing it in the application.
- Securely attach the MTX-3G-JAVA Terminal modem to the host application using two 3mm diameter pan-head screws

9.3 Antenna

9.3.1 General

The antenna is the component in your system that maintains the radio link between the network and the modem. Since the antenna transmits and receives electromagnetic energy, its efficient function will depend on:

- The type of antenna (for example, circular or directional);
- The placement of the antenna;
- Communication disturbances in the vicinity in which the antenna operates.

In the sections below, issues concerning antenna type, antenna placement, antenna cable, and possible communication disturbances are addressed. In any event, you should contact your local antenna manufacturer for additional information concerning antenna type, cables, connectors, antenna placement, and the surrounding area.

You should also determine whether the antenna needs to be grounded or not. Your local antenna manufacturer might be able to design a special antenna suitable for your application.

9.3.2 Antenna type

Make sure that you choose the right type of antenna for the modem. Consider the following requirements:

- The antenna must be designed for one of the frequency bands in use; please ask your network provider for more information:
 - UMTS 800/850/900/1900/2100 MHz
 - GSM 850/900/1800/1900 MHz
- The impedance of the antenna and antenna cable must be 50Ω;
- The antenna output-power handling must be a minimum of 2W

9.3.3 Antenna placement

The antenna should be placed away from electronic devices and other antennas. The recommended minimum distance between adjacent antennas, operating in a similar radio frequency band, is at least 50cm. If the signal strength is weak, it is useful to face a directional antenna towards the closest radio base station. This can increase the strength of the signal received by the modem. The modem's peak output power can reach 2W.

RF field strength varies with antenna type and distance. At 10cm from the antenna the field strength may be up to 70V/m and at 1m it will have reduced to 7V/m. In general, CE-marked products for residential /commercial areas and the light industry can withstand a minimum of 3V/m.

9.3.4 The antenna cable

Use 50Ω impedance low-loss cable and high-quality 50Ω impedance connectors (frequency range up to 3GHz) to avoid RF losses. Ensure that the antenna cable is as short as possible. The Voltage Standing-Wave Ratio (VSWR) may depend on the effectiveness of the antenna, cable and connectors. In addition, if you use an adaptor between the antenna cable and the antenna connector, it is crucial that the antenna cable is a high-quality, low-loss cable. Minimize the use of extension cables, connectors and adapters. Each additional cable, connector or adapter causes a loss of signal power.

9.3.5 Possible communications disturbances

Possible communication disturbances include the following:

- **Noise** can be caused by electronic devices and radio transmitters.
- **Path-loss** occurs as the strength of the received signal steadily decreases in proportion to the distance from the transmitter.
- **Shadowing** is a form of environmental attenuation of radio signals caused by hills, buildings, trees or even vehicles. This can be a particular problem inside buildings, especially if the walls are thick and reinforced.
- **Multi-path fading** is a sudden decrease or increase in the signal strength. This is the result of interference which is caused when direct and reflected signals reach the antenna simultaneously. Surfaces such as buildings, streets, vehicles, etc., can reflect signals.
- **Hand-over** occurs as you move from one cell to another in the GSM network. Your mobile application call is transferred from one cell to the next. Hand-over can briefly interfere with communication and may cause a delay, or at worst, disruption.

10. Conformity assessment

MATRIX ELECTRONICA S.L.U.
C/ Alejandro Sanchez 109
28019 Madrid
Spain

10.1 Standards of European Type Approval

We declare under our sole responsibility that the products MTX-3G-JAVA Terminal 0 containing Cellular Engine Cinterion engine EHS6 (Type L30960-N2950-A100), to which this declaration relates, are labeled with the CE conformity mark.

DIRECTIVE 2004/108/EC OF THE EUROPEAN PARLIAMENT AND OF THE COUNCIL of 15 December 2004 on the approximation of the laws of the Member States relating to electromagnetic compatibility and repealing Directive 89/336/EEC.

DIRECTIVE 2006/95/EC OF THE EUROPEAN PARLIAMENT AND OF THE COUNCIL of 12 December 2006 on the harmonization of the laws of Member States relating to electrical equipment designed for use within certain voltage limits.

ETSI EN 301 511 V9.0.2: Global System for Mobile communications (GSM); Harmonized standard for mobile stations in the GSM 900 and DCS 1800 bands covering essential requirements under article 3.2 of the R&TTE directive (1999/5/EC) (GSM 13.11 version 7.0.1 Release 1998).

ETSI EN 301 489-1 V1.9.2: Electro Magnetic Compatibility and Radio spectrum Matters (ERM); Electro Magnetic Compatibility (EMC) standard for radio equipment and services; Part 1: Common Technical Requirements

ETSI EN 301 489-7 V1.3.1: Electromagnetic Compatibility and Radio spectrum Matters (ERM); Electromagnetic Compatibility (EMC) standard for radio equipment and services; Part 7: Specific conditions for mobile and portable radio and ancillary equipment of digital cellular radio telecommunications systems (GSM and DCS).

ETSI EN 301 489-24 V1.5.1: Electromagnetic Compatibility and Radio spectrum Matters (ERM); Electromagnetic Compatibility (EMC) standard for radio equipment and services; Part 24: Specific conditions for IMT-2000 CDMA Direct Spread (UTRA) for Mobile and portable (UE) radio and ancillary equipment.

ETSI EN 301 908-01 V5.2.1: Electromagnetic compatibility and Radio spectrum Matters (ERM); Base Stations (BS) and User Equipment (UE) for IMT-2000 Third Generation cellular networks; Part 1: Harmonized EN for IMT-2000, introduction and common requirements of article 3.2 of the R&TTE Directive.


ETSI EN 301 908-02 V5.2.1: Electromagnetic compatibility and Radio spectrum Matters (ERM); Base Stations (BS) and User Equipment (UE) for IMT-2000 Third Generation cellular networks; Part 2: Harmonized EN for IMT-2000, CDMA Direct Spread (UTRA FDD) (UE) covering essential requirements of article 3.2 of the R&TTE Directive

IEC/EN 60950-1:2005 / EN 60950-1:2006+A11:2009: Health and Safety

The technical documentation relevant to the above equipment will be held at
MATRIX ELECTRONICA S.L.U.

Alejandro Sanchez 109
28019 Madrid
Spain

Madrid, 20/05/2013.
Mr. J. Vicente
Managing Board



10.2 PTCRB approval



PTCRB is the regional approval needed in North American Market.

MTX-3G-JAVA is now PTCRB Certified:

Request #: 39216

Manufacturer: Matrix Electronica

Model #: MTX-3G-JAVA

Technologies and Frequency Bands: GSM 850/900/1800/1900, UMTS FDD: Band I/Band II/Band V/Band VIII

FCCID: QIPEHS6

Industry Canada #: 7830A-EHS6

IMEI TAC: 35888405

Hardware Version: 1.12

Software Version: 02.000

SVN: 08

NAPRD.03 Version: GSM Test: 5.15/OTA Performance Test: 5.15

10.3 FCC Compliant

MTX-3G-JAVA and any variants contain FCC ID: QIPEHS6. The FCC Equipment Authorization Certification for the EHS6 Module is listed under the FCC identifier QIPEHS6
Industry Canada Certification Number: 7830A-EHS6 granted to Gemalto M2M GmbH.

The Cinterion reference application of the EHS6 Module registered under the above identifier is certified to be in accordance with the following Rules and Regulations of the Federal Communications Commission (FCC). Power listed is ERP for Part 22 and EIRP for Part 24. It is compliant with FCC regulations.

Equipment class: PCS Licensed Transmitter

Notes: Quad band GSM/GPRS Modem

10.3.1 SAR information

Cinterion Wireless Modules models: EHS6 is marketed without a defined antenna.

The Maximum Antenna Gain when using indoor antennas depends on the distance from the antenna to any nearby persons when in normal operation. It should not exceed the values shown on the table below.

According to the limit in 47 CFR 1.1310, we get the value of the maximum antenna gain as follows:

The maximum measured power output in the 850 MHz band is 1866.38 mW (32.71 dBm, see 7layers test report MDE_Siem_0714_FCCb).

The maximum permissible exposure is defined as 47 CFR 1.1310 with 0.55773 mW/cm².

The maximum measured power output in the 1900 MHz band is 974.99 mW (29.89 dBm, see 7layers test report MDE_Siem_0714_FCCc).

The maximum permissible exposure is defined as 47 CFR 1.1310 with 1 mW/cm².

According to the limit in 47 CFR 1.1310, we get the value of the maximum antenna gain as follows:

$$S = P \cdot G / 4\pi R^2$$

$$S = 0.55773 \text{ mW/cm}^2 \text{ or } 1 \text{ mW/cm}^2$$

$$P = 1866.38 \text{ mW or } 974.99 \text{ mW}$$

$$R = 20 \text{ cm or } 100 \text{ cm}$$

$$\pi = 3.1416$$

$$G(\text{dBi}) = 10 \cdot \log_{10}(G)$$

Solving for G; the maximum antenna gain is

Band	Distance	Maximum Gain in dBi
850MHz	20cm	1.7669
850MHz	50cm	9.7257
1900MHz	20cm	7.1227
1900MHz	50cm	15.0815

10.4 AT&T certification

AT&T performed applicable testing on the MTX-3G-JAVA. This includes testing for:

- Negative impacts on AT&T's wireless network
- Baseline regulatory confirmation
- RF testing against components in the wireless AT&T network
- Network selection testing

The MTX-3G-JAVA device was not observed to cause any adverse problems to the AT&T network when activated and used in the lab. The MTX-3G-JAVA is certified for both CS and PS services (as applicable). Any change to the mode of operation invalidates the AT&T Certification

11. Declaración de conformidad (Spanish)

MATRIX ELECTRONICA S.L.U.

C/ Alejandro Sanchez 109

28019 Madrid

Spain

11.1 Estándares de homologación europea

Declaramos bajo nuestra responsabilidad que los productos MTX-3G-JAVA que contienen un modulo celular Cinterion EHS6 (tipo L30960-N2950-A100), al cual se refiere esta declaración, están etiquetados con el marcado CE de conformidad.

DIRECTIVA 2004/108/EC DEL PARLAMENTO EUROPE Y DEL CONSEJO del 15 de Diciembre de 2004 sobre la aproximación de las leyes de los Estados Miembros correspondientes a la compatibilidad electromagnética y que deroga la Directiva 89/336/EEC.

DIRECTIVA 2006/95/EC DEL PARLAMENTO EUROPE Y DEL CONSEJO del 12 de Diciembre de 2006 sobre la armonización de las leyes de los estados miembros relacionadas con los equipos eléctricos diseñados para su uso bajo ciertos límites de voltaje.

ETSI EN 301 511 V9.0.2: Sistema Global de Comunicaciones Móviles (GSM); estándar unificado para estaciones móviles en las bandas GSM 900 y DCS 1800, que cubren los requisitos esenciales del artículos 3.2 de la directiva R&TTE (1999/5/EC) (GSM 13.11 versión 7.0.1 Release 1998).

ETSI EN 301 489-1 V1.9.2: Cuestiones sobre Compatibilidad Electromagnética y espectro Radioeléctricos (ERM); estándar de compatibilidad electromagnética (EMC) para equipos y sistema de radio; Parte 1: Requisitos Técnicos Comunes

ETSI EN 301 489-7 V1.3.1: Cuestiones sobre Compatibilidad Electromagnética y espectro Radioeléctricos (ERM); estándar de compatibilidad electromagnética (EMC) para equipos y sistema de radio; Parte 7: Condiciones específicas para equipos de radio móviles y portátiles y equipos auxiliares de sistemas de radiocomunicaciones móviles digitales (GSM y DCS).

ETSI EN 301 489-24 V1.5.1: Cuestiones sobre Compatibilidad Electromagnética y espectro Radioeléctricos (ERM); estándar de compatibilidad electromagnética (EMC) para equipos y sistema de radio; Parte 24: Condiciones específicas para IMT-2000 CDMA Direct Spread (UTRA) para radios móviles y portátiles (UE) y equipamiento auxiliar.

ETSI EN 301 908-01 V5.2.1: Cuestiones sobre Compatibilidad Electromagnética y espectro Radioeléctricos (ERM); estaciones base (BS) y equipamiento de usuario (UE) para redes celulares IMT-2000 de tercera generación; Parte 1: Normativa europea armonizada para IMT-2000, introducción y requisitos comunes del artículo 3.2 de la directiva R&TTE.

ETSI EN 301 908-02 V5.2.1: Cuestiones sobre Compatibilidad Electromagnética y espectro Radioeléctricos (ERM); estaciones base (BS) y equipamiento de usuario (UE) para redes celulares IMT-2000 de tercera generación; Parte 2: Normativa europea armonizada para IMT-2000, CDMA Direct Spread (UTRA FDD) (UE) que cubre los requisitos esenciales del artículo 3.2 de la directiva R&TTE

IEC/EN 60950-1:2005 / EN 60950-1:2006+A11:2009: Salud y Seguridad

La documentación técnica referente al equipo anterior está disponible en:

MATRIX ELECTRONICA S.L.U.

Alejandro Sanchez 109


28019 Madrid

España

Madrid, 20/05/2013.

Sr. J. Vicente

Managing Board



11.2 Aprobación PTCRB



PTCRB es un aprobado regional necesario en el mercado norteamericano.

MTX-3G-JAVA tiene la certificación PTCRB:

Solicitud #: 39216

Fabricante: Matrix Electronica

Modelo#: MTX-3G-JAVA

Tecnologías y bandas de frecuencias: GSM 850/900/1800/1900, UMTS FDD: Band I/Band II/Band V/Band VIII

FCCID: QIPEHS6

Industry Canada #: 7830A-EHS6

IMEI TAC: 35888405

Version Hardware: 1.12

Version Software: 02.000

SVN: 08

NAPRD.03 Version: GSM Test: 5.15/OTA Performance Test: 5.1

11.3 Conformidad FCC

MTX-3G-JAVA y todas sus variantes contienen el FCC ID: QIPEHS6. El Certificado de Autorización de Equipo de la FCC para el módulo EHS6 está listado con el identificador FCC QIPEHS6
Número de Certificación de Industria en Canadá: 7830A-EHS6 asignado a Gemalto M2M GmbH.

El formulario de referencia del módulo EHS6 registrado bajo el anterior identificador está conforme con las siguientes Reglas y Regulaciones de la Comisión Federal de Comunicaciones (FCC). La potencia listada como ERP para la parte 22 y como EIRP para la parte 24 cumple con las regulaciones de la FCC.

Clase de equipo: Transmisor PCS Licenciado

Notas: Quad band GSM/GPRS Modem

11.3.1 Tasa de absorción específica (SAR)

El modulo Cinterion EHS6 es comercializado sin una antena definida. La ganancia máxima de antena usando antenas de interior depende de la distancia de esta a las personas cercanas y en condiciones normales no debe sobrepasar los límites mostrados en la tabla siguiente.

La máxima potencia de salida medida en la banda de 850MHz es 1866.38 mW (32.71 dBm, ver el reporte de test de 7layers MDE_Siem_0714_FCCb).

La máxima exposición permisible se define en 47 CFR 1.1310 con un valor de 0.55773 mW/cm².

La máxima potencia de salida medida en la banda de 1900 MHz es 974.99 mW (29.89 dBm, ver el reporte de test de 7layers MDE_Siem_0714_FCCc).

La máxima exposición permisible se define en 47 CFR 1.1310 con un valor de 1 mW/cm².

De acuerdo al límite en 47 CFR 1.1310, obtenemos el valor de la máxima ganancia de antena como sigue:

$$S = P \cdot G / 4\pi R^2$$

$$S = 0.55773 \text{ mW/cm}^2 \text{ o } 1 \text{ mW/cm}^2$$

$$P = 1866.38 \text{ mW o } 974.99 \text{ mW}$$

$$R = 20 \text{ cm o } 100\text{cm}$$

$$\pi = 3.1416$$

$$G(\text{dBi}) = 10 \cdot \log_{10}(G)$$

Despejando G; la máxima ganancia de antena es:

Banda	Distancia	Ganancia Máxima en dBi
850MHz	20cm	1.7669
850MHz	50cm	9.7257
1900MHz	20cm	7.1227
1900MHz	50cm	15.0815

11.4 Certificación AT&T

AT&T ha realizado los test aplicables al terminal MTX-3G-JAVA. Esto incluye las siguientes comprobaciones:

- Impactos negativos en la red inalámbrica de AT&T
- Confirmación del cumplimiento de la normativa básica aplicable
- Prueba de RF contra los distintos components usados en la red de AT&T
- Prueba de selección de red

El dispositivo MTX-3G-JAVA no ha evidenciado ni causado ningún tipo de problema en la red de AT&T cuando ha sido activado y utilizado en el laboratorio. El MTX-3G-JAVA está certificado para servicios CS y PS. Cualquier cambio en el modo de operación del equipo invalidará la certificación de AT&T.

12. Regulatory and type approval information

12.1 Directives and standards

The MTX-3G-JAVA modem has been designed to comply with the directives and standards listed below.

It is the responsibility of the application manufacturer to ensure compliance of the final product with all provisions of the applicable directives and standards, as well as with the technical specifications provided in this document.

Directives	
1999/05/EC	Directive of the European Parliament and of the council of 9 March 1999 on radio equipment and telecommunications terminal equipment and the mutual recognition of their conformity (in short referred to as R&TTE Directive 1999/5/EC). The product is labeled with the CE conformity mark
ECE-R 10	Economic Commission for Europe (ECE) Regulation No. 10: Uniform provisions concerning the approval of vehicles with regard to electromagnetic compatibility
2002/95/EC (RoHS 1) 2011/65/EC (RoHS 2)	Directive of the European Parliament and of the Council of 27 January 2003 (and revised on 8 June 2011) on the restriction of the use of certain hazardous substances in electrical and electronic equipment (RoHS)

Standards of North American type approval	
CFR Title 47	Code of Federal Regulations, Part 22 and Part 24 (Telecommunications, PCS); US Equipment Authorization FCC
OET Bulletin 65 (Edition 97-01)	Evaluating Compliance with FCC Guidelines for Human Exposure to Radiofrequency Electromagnetic Fields
UL 60 950-1	Product Safety Certification (Safety requirements)
NAPRD.03 V5.15	Overview of PCS Type certification review board Mobile Equipment Type Certification and IMEI control PCS Type Certification Review board (PTCRB)
RSS132 (Issue2) RSS133 (Issue5)	Canadian Standard

Standards of European type approval	
3GPP TS 51.010-1	Digital cellular telecommunications system (Release 7); Mobile Station (MS) conformance specification;
ETSI EN 301 511 V9.0.2	Global System for Mobile communications (GSM); Harmonized standard for mobile stations in the GSM 900 and DCS 1800 bands covering essential requirements under article 3.2 of the R&TTE directive (1999/5/EC)
GCF-CC V3.49	Global Certification Forum - Certification Criteria
ETSI EN 301 489-01 V1.9.2	Electromagnetic Compatibility and Radio spectrum Matters (ERM); Electromagnetic Compatibility (EMC) standard for radio equipment and services; Part 1: Common Technical Requirements
ETSI EN 301 489-07 V1.3.1	Electromagnetic Compatibility and Radio spectrum Matters (ERM); Electromagnetic Compatibility (EMC) standard for radio equipment and services; Part 7: Specific conditions for mobile and portable radio and ancillary equipment of digital cellular radio telecommunications systems (GSM and DCS)
ETSI EN 301 489-24 V1.5.1	Electromagnetic Compatibility and Radio spectrum Matters (ERM); Electromagnetic Compatibility (EMC) standard for radio equipment and services; Part 24: Specific conditions for IMT-2000 CDMA Direct Spread (UTRA) for Mobile and portable (UE) radio and ancillary equipment

EN 301 908-01 V5.2.1	Electromagnetic compatibility and Radio spectrum Matters (ERM); Base Stations (BS) and User Equipment (UE) for IMT-2000 Third Generation cellular networks; Part 1: Harmonized EN for IMT-2000, introduction and common requirements of article 3.2 of the R&TTE Directive
EN 301 908-02 V5.2.1	Electromagnetic compatibility and Radio spectrum Matters (ERM); Base Stations (BS) and User Equipment (UE) for IMT-2000 Third Generation cellular networks; Part 2: Harmonized EN for IMT-2000, CDMA Direct Spread (UTRA FDD) (UE) covering essential requirements of article 3.2 of the R&TTE Directive
EN 62311:2008	Assessment of electronic and electrical equipment related to human exposure restrictions for electromagnetic fields (0 Hz - 300 GHz)
IEC/EN 60950-1:2006+ A11:2009+A1:2010+ A12:2011	Safety of information technology equipment

Requirements of quality

IEC 60068	Environmental testing
DIN EN 60529	IP codes

Standards of the Ministry of Information Industry of the People's Republic of China

SJ/T 11363-2006	"Requirements for Concentration Limits for Certain Hazardous Substances in Electronic Information Products" (2006-06).
SJ/T 11364-2006	<p>"Marking for Control of Pollution Caused by Electronic Information Products" (2006-06).</p> <p>According to the "Chinese Administration on the Control of Pollution caused by Electronic Information Products" (ACPEIP) the EPUP, i.e., Environmental Protection Use Period, of this product is 20 years as per the symbol shown here, unless otherwise marked. The EPUP is valid only as long as the product is operated within the operating limits described in the Gemalto M2M Hardware Interface Description.</p> <p>Please see next table for an overview of toxic or hazardous substances or elements that might be contained in product parts in concentrations above the limits defined by SJ/T 11363-2006.</p>

部件名称 Name of the part	有毒有害物质或元素 Hazardous substances					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
金属部件 (Metal Parts)	○	○	○	○	○	○
电路模块 (Circuit Modules)	X	○	○	○	○	○
电缆及电缆组件 (Cables and Cable Assemblies)	○	○	○	○	○	○
塑料和聚合物部件 (Plastic and Polymeric parts)	○	○	○	○	○	○
<p>O: 表示该有毒有害物质在该部件所有均质材料中的含量均在SJ/T11363-2006 标准规定的限量要求以下。 Indicates that this toxic or hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in SJ/T11363-2006.</p> <p>X: 表示该有毒有害物质至少在该部件的某一均质材料中的含量超出SJ/T11363-2006标准规定的限量要求。 Indicates that this toxic or hazardous substance contained in at least one of the homogeneous materials used for this part <i>might exceed</i> the limit requirement in SJ/T11363-2006.</p>						

12.2 SAR requirements specific to portable mobiles

Mobile phones, PDAs or other portable transmitters and receivers incorporating a GSM module must be in accordance with the guidelines for human exposure to radio frequency energy. This requires the Specific Absorption Rate (SAR) of portable EHS6 based applications to be evaluated and approved for compliance with national and/or international regulations.

Since the SAR value varies significantly with the individual product design, manufacturers are advised to submit their product for approval if designed for portable use. For European markets the relevant directives are mentioned below. It is the responsibility of the manufacturer of the final product to verify whether or not further standards, recommendations or directives are in force outside these areas.

Products intended for sale in US markets

EN 59005/ANSI C95.1: Considerations for evaluation of human exposure to Electromagnetic Fields (EMFs) from Mobile Telecommunication Equipment (MTE) in the frequency range 30MHz – 6GHz

Products intended for sale in European markets

EN 50360: Product standard to demonstrate the compliance of mobile phones with the basic restrictions related to human exposure to electromagnetic fields (300MHz - 3GHz)

Please note that SAR requirements are specific only for portable devices and not for mobile devices as defined below:

- **Portable device:**
A portable device is defined as a transmitting device designed to be used so that the radiating structure(s) of the device is/are within 20 centimeters of the user's body.
- **Mobile device:**
A mobile device is defined as a transmitting device designed to be used in other than fixed locations and to generally be used in such a way that a separation distance of at least 20 centimeters is normally maintained between the transmitter's radiating structure(s) and the user's body or that of nearby persons. In this context, the term "fixed location" means that the device is physically secured at one location and cannot be easily moved to another location.

12.3 SELV requirements

The power supply connected to the MTX-3G-JAVA modem shall be in compliance with the SELV requirements defined in EN 60950-1.

13. RoHS Statement

The MTX-3G-JAVA modem is compliant with the 2002/95/EC Directive of the European Parliament and of the Council of 27 January 2003 on the restriction of the use of certain hazardous substances in electrical and electronic equipment (RoHS).



14. Disposal of old electrical & electronic equipment



This symbol, applied on our products and/or on its packaging, indicates that this product should not be treated as household waste when you wish to dispose of it. Instead, it should be handed over to an applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences to the environment and human health, which could otherwise be caused by inappropriate disposal of this product. The recycling of materials will help to conserve natural resources. For more detailed information about the recycling of this product, please contact your local city office, household waste disposal service or the retail store where you purchased this product.

15. Abbreviations

Abbreviation	Description
ADC	Analog-to-digital converter
AGC	Automatic Gain Control
ANSI	American National Standards Institute
ARFCN	Absolute Radio Frequency Channel Number
ARP	Antenna Reference Point
ASC0/ASC1	Asynchronous Controller. Abbreviations used for first and second serial interface of EHS6
B	Thermistor Constant
BER	Bit Error Rate
BTS	Base Transceiver Station
CB or CBM	Cell Broadcast Message
CE	Conformité Européene (European Conformity)
CHAP	Challenge Handshake Authentication Protocol
CPU	Central Processing Unit
CS	Coding Scheme
CSD	Circuit Switched Data
CTS	Clear to Send
DAC	Digital-to-Analog Converter
DAI	Digital Audio Interface
dBm0	Digital level, 3.14dBm0 corresponds to full scale, see ITU G.711, A-law
DCE	Data Communication Equipment (typically modems, e.g. Gemalto M2M module)
DCS 1800	Digital Cellular System, also referred to as PCN
DL	Download
dnu	Do not use
DRX	Discontinuous Reception
DSB	Development Support Box
DSP	Digital Signal Processor
DSR	Data Set Ready
DTE	Data Terminal Equipment (typically a computer, terminal, printer or, for example, a GSM application)
DTR	Data Terminal Ready
DTX	Discontinuous Transmission
EDGE	Enhanced Data rates for GSM Evolution
EFR	Enhanced Full Rate
EGSM	Enhanced GSM
EIRP	Equivalent Isotropic Radiated Power
EMC	Electromagnetic Compatibility
ERP	Effective Radiated Power
ESD	Electrostatic Discharge
ETS	European Telecommunication Standard
ETSI	European Telecommunications Standards Institute
FCC	Federal Communications Commission (U.S.)
FDD	Frequency Division Duplex
FDMA	Frequency Division Multiple Access

FR	Full Rate
GMSK	Gaussian Minimum Shift Keying
GPIO	General Purpose Input/Output
GPRS	General Packet Radio Service
GSM	Global Standard for Mobile Communications
HiZ	High Impedance
HR	Half Rate
HSDPA	High Speed Downlink Packet Access
I/O	Input/Output
IC	Integrated Circuit
IMEI	International Mobile Equipment Identity
ISO	International Standards Organization
ITU	International Telecommunications Union
kbps	kbits per second
LED	Light Emitting Diode
Li-Ion/Li+	Lithium-Ion
Li battery	Rechargeable Lithium Ion or Lithium Polymer battery
LPM	Link Power Management
MBB	Moisture barrier bag
Mbps	Mbits per second
MCS	Modulation and Coding Scheme
MMI	Man Machine Interface
MO	Mobile Originated
MS	Mobile Station (GSM module), also referred to as TE
MSISDN	Mobile Station International ISDN number
MSL	Moisture Sensitivity Level
MT	Mobile Terminated
nc	Not connected
NTC	Negative Temperature Coefficient
OEM	Original Equipment Manufacturer
PA	Power Amplifier
PAP	Password Authentication Protocol
PBCCH	Packet Switched Broadcast Control Channel
PCB	Printed Circuit Board
PCL	Power Control Level
PCM	Pulse Code Modulation
PCN	Personal Communications Network, also referred to as DCS 1800
PCS	Personal Communication System, also referred to as GSM 1900
PD	Pull Down resistor (appr. 100k)
PDU	Protocol Data Unit
PLL	Phase Locked Loop
PPP	Point-to-point protocol
PS	Packet Switched
PSK	Phase Shift Keying
PSU	Power Supply Unit

PU	Pull Up resistor (appr. 100k)
PWM	Pulse Width Modulation
QAM	Quadrature Amplitude Modulation
R&TTE	Radio and Telecommunication Terminal Equipment
RAM	Random Access Memory
RF	Radio Frequency
RLS	Radio Link Stability
RMS	Root Mean Square (value)
RoHS	Restriction of the use of certain hazardous substances in electrical and electronic equipment.
ROM	Read-only Memory
RTC	Real Time Clock
RTS	Request to Send
Rx	Receive Direction
SAR	Specific Absorption Rate
SAW	Surface Acoustic Wave
SELV	Safety Extra Low Voltage
SIM	Subscriber Identification Module
SMD	Surface Mount Device
SMS	Short Message Service
SMT	Surface Mount Technology
SPI	Serial Peripheral Interface
SRAM	Static Random Access Memory
SRB	Signalling Radio Bearer
TA	Terminal adapter (e.g. GSM module)
TDMA	Time Division Multiple Access
TE	Terminal Equipment, also referred to as DTE
TLS	Transport Layer Security
TPC	Transmit Power Control
TS	Technical Specification
Tx	Transmit Direction
UART	Universal asynchronous receiver-transmitter
UICC	USIM Integrated Circuit Card
UL	Upload
UMTS	Universal Mobile Telecommunications System
URC	Unsolicited Result Code
USB	Universal Serial Bus
USIM	UMTS Subscriber Identification Module
USSD	Unstructured Supplementary Service Data
VSWR	Voltage Standing Wave Ratio
WCDMA	Wideband Code Division Multiple Access

16. AT command summary

The AT standard is a line-oriented command language. AT is an abbreviation of ATtention and it is always used to send a command line from the terminal equipment (TE) to the terminal adaptor (TA). The command line consists of a string of alphanumeric characters. It is sent to the MTX-3G-JAVA to instruct it to perform the commands specified by the characters.

The AT commands listed below are supported from within the MTX-3G-JAVA. The AT Command Set manual can be downloaded from the MTX-3G-JAVA web page at www.mtxm2m.com.

AT Command	Description
+++	Switch from data mode or PPP online mode to command mode
A/	Repeat Previous Command Line
AT&C	Set Data Carrier Detect (DCD) Line Mode
AT&D	Set Data Terminal Ready (DTR) Line Mode
AT&F	Reset AT Command Settings to Factory Default Values
AT&S	Set Data Set Ready (DSR) Line Mode
AT&V	Display current configuration
AT&W	Store AT Command Settings to User Defined Profile
AT+CACM	Accumulated call meter (ACM) reset or query
AT+CALA	Alarm Configuration
AT+CAMM	Accumulated call meter maximum (ACMmax) set or query
AT+CAOC	Advise of Charge Information
AT+CBST	Select Bearer Service Type
AT+CCFC	Call forwarding number and conditions control
AT+CCID	USIM Card Identification Number
AT+CCLK	Real Time Clock
AT+CCUG	Closed User Group
AT+CCWA	Call Waiting
AT+CEER	Extended Error Report
AT+CFUN	Functionality Level
AT+CGACT	PDP context activate or deactivate
AT+CGANS	Manual response to a network request for PDP context activation
AT+CGATT	GPRS attach or detach
AT+CGAUTO	Automatic response to a network request for PDP context activation
AT+CGCMOD	PDP Context Modify
AT+CGDATA	Enter data state
AT+CGDCONT	Define PDP Context
AT+CGEQMIN	Rel. 99 Quality of Service Profile (Minimum acceptable)
AT+CGEQREQ	Rel. 99 Quality of Service Profile (Requested)
AT+CGEREP	GPRS event reporting
AT+CGMI	Request manufacturer identification
AT+CGMM	Request model identification
AT+CGMR	Request revision identification of software status
AT+CGPADDR	Show PDP address

AT+CGQMIN	Quality of Service Profile (Minimum acceptable)
AT+CGQREQ	Quality of Service Profile (Requested)
AT+CGREG	Packet Domain Network Registration Status
AT+CGSMS	Select service for MO SMS messages
AT+CGSN	Request International Mobile Equipment Identity (IMEI)
AT+CHLD	Call Hold and Multiparty
AT+CHUP	Hang up call
AT+CIMI	Request International Mobile Subscriber Identity (IMSI)
AT+CLCC	List of current calls
AT+CLCK	Facility lock
AT+CLIP	Calling Line Identification Presentation
AT+CLIR	Calling Line Identification Restriction
AT+CMEE	Error Message Format
AT+CMGC	Send SMS Command
AT+CMGD	Delete short message
AT+CMGF	Select SMS message format
AT+CMGL	List SMS messages from preferred store
AT+CMGR	Read SMS messages
AT+CMGS	Send SMS
AT+CMGW	Write Short Messages to Memory
AT+CMMS	More Messages to Send
AT+CMSS	Send short messages from storage
AT+CMUT	Mute control
AT+CMUX	Multiplex mode
AT+CNAP	Calling Name Presentation
AT+CNMA	New Message Acknowledgement to ME/TE
AT+CNMI	SMS Event Reporting Configuration
AT+CNUM	Read own numbers
AT+COLP	Connected Line Identification Presentation
AT+COPN	Read operator names
AT+COPS	Operator Selection
AT+CPAS	Activity Status
AT+CPBF	Find phonebook entries
AT+CPBR	Read from Phonebook
AT+CPBS	Select phonebook memory storage
AT+CPBW	Write into Phonebook
AT+CPIN	PIN Authentication
AT+CPIN2	PIN2 Authentication
AT+CPLS	Select Preferred Operator List
AT+CPMS	Preferred SMS message storage
AT+CPOL	Preferred Operator List
AT+CPUC	Price per unit and currency table
AT+CPWD	Change Password
AT+CR	Service reporting control
AT+CRC	Incoming Call Indication Format

AT+CREG	Network Registration Status
AT+CRLP	Configure RLP Parameters for Outgoing Non-Transparent Data Calls
AT+CRSM	Restricted SIM Access
AT+CSCA	SMS Service Center Address
AT+CSCB	Select Cell Broadcast Message Indication
AT+CSCS	Character Set
AT+CSDH	Show SMS text mode parameters
AT+CSIM	Generic USIM Access
AT+CSMP	Set SMS Text Mode Parameters
AT+CSMS	Select Message Service
AT+CSQ	Signal quality
AT+CSSN	Supplementary service notifications
AT+CSTA	Select type of address
AT+CSVM	Set voice mail number
AT+CTZR	Time Zone Reporting
AT+CTZU	Automatic Time Zone Update
AT+CUSD	Unstructured Supplementary Service Data
AT+GSN	Request International Mobile Equipment Identity (IMEI)
AT+IPR	Bit Rate
AT+STKCC	USAT Call Control Notification
AT+STKCNF	USAT Proactive Session Status
AT+STKENV	USAT Envelope Command
AT+STKPRO	USAT Proactive Command URCS
AT+STKTR	USAT Terminal Response Commands
AT+VTD	Tone duration
AT+VTS	DTMF and tone generation
AT\Q	Flow Control
AT^SBV	Battery/Supply Voltage
AT^SCCNT	Configure Pulse Counter
AT^SCFG	Extended Configuration Settings
AT^SCPIN	Pin Configuration
AT^SCPOL	Polling Configuration
AT^SCTM	Critical Operating Temperature Monitoring
AT^SFDL	Firmware Download
AT^SFSA	Flash File System Access
AT^SGAUTH	Set Type of Authentication for PDP-IP Connections
AT^SGIO	Get IO state of a specified pin or port
AT^SHUP	Hang up call(s) indicating a specific 3GPP TS 24.008 release cause
AT^SICI	Internet Connection Information
AT^SICS	Internet Connection Setup Profile
AT^SIND	Extended Indicator Control
AT^SIPS	Internet Profile Storage
AT^SISC	Internet Service Close
AT^SISE	Internet Service Error Report
AT^SISH	Internet Listener Service Disconnect

AT^SISI	Internet Service Information
AT^SISO	Internet Service Open
AT^SISR	Internet Service Read Data
AT^SISS	Internet Service Setup Profile
AT^SIST	Enter Transparent Access Mode
AT^SISW	Internet Service Write Data
AT^SISX	Internet Service Execution
AT^SJAM	Manage Java Application
AT^SJDL	Java Download
AT^SJMSEC	Java Midlet Security
AT^SJNET	Set Dialup Network Access Parameters
AT^SJOTAP	Over The Air Application Provisioning
AT^SJRA	Run Java Application
AT^SLED	LED Feature
AT^SMGL	List Short Messages from preferred store without setting status to REC READ
AT^SMGR	Read short message without setting status to REC READ
AT^SMONI	Monitoring Serving Cell
AT^SMONP	Monitoring Neighbour Cells
AT^SMSO	Switch Off EHS6
AT^SNFI	Set microphone path parameters
AT^SNFM	Set microphone audio path and power supply
AT^SNFO	Set audio output (= loudspeaker path) parameter
AT^SNFS	Select audio hardware set
AT^SNFTTY	Signal TTY/CTM audio mode capability
AT^SNMON	Network monitoring
AT^SPIO	GPIO Driver Open/Close
AT^SPOW	Set UART Mode and SLEEP Mode on UART
AT^SRADC	Configure and Read ADC Measurement
AT^SRTC	Ring tone configuration
AT^SSCNT	Start and Stop Pulse Counter
AT^SSIO	Set IO state of a specified pin or port
AT^SSPI	Serial Protocol Interface
AT^SSTA	Remote-SAT Interface Activation
AT^SWDAC	PWM Signal Configuration for DAC
AT^SXCALLSTAT	Set Reporting Call Status
AT^SXEONS	Display Eons names
AT^SXRAT	Selection of Radio Access Technology
ATA	Connect to Incoming Call
ATA	Manual acceptance of a network request for PDP context activation
ATD	Mobile originated call to specified number
ATD*99#	Request Packet Domain Service
ATD><mem><n>	Mobile originated call using specific memory and index number
ATD><n>	Mobile originated call from active memory using index number
ATD><str>	Mobile originated call from active memory using corresponding field
ATDL	Redial last number used

ATE	AT Command Echo
ATH	Disconnect existing connection
ATI	Display product identification information
ATL	Set monitor speaker loudness
ATO	Switch from command mode to data mode / PPP online mode
ATQ	Result Code Presentation Mode
ATS0	Set number of rings before automatically answering a call
ATS10	Set disconnect delay after indicating the absence of data carrier
ATS3	Command Line Termination
ATS4	Response Formatting
ATS5	Command Line Editing
ATS6	Set pause before blind dialing
ATS7	Set number of seconds to wait for connection completion
ATS8	Comma Dial Pause Time
ATV	Result code format mode
ATX	CONNECT Result Code Format
ATZ	Restore AT Command Settings from User Defined Profile

17. Accessories

The MTX-3G-JAVA has a wide range of available accessories, including:

- Power supplies
- All type of antennas (indoor, outdoor, high gain, etc...)
- Cables and DIN adapters

The MTX-3G-JAVA is shipped without any accessories.

Please visit the following web sites to see the full range of accessories:

- www.mtxm2m.com

18. Sales contact

www.mtxm2m.com

Matrix Madrid	Matrix Barcelona	Matrix Bilbao	Matrix Valencia
Matrix Electrónica S.L. C/ Alejandro Sánchez, 109 28019 Madrid (SPAIN) Phone 1: 902 19 81 46 Phone 2: +34915602737 Fax 1: 902 99 54 14 Fax 2: +34915652865	Matrix Electrónica S.L. Ctra. Rubí a Sabadell Km 13 Nave 109, Oficinas 6-9 08191 Rubí, Barcelona (SPAIN) Phone 1: 902 19 81 46 Fax 1: 902 99 54 14	Matrix Electrónica S.L. Pol. Aliendalde, 11 Oficina 2G 48200 - Durango, Vizcaya (SPAIN) Phone 1: 902 19 81 46 Fax 1: 902 99 54 14	Matrix Electrónica S.L. Valencia (SPAIN) Phone 1: 902 19 81 46 Fax 1: 902 99 54 14
Matrix Sevilla	Matrix Lisboa	Matrix Santiago de Chile	
Matrix Electrónica S.L. Sevilla (SPAIN) Phone: 902 19 81 46 Fax: 902 99 54 14 Phone 1: 902 19 81 46 Fax 1: 902 99 54 14	LusoMatrix Lda. Av. Coronel Eduardo Galhardo, 7 1ºC 1170-105 - Lisboa (PORTUGAL) Phone 1: +351218162625 Fax 1: +351218149482	Matrix Electrónica S.L. Calle Badajoz, 100 Oficina 1305 Santiago de Chile (CHILE) Phone 1: +56(9)53369943 Phone 2: +56(9)74822647	